

PILOT'S OPERATING HANDBOOK

PIPER CHEROKEE TURBO ARROW III



FAA APPROVED IN NORMAL CATEGORY BASED ON CAR 3 AND FAR PART 21, SUBPART J. THIS HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY CAR 3 AND FAR PART 21, SUBPART J AND CONSTITUTES THE APPROVED AIRPLANE FLIGHT MANUAL AND MUST BE CARRIED IN THE AIRPLANE AT ALL TIMES.

AIRPLANE SERIAL NO. _____

AIRPLANE REGISTRATION NO. _____

PA-28R-201T
REPORT: VB-800

FAA APPROVED BY: _____

*H.W. Benhouse for
Ward Evans*

WARD EVANS
D.O.A. NO. SO-1
PIPER AIRCRAFT CORPORATION
VERO BEACH, FLORIDA

DATE OF APPROVAL: DECEMBER 20, 1976



WARNING

EXTREME CARE MUST BE EXERCISED TO LIMIT THE USE OF THIS MANUAL TO APPLICABLE AIRCRAFT. THIS MANUAL REVISED AS INDICATED BELOW OR SUBSEQUENTLY REVISED IS VALID FOR USE WITH THE AIRPLANE IDENTIFIED ON THE FACE OF THE TITLE PAGE WHEN OFFICIALLY APPROVED. SUBSEQUENT REVISIONS SUPPLIED BY PIPER AIRCRAFT CORPORATION MUST BE PROPERLY INSERTED.

MODEL PA-28R-201T, CHEROKEE TURBO ARROW III

PILOT'S OPERATING HANDBOOK, REPORT: VB-800 REVISION _____

PIPER AIRCRAFT CORPORATION
APPROVAL SIGNATURE AND STAMP _____

Published by
PUBLICATIONS DEPARTMENT
Piper Aircraft Corporation
Issued: December 20, 1976

APPLICABILITY

Application of this handbook is limited to the specific Piper PA-28R-201T model airplane designated by serial number and registration number on the face of the title page of this handbook.

This handbook cannot be used for operational purposes unless kept in a current status.

REVISIONS

The information compiled in the Pilot's Operating Handbook will be kept current by revisions distributed to the airplane owners.

Revision material will consist of information necessary to update the text of the present handbook and/or to add information to cover added airplane equipment.

I. Revisions

Revisions will be distributed whenever necessary as complete page replacements or additions and shall be inserted into the handbook in accordance with the instructions given below:

1. Revision pages will replace only pages with the same page number.
2. Insert all additional pages in proper numerical order within each section.
3. Page numbers followed by a small letter shall be inserted in direct sequence with the same common numbered page.

II. Identification of Revised Material

Revised text and illustrations shall be indicated by a black vertical line along the outside margin of the page, opposite revised, added or deleted material. A line along the outside margin of the page opposite the page number will indicate that an entire page was added.

Black lines will indicate only current revisions with changes and additions to or deletions of existing text and illustrations. Changes in capitalization, spelling, punctuation or the physical location of material on a page will not be identified by symbols.

ORIGINAL PAGES ISSUED

The original pages issued for this handbook prior to revision are given below:

Title ii through v, 1-1 through 1-14, 2-1 through 2-10, 3-1 through 3-16, 4-1 through 4-20, 5-1 through 5-32, 6-1 through 6-56, 7-1 through 7-28, 8-1 through 8-16, 9-1 through 9-16, 10-1 through 10-2.

PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-28R-201T Cherokee Turbo Arrow III Pilot's Operating Handbook, REPORT: VB-800 issued December 20, 1976.

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 1 - 761 636 (PR770128)	6-4 6-44 7-3 8-i, 8-15	Revised Figure 6-3. Revised item 195. Revised para. 7.5 (added winterization reference). Added para 8.29 (Winterization).	<i>Ward Evans</i> Ward Evans Jan. 28, 1977
Rev. 2 - 761 636 (PR770407)	1-6 2-5 6-53 7-3 7-28 9-7 9-8 9-9	Revised (b) heading to read "Meteorological." Revised para. 2.25. Added Piper Dwg. Nos. to items 287 and 289. Revised fuel injection description in para. 7.5. Revised ELT test info in NOTE. Added STC No. to Section 1 - General; revised (a), (c) and (d) in Section 3 - Emergency Procedures. Revised item (c) (2) and (d) (1) NOTE. Added STC No. to Section 1 - General; revised (a) (1) and (d) in Section 3 - Emergency Procedures.	<i>Ward Evans</i> Ward Evans April 7, 1977
Rev. 3 - 761 636 (PR770713)	1-11, 1-12, 1-13, 1-14 3-3 3-8 3-9 4-6 4-16 6-17 6-45 6-46 6-47 6-48 6-49 6-53 6-54 7-6	Revised Conversion Factors Revised airspeeds under Engine Power Loss In Flight and Power Off Landing. Revised airspeed under para. 3.11, Engine Power Loss In Flight. Revised airspeed under para. 3.13, Power Off Landing. Revised Climb procedure. Revised para. 4.33, Climb. Added item 3. Added new item 213; revised item nos.; re-located item to page 6-46. Added item from pg. 6-46; revised item nos.; added new items; relocated items to pg. 6-47. Added new items; added items from pg. 6-46; relocated items to pg. 6-48. Added new items; added items from pg. 6-47. Revised item nos.; revised item 273; added item 281. Revised item nos.; revised items 325 and 329; added items from pg. 6-54. Revised item nos.; relocated items to pg. 6-53; added new items; revised item 351. Revised airspeed under para. 7.9, Landing Gear.	<i>Ward Evans</i> Ward Evans July 13, 1977

TABLE OF CONTENTS

SECTION 1	GENERAL
SECTION 2	LIMITATIONS
SECTION 3	EMERGENCY PROCEDURES
SECTION 4	NORMAL PROCEDURES
SECTION 5	PERFORMANCE
SECTION 6	WEIGHT AND BALANCE
SECTION 7	DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS
SECTION 8	AIRPLANE HANDLING, SERVICING AND MAINTENANCE
SECTION 9	SUPPLEMENTS
SECTION 10	SAFETY TIPS

TABLE OF CONTENTS

SECTION 1

GENERAL

Paragraph No.		Page No.
1.1	Introduction	1-1
1.3	Engines	1-3
1.5	Propellers	1-3
1.7	Fuel	1-3
1.9	Oil	1-3
1.11	Maximum Weights	1-4
1.13	Standard Airplane Weights	1-4
1.15	Baggage Space	1-4
1.17	Specific Loadings	1-4
1.19	Symbols, Abbreviations and Terminology	1-5
1.21	Conversion Factors	1-11

SECTION 1

GENERAL

1.1 INTRODUCTION


This Pilot's Operating Handbook is designed for maximum utilization as an operating guide for the pilot. It includes the material required to be furnished to the pilot by C.A.R. 3 and FAR Part 21 Subpart J. It also contains supplemental data supplied by the airplane manufacturer.

This handbook is not designed as a substitute for adequate and competent flight instruction, knowledge of current airworthiness directives, applicable federal air regulations or advisory circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in a current status.

Assurance that the airplane is in an airworthy condition is the responsibility of the owner. The pilot in command is responsible for determining that the airplane is safe for flight. The pilot is also responsible for remaining within the operating limitations as outlined by instrument markings, placards, and this handbook.

Although the arrangement of this handbook is intended to increase its in-flight capabilities, it should not be used solely as an occasional operating reference. The pilot should study the entire handbook to familiarize himself with the limitations, performance, procedures and operational handling characteristics of the airplane before flight.

The handbook has been divided into numbered (arabic) sections each provided with a "finger-tip" tab divider for quick reference. The limitations and emergency procedures have been placed ahead of the normal procedures, performance and other sections to provide easier access to information that may be required in flight. The "Emergency Procedures" Section has been furnished with a red tab divider to present an instant reference to the section. Provisions for expansion of the handbook have been made by the deliberate omission of certain paragraph numbers, figure numbers, item numbers and pages noted as being intentionally left blank.



THREE VIEW

Figure 1-1

1.3 ENGINES

(a) Number of Engines	1
(b) Engine Manufacturer	Teledyne Continental
(c) Engine Model Number	TSIO-360-F
(d) Rated Horsepower	200 Sea Level to 12,000 Ft. Density Altitude
(e) Rated Speed (rpm)	2575
(f) Maximum Manifold Pressure (inches mercury)	41
(g) Bore (inches)	4.438
(h) Stroke (inches)	3.875
(i) Displacement (cubic inches)	360
(j) Compression Ratio	7.5:1
(k) Engine Type	Six Cylinder, Direct Drive, Horizontally Opposed, Air Cooled, Turbocharged and Fuel Injected

1.5 PROPELLERS

(a) Number of Propellers	1
(b) Propeller Manufacturer	Hartzell
(c) Blade Model	F8459A-8R
(d) Number of Blades	2
(e) Hub Model	BHC-C2YF-1BF
(f) Propeller Diameter (inches)	
(1) Maximum	76
(2) Minimum	75
(g) Propeller Type	Constant Speed, Hydraulically Actuated

1.7 FUEL

(a) Fuel Capacity (U.S. gal) (total)	77
(b) Usable Fuel (U.S. gal) (total)	72
(c) Fuel Grade, Aviation	
(1) Minimum Octane	100 LL - Blue or 100/130 - Green
(2) Specified Octane	100 LL - Blue or 100/130 - Green
(3) Alternate Fuels	Refer to latest revision of Continental Service Bulletin "Fuel and Oil Grades"

1.9 OIL

(a) Oil Capacity (U.S. quarts)	8
(b) Oil Specification	MHS-24A
(c) Oil Viscosity	
(1) Above 40°F Ambient Air (Sea Level)	SINGLE SAE 50
(2) Below 40°F Ambient Air (Sea Level)	SAE 30
	MULTI See Teledyne Continental TSIO-360-F Operator's Manual

1.11 MAXIMUM WEIGHTS

(a) Maximum Takeoff Weight (lbs)	2900
(b) Maximum Landing Weight (lbs)	2900
(c) Maximum Weights in Baggage Compartment	200

1.13 STANDARD AIRPLANE WEIGHTS

(a) Standard Empty Weight (lbs): Weight of a standard airplane including unusable fuel, full operating fluids and full oil.	1645
(b) Maximum Useful Load (lbs)*: The difference between the Maximum Takeoff Weight and the Standard Empty Weight.	1255

1.15 BAGGAGE SPACE

(a) Compartment Volume (cubic feet)	24
(b) Entry Width (inches)	22
(c) Entry Height (inches)	20

1.17 SPECIFIC LOADINGS

(a) Wing Loading (lbs per sq ft)	17
(b) Power Loading (lbs per hp)	14.5

*This value is for a standard airplane without optional equipment. Refer to Figure 6-5 for the useful load value to be used for C.G. calculations for the airplane specified.

1.19 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

The following definitions are of symbols, abbreviations and terminology used throughout the handbook and those which may be of added operational significance to the pilot.

(a) General Airspeed Terminology and Symbols

CAS	Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KCAS	Calibrated Airspeed expressed in "Knots."
GS	Ground Speed is the speed of an airplane relative to the ground.
IAS	Indicated Airspeed is the speed of an aircraft as shown on the airspeed indicator when corrected for instrument error. IAS values published in this handbook assume zero instrument error.
KIAS	Indicated Airspeed expressed in "Knots."
M	Mach Number is the ratio of true airspeed to the speed of sound.
TAS	True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressability.
V_A	Maneuvering Speed is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.
V_{FE}	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
V_{LE}	Maximum Landing Gear Extended Speed is the maximum speed at which an aircraft can be safely flown with the landing gear extended.
V_{LO}	Maximum Landing Gear Operating Speed is the maximum speed at which the landing gear can be safely extended or retracted.
V_{NE}/M_{NE}	Never Exceed Speed or Mach Number is the speed limit that may not be exceeded at any time.
V_{NO}	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air and then only with caution.

V_S	Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
V_{SO}	Stalling Speed or the minimum steady flight speed at which the airplane is controllable in the landing configuration.
V_X	Best Angle-of-Climb Speed is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
V_Y	Best Rate-of-Climb Speed is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

(b) Meteorological Terminology

ISA	International Standard Atmosphere in which: The air is a dry perfect gas; The temperature at sea level is 15° Celcius (59° Fahrenheit); The pressure at sea level is 29.92 inches hg. (1013 mb); The temperature gradient from sea level to the altitude at which the temperature is -56.5° C (-69.7°F) is -0.00198°C (-0.003566°F) per foot and zero above that altitude.
OAT	Outside Air Temperature is the free air static temperature, obtained either from inflight temperature indications or ground meteorological sources, adjusted for instrument error and compressibility effects.
Indicated Pressure Altitude	The number actually read from an altimeter when the barometric subscale has been set to 29.92 inches of mercury (1013 millibars).
Pressure Altitude	Altitude measured from standard sea-level pressure (29.92 in. Hg) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error. In this handbook, altimeter instrument errors are assumed to be zero.
Station Pressure	Actual atmospheric pressure at field elevation.
Wind	The wind velocities recorded as variables on the charts of this handbook are to be understood as the headwind or tailwind components of the reported winds.

(c) Power Terminology

Takeoff Power	Maximum power permissible for takeoff.
Maximum Continuous Power	Maximum power permissible continuously during flight.
Maximum Climb Power	Maximum power permissible during climb.
Maximum Cruise Power	Maximum power permissible during cruise.

(d) Engine Instruments

EGT Gauge	Exhaust Gas Temperature Gauge
-----------	-------------------------------

(e) Airplane Performance and Flight Planning Terminology

Climb Gradient	The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval.
Demonstrated Crosswind Velocity	The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests.
Accelerate-Stop Distance	The distance required to accelerate an airplane to a specified speed and, assuming failure of an engine at the instant that speed is attained, to bring the airplane to a stop.
MEA	Minimum en route IFR altitude.
Route Segment	A part of a route. Each end of that part is identified by: (1) a geographical location; or (2) a point at which a definite radio fix can be established.

(f) Weight and Balance Terminology

Reference Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Arm	The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Moment	The product of the weight of an item multiplied by its arm. (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Center of Gravity (C.G.)	The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	The extreme center of gravity locations within which the airplane must be operated at a given weight.
Usable Fuel	Fuel available for flight planning.
Unusable Fuel	Fuel remaining after a runout test has been completed in accordance with governmental regulations.
Standard Empty Weight	Weight of a standard airplane including unusable fuel, full operating fluids and full oil.
Basic Empty Weight	Standard empty weight plus optional equipment.
Payload	Weight of occupants, cargo and baggage.
Useful Load	Difference between takeoff weight, or ramp weight if applicable, and basic empty weight.
Maximum Ramp Weight	Maximum weight approved for ground maneuver. (It includes weight of start, taxi and run up fuel.)
Maximum Takeoff Weight	Maximum weight approved for the start of the takeoff run.
Maximum Landing Weight	Maximum weight approved for the landing touchdown.
Maximum Zero Fuel Weight	Maximum weight exclusive of usable fuel.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

1.21 CONVERSION FACTORS

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	
acres	0.4047	ha	cubic inches (cu. in.)	16.39	cm ³	
	43560	sq. ft.		1.639×10^{-5}	m ³	
	0.0015625	sq. mi.		5.787×10^{-4}	cu. ft.	
atmospheres (atm)	76	cm Hg	cubic meters (m ³)	0.5541	fl. oz.	
	29.92	in. Hg		0.01639	1	
	1.0133	bar		4.329×10^{-3}	U.S. gal.	
	1.033	kg/cm ²		0.01732	U.S. qt.	
	14.70	lb./sq. in.				
	2116	lb./sq. ft.				
bars (bar)	0.98692	atm.	cubic meters per minute (m ³ /min.)	35.3147	cu. ft./min.	
	14.503768	lb./sq. in.				
British Thermal Unit (BTU)	0.2519958	kg-cal	cubic yards (cu. yd.)	27	cu. ft.	
centimeters (cm)	0.3937	in.		0.7646	m ³	
	0.032808	ft.		202	U.S. gal.	
centimeters of mercury at 0°C (cm Hg)	0.01316	atm	degrees (arc)	0.01745	radians	
	0.3937	in. Hg		degrees per second (deg./sec.)	0.01745	radians/sec.
	0.1934	lb./sq. in.				
	27.85	lb./sq. ft.				
135.95	kg/m ²					
centimeters per second (cm/sec.)	0.032808	ft./sec.	drams, fluid (dr. fl.)	0.125	fl. oz.	
	1.9685	ft./min.	drams, avdp. (dr. avdp.)	0.0625	oz. avdp.	
	0.02237	mph				
cubic centimeters (cm ³)	0.03381	fl. oz.	feet (ft.)	30.48	cm	
	0.06102	cu. in.		0.3048	m	
	3.531×10^{-5}	cu. ft.		12	in.	
	0.001	1		0.33333	yd.	
	2.642×10^{-4}	U.S. gal.		0.0606061	rod	
cubic feet (cu.ft.)	28317	cm ³	feet per minute (ft./min.)	1.894×10^{-4}	mi.	
	0.028317	m ³		1.645×10^{-4}	NM	
	1728	cu. in.		0.01136	mph	
	0.037037	cu. yd.		0.01829	km/hr.	
	7.481	U.S. gal.		0.508	cm/sec.	
	28.32	1		0.00508	m/sec.	
cubic feet per minute (cu. ft./min.)	0.472	1/sec.				
	0.028317	m ³ /min.				

**SECTION 1
GENERAL**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
feet per second (ft./sec.)	0.6818 1.097 30.48 0.5921	mph km/hr. cm/sec. kts.
foot-pounds (ft.-lb.)	0.1383255 3.24×10^{-4}	m-kg kg-cal
foot-pounds per minute (ft.-lb./min.)	3.030×10^{-5}	hp
foot-pounds per second (ft.-lb./sec.)	1.818×10^{-5}	hp
gallons, Imperial (Imperial gal.)	277.4 1.201 4.546	cu. in. U.S. gal. 1
gallons, U.S. dry (U.S. gal. dry)	268.8 1.556×10^{-1} 1.164 4.405	cu. in. cu. ft. U.S. gal. 1
gallons, U.S. liquid (U.S. gal.)	231 0.1337 4.951×10^{-3} 3785.4 3.785×10^{-3} 3.785 0.83268 128	cu. in. cu. ft. cu. yd. cm ³ m ³ 1 Imperial gal. fl. oz.
gallons per acre (gal./acre)	9.353	1/ha
grams (g)	0.001 0.3527 2.205×10^{-3}	kg oz. avdp. lb.
grams per centimeter (g/cm)	0.1 6.721×10^{-2} 5.601×10^{-3}	kg/m lb./ft. lb./in.
grams per cubic centimeter (g/cm ³)	1000 0.03613 62.43	kg/m ³ lb./cu. in. lb./cu. ft.

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
hectares (ha)	2.471 107639 10000	acres sq. ft. m ²
horsepower (hp)	33000 550 76.04 1.014	ft.-lb./min. ft.-lb./sec. m-kg/sec. metric hp
horsepower, metric	75 0.9863	m-kg/sec. hp
inches (in.)	25.40 2.540 0.0254 0.08333 0.027777	mm cm m ft. yd.
inches of mercury at 0°C (in. Hg)	0.033421 0.4912 70.73 345.3 2.540 25.40	atm lb./sq. in. lb./sq. ft. kg/m ² cm Hg mm Hg
inch-pounds (in.-lb.)	0.011521	m-kg
kilograms (kg)	2.204623 35.27 1000	lb. oz. avdp. g
kilogram-calories (kg-cal)	3.9683 3087 426.9	BTU ft.-lb. m-kg
kilograms per cubic meter (kg/m ³)	0.06243 0.001	lb./cu. ft. g/cm ³
kilograms per hectare (kg/ha)	0.892	lb./acre
kilograms per square centimeter (kg/cm ²)	0.9678 28.96 14.22 2048	atm in. Hg lb./sq. in. lb./sq. ft.

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
kilograms per square meter (kg/m ²)	2.896 x 10 ⁻³ 1.422 x 10 ⁻³ 0.2048	in. Hg lb./sq. in. lb./sq. ft.	meters per minute (m/min.)	0.06	km/hr.
kilometers (km)	1 x 10 ⁻⁵ 3280.8 0.6214 0.53996	cm ft. mi. NM	meters per second (m/sec.)	3.280840 196.8504 2.237 3.6	ft./sec. ft./min. mph km/hr.
kilometers per hour (km/hr.)	0.9113 58.68 0.53996 0.6214 0.27778 16.67	ft./sec. ft./min. kt mph m/sec. m/min.	microns	3.937 x 10 ⁻⁵	in.
knots (kt)	1 1.689 1.1516 1.852 51.48	nautical mph ft./sec. statute mph km/hr. m/sec.	miles, statute (mi.)	5280 1.6093 1609.3 0.8684	ft. km m NM
liters (l)	1000 61.02 0.03531 33.814 0.264172 0.2200 1.05669	cm ³ cu. in. cu. ft. fl. oz. U.S. gal. Imperial gal. qt.	miles per hour (mph)	44.7041 4.470 x 10 ⁻¹ 1.467 88 1.6093 0.8684	cm/sec. m/sec. ft./sec. ft./min. km/hr. kt
liters per hectare (l/ha)	13.69 0.107	fl. oz./acre gal./acre	miles per hour square (m/hr. sq.)	2.151	ft./sec. sq.
liters per second (l/sec.)	2.12	cu. ft./min.	millibars	2.953 x 10 ⁻²	in. Hg
meters (m)	39.37 3.280840 1.0936 0.198838 6.214 x 10 ⁻⁴ 5.3996 x 10 ⁻⁴	in. ft. yd. rod mi. NM	millimeters (mm)	0.03937	in.
meter-kilogram (m-kg)	7.23301 86.798	ft.-lb. in.-lb.	millimeters of mercury at 0°C (mm Hg)	0.03937	in. Hg
			nautical miles (NM)	6080 1.1516 1852 1.852	ft. statute mi. m km
			ounces, avdp. (oz. avdp.)	28.35 16	g dr. avdp.
			ounces, fluid (fl. oz.)	8 29.57 1.805 0.0296 0.0078	dr. fl. cm ³ cu. in. l U.S. gal.

**SECTION 1
GENERAL**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
ounces, fluid per acre (fl. oz./acre)	0.073	l/ha	rod	16.5 5.5 5.029	ft. yd. m
pounds (lb.)	0.453592 453.6 3.108×10^{-2}	kg g slug	slug	32.174	lb.
pounds per acre (lb./acre)	1.121	kg/ha	square centimeters (cm ²)	0.1550 0.001076	sq. in. sq. ft.
pounds per cubic foot (lb./cu. ft.)	16.02	kg/m ³	square feet (sq. ft.)	929 0.092903 144 0.1111 2.296×10^{-5}	cm ² m ² sq. in. sq. yd. acres
pounds per cubic inch (lb./cu. in.)	1728 27.68	lb./cu. ft. g/cm ³	square inches (sq. in.)	6.4516 6.944×10^{-3}	cm ² sq. ft.
pounds per square foot (lb./sq. ft.)	0.1414 4.88243 4.725×10^{-4}	in. Hg kg/m ² atm	square kilometers (km ²)	0.3861	sq. mi.
pounds per square inch (psi or lb./sq. in.)	5.1715 2.036 0.06804 0.0689476 703.1	cm Hg in. Hg atm bar kg/m ²	square meters (m ²)	10.76391 1.196 0.0001	sq. ft. sq. yd. ha
quart, U.S. (qt.)	0.94635 57.749	l cu. in.	square miles (sq. mi.)	2.590 640	km ² acres
radians	57.30 0.1592	deg. (arc) rev.	square rods (sq. rods)	30.25	sq. yd.
radians per second (radians/sec.)	57.30 0.1592 9.549	deg./sec. rev./sec. rpm	square yards (sq. yd.)	0.8361 9 0.0330579	m ² sq. ft. sq. rods
revolutions (rev.)	6.283	radians	yards (yd.)	0.9144 3 36 0.181818	m ft. in. rod
revolutions per minute (rpm or rev./min.)	0.1047	radians/sec.			
revolutions per second (rev./sec.)	6.283	radians/sec.			

TABLE OF CONTENTS

SECTION 2

LIMITATIONS

Paragraph No.		Page No.
2.1	General	2-1
2.3	Airspeed Limitations	2-1
2.5	Airspeed Indicator Markings	2-2
2.7	Power Plant Limitations	2-2
2.9	Power Plant Instrument Markings	2-3
2.11	Weight Limits	2-3
2.13	Center of Gravity Limits	2-4
2.15	Maneuver Limits	2-4
2.17	Flight Load Factors	2-4
2.19	Types of Operations	2-4
2.21	Fuel Limitations	2-5
2.23	Operating Altitude Limitations	2-5
2.25	Noise Level	2-5
2.27	Placards	2-7

SECTION 2
LIMITATIONS

2.1 GENERAL

This section provides the "FAA Approved" operating limitations, instrument markings, color coding and basic placards necessary for the safe operation of the airplane and its systems.

Limitations associated with those optional systems and equipment which require handbook supplements can be found in Section 9 (Supplements).

2.3 AIRSPEED LIMITATIONS

SPEED	KIAS	KCAS
Never Exceed Speed (V_{NE}) - Do not exceed this speed in any operation.	183	186
Maximum Structural Cruising Speed (V_{NO}) - Do not exceed this speed except in smooth air and then only with caution.	146	148
Design Maneuvering Speed (V_A) - Do not make full or abrupt control movements above this speed.		
At 2900 LBS. G.W.	119	121
At 1865 LBS. G.W.	96	96

CAUTION

Maneuvering speed decreases at lighter weight as the effects of aerodynamic forces become more pronounced. Linear interpolation may be used for intermediate gross weights. Maneuvering speed should not be exceeded while operating in rough air.

Maximum Flaps Extended Speed (V_{FE}) - Do not exceed this speed with the flaps extended.	103	104
Maximum Landing Gear Extension Speed - Do not exceed this speed when extending the landing gear.	129	130
Maximum Landing Gear Retraction Speed - Do not exceed this speed when retracting the landing gear.	107	109
Maximum Landing Gear Extended Speed (V_{LE}) - Do not exceed this speed with the landing gear extended.	129	130

2.5 AIRSPEED INDICATOR MARKINGS

MARKING	IAS
Red Radial Line (Never Exceed)	183 KTS
Yellow Arc (Caution Range - Smooth Air Only)	146 KTS to 183 KTS
Green Arc (Normal Operating Range)	63 KTS to 146 KTS
White Arc (Flap Down)	56 KTS to 103 KTS

2.7 POWER PLANT LIMITATIONS

(a) Number of Engines	1
(b) Engine Manufacturer	Teledyne Continental
(c) Engine Model No.	TSIO-360-F
(d) Engine Operating Limits	
(1) Maximum Horsepower	200
(2) Maximum Rotation Speed (RPM)	2575
(3) Maximum Manifold Pressure (In. Mercury)	41
(4) Maximum Oil Temperature	240° F
(e) Oil Pressure	
Minimum (red line)	10 PSI
Maximum (red line)	100 PSI
(f) Fuel Pressure	
Maximum (red line)	19 PSI
(g) Fuel Grade (minimum octane)	100LL - Blue or 100/130 - Green
(h) Number of Propellers	1
(i) Propeller Manufacturer	Hartzell
(j) Propeller Hub and Blade Model	BHC-C2YF-1BF/F8459A-8R
(k) Propeller Diameter	
Minimum	76 IN.
Maximum	75 IN.
(l) Blade Angle Limits	
Low Pitch Stop	14.2 ± .2°
High Pitch Stop	29 ± 1°

2.9 POWER PLANT INSTRUMENT MARKINGS

(a) Tachometer	
Green Arc (Normal Operating Range)	500 to 2000 RPM and 2200 to 2575 RPM
Yellow Arc (Avoid continuous operation above 32" Hg. manifold pressure)	2000 to 2200 RPM
Red Line (Maximum Continuous Power)	2575 RPM
(b) Oil Temperature	
Green Arc (Normal Operating Range)	100° to 240° F
Red Line (Maximum)	240° F
(c) Oil Pressure	
Green Arc (Normal Operating Range)	30 PSI to 80 PSI
Yellow Arc (Caution Range) (Idle)	10 PSI to 30 PSI
Yellow Arc (Caution Range) (Start and Warm Up)	80 PSI to 100 PSI
Red Line (Minimum)	10 PSI
Red Line (Maximum)	100 PSI
(d) Fuel Pressure	
Green Arc (Normal Operating Range)	3.5 PSI to 19 PSI
Red Line (Maximum)	19 PSI
(e) Exhaust Gas Temperature (EGT)	
Green Arc (Normal Operating Range)	1200° F to 1650° F
Red Line (Maximum)	1650° F
(f) Manifold Pressure	
Green Arc (Normal Operating Range)	10 IN. to 41 IN. HG.
Red Line (Maximum)	41 IN. HG.

2.11 WEIGHT LIMITS

(a) Maximum Weight	2900 LBS
(b) Maximum Baggage	200 LBS

NOTE

Refer to Section 5 (Performance) for maximum weight as limited by performance.

2.13 CENTER OF GRAVITY LIMITS

Weight Pounds	Forward Limit Inches Aft of Datum	Rearward Limit Inches Aft of Datum
2900	86.0	90.0
2240	78.0	90.0

NOTES

Straight line variation between points given.

The datum used is 78.4 inches ahead of the wing leading edge at the intersection of the straight and tapered section.

It is the responsibility of the airplane owner and the pilot to insure that the airplane is properly loaded. See Section 6 (Weight and Balance) for proper loading instructions.

2.15 MANEUVER LIMITS

No acrobatic maneuvers including spins approved.

2.17 FLIGHT LOAD FACTORS

- (a) Positive Load Factor (Maximum) 3.8 G
- (b) Negative Load Factor (Maximum) No inverted maneuvers approved

2.19 TYPES OF OPERATIONS

The airplane is approved for the following operations when equipped in accordance with FAR 91 or FAR 135.

- (a) Day V.F.R.
- (b) Night V.F.R.
- (c) Day I.F.R.
- (d) Night I.F.R.
- (e) Non Icing

2.21 FUEL LIMITATIONS

- | | |
|--|-------------|
| (a) Total Capacity | 77 U.S. GAL |
| (b) Unusable Fuel | 5 U.S. GAL |
| The unusable fuel for this airplane has been determined as 2.5 gallons in each wing tank in critical flight attitudes. | |
| (c) Usable Fuel | 72 U.S. GAL |
| The usable fuel in this airplane has been determined as 36.0 gallons in each wing tank. | |
| (d) Fuel remaining when the quantity indicators read zero cannot be used safely in flight. | |

2.23 OPERATING ALTITUDE LIMITATIONS

Flight above 20,000 feet is not approved. Flight up to and including 20,000 feet is approved if equipped with oxygen in accordance with F.A.R. 23.1441 and avionics in accordance with F.A.R. 91 or F.A.R. 135.

2.25 NOISE LEVEL

The noise level of this aircraft is 68.8 dBA.

No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into, or out of, any airport.

The above statement notwithstanding the noise level stated above has been verified by and approved by the Federal Aviation Administration in noise level test flights conducted in accordance with FAR 36, Noise Standards - Aircraft Type and Airworthiness Certification. This aircraft model is in compliance with all FAR 36 noise standards applicable to this type.

THIS PAGE INTENTIONALLY LEFT BLANK

2.27 PLACARDS

In full view of the pilot:

“THIS AIRPLANE MUST BE OPERATED AS A NORMAL CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATING LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUALS.”

THIS AIRCRAFT APPROVED FOR NIGHT IFR NON-ICING FLIGHT WHEN EQUIPPED IN ACCORDANCE WITH FAR 91 or FAR 135.

In full view of the pilot, the following takeoff and landing check lists will be installed:

TAKEOFF CHECK LIST

Fuel on Proper Tank
Auxiliary Fuel Pump - Off
Engine Gauges - Checked
Alternate Air - Closed
Seat Backs Erect

Mixture - Set
Propeller - Set
Fasten Belts/Harness

Flaps - Set
Trim Tab - Set
Controls - Free
Doors - Latched
Air Conditioner - Off

LANDING CHECK LIST

Fuel on Proper Tank
Seat Backs Erect
Fasten Belts/Harness

Auxiliary Fuel Pump - Off
Mixture - Rich
Propeller - Set

Gear Down (129 KIAS Max)
Flaps - Set (103 KIAS Max)
Air Conditioner - Off

The “AIR CONDITIONER OFF” item in the above takeoff and landing check lists is mandatory for air conditioned aircraft only.

On the instrument panel in full view of the pilot:

MANEUVERING SPEED
119 KIAS AT 2900
LBS. (SEE P.O.H.)

On the instrument panel in full view of the pilot:

“DEMONSTRATED CROSSWIND COMPONENT 17 KTS”

On the instrument panel in full view of the pilot:

“NO ACROBATIC MANEUVERS, INCLUDING SPINS, APPROVED.”

On instrument panel in full view of the pilot:

"GEAR DOWN	129 KIAS (MAX)"
"GEAR UP	107 KIAS (MAX)"
"EXTENDED	129 KIAS (MAX)"

Near emergency gear lever:

"EMERGENCY DOWN"

"OVERRIDE ENGAGED AUTO-EXT-OFF
LOCK PIN ON SIDE
TO ENGAGE OVERRIDE:
PULL LEVER FULL UP, PUSH LOCK PIN
TO RELEASE OVERRIDE:
PULL LEVER FULL UP & RELEASE"

Near gear selector switch:

"GEAR UP	107 KIAS MAX"
"DOWN	129 KIAS MAX"

Adjacent to upper door latch:

"ENGAGE LATCH BEFORE FLIGHT"

On the instrument panel in full view of the pilot:

"WARNING – TURN OFF STROBE LIGHTS WHEN IN CLOSE
PROXIMITY TO GROUND OR DURING FLIGHT THROUGH
CLOUD, FOG OR HAZE."

In full view of the pilot, in the area of the air conditioner controls when the air conditioner is installed:

"WARNING – AIR CONDITIONER MUST BE OFF TO INSURE
NORMAL TAKEOFF CLIMB PERFORMANCE."

On inside of baggage compartment door:

"BAGGAGE MAXIMUM 200 LBS. SEE WEIGHT AND
BALANCE DATA FOR BAGGAGE LOADING BETWEEN 150
LBS AND 200 LBS."

Adjacent to fuel tank filler caps:

**“FUEL — 100/130 AVIATION GRADE — MIN. USABLE
CAPACITY 36 GAL.”**

**“USABLE CAPACITY TO BOTTOM OF FILLER NECK
INDICATOR 25 GAL.”**

Above fuel quantity gauges:

**“FUEL REMAINING WHEN QUANTITY INDICATOR READS
ZERO CANNOT BE USED SAFELY IN FLIGHT.”**

On the instrument panel in full view of the pilot:

**“AVOID CONTINUOUS GROUND OPERATION 1700-2100
RPM IN CROSS/TAIL WIND OVER 10 KTS.”**

**“AVOID CONTINUOUS OPERATION 2000-2200 RPM ABOVE
32” MANIFOLD PRESSURE.”**

On the aft baggage closeout:

**“MAXIMUM BAGGAGE 200 LBS. NO HEAVY OBJECTS ON
HAT SHELF.”**

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 3

EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.1	General	3-1
3.3	Emergency Procedures Check List	3-3
3.5	Amplified Emergency Procedures (General)	3-7
3.7	Engine Fire During Start	3-7
3.9	Engine Power Loss During Takeoff	3-7
3.11	Engine Power Loss In Flight	3-8
3.13	Power Off Landing	3-9
3.15	Fire In Flight	3-10
3.17	Loss of Oil Pressure	3-11
3.19	Loss of Fuel Pressure	3-11
3.21	Engine Driven Fuel Pump Failure	3-12
3.23	High Oil Temperature	3-12
3.25	Alternator Failure	3-13
3.27	Propeller Overspeed	3-13
3.29	Emergency Landing Gear Extension	3-13
3.31	Spin Recovery	3-14
3.33	Open Door	3-14
3.35	Engine Roughness	3-14
3.37	Emergency Descent	3-15

SECTION 3
EMERGENCY PROCEDURES

3.1 GENERAL

The recommended procedures for coping with various types of emergencies and critical situations are provided by this section. All of the required (FAA regulations) emergency procedures and those necessary for the safe operation of the airplane as determined by the operating and design features of the airplane are presented.

Emergency procedures associated with those optional systems and equipment which require handbook supplements are provided by Section 9 (Supplements).

The first portion of this section consists of an abbreviated emergency check list which supplies an action sequence for critical situations with little emphasis on the operation of systems.

The remainder of the section is devoted to amplified emergency procedures containing additional information to provide the pilot with a more complete understanding of the procedures.

These procedures are suggested as the best course of action for coping with the particular condition described, but are not a substitute for sound judgment and common sense. Since emergencies rarely happen in modern aircraft, their occurrence is usually unexpected and the best corrective action may not always be obvious. Pilots should familiarize themselves with the procedures given in this section and be prepared to take appropriate action should an emergency arise.

Most basic emergency procedures, such as power off landings, are a normal part of pilot training. Although these emergencies are discussed here, this information is not intended to replace such training, but only to provide a source of reference and review, and to provide information on procedures which are not the same for all aircraft. It is suggested that the pilot review standard emergency procedures periodically to remain proficient in them.

THIS PAGE INTENTIONALLY LEFT BLANK

3.3 EMERGENCY PROCEDURES CHECK LIST

ENGINE FIRE DURING START

Starter crank engine
 Mixture idle cut-off
 Throttle open
 Primer OFF
 Fuel selector OFF
 Abandon if fire continues.

ENGINE POWER LOSS DURING TAKEOFF

If sufficient runway remains for a normal landing, leave gear down and land straight ahead.

If area ahead is rough, or if it is necessary to clear obstructions:

Gear selector switch UP
 Emergency gear lever locked in **VERRIDE ENGAGED** position

If sufficient altitude has been gained to attempt a restart:

Maintain safe airspeed.
 Fuel selector switch to tank containing fuel
 Auxiliary fuel pump unlatch, HI
 Mixture check RICH
 Alternate air OPEN
 Emergency gear lever as required
 If power is not regained, proceed with power off landing.

ENGINE POWER LOSS IN FLIGHT

Fuel selector switch to tank containing fuel
 Auxiliary fuel pump unlatch, HI
 Mixture RICH
 Alternate air OPEN
 Engine gauges check for indication of cause of power loss
 If no fuel pressure is indicated, check tank selector position to be sure it is on a tank containing fuel.

When power is restored:

Alternate air CLOSED
 Auxiliary fuel pump OFF
 If power is not restored prepare for power off landing.
 Trim for 97 KIAS.

POWER OFF LANDING

Trim for 97 KIAS.
 Locate suitable field.
 Establish spiral pattern.
 1000 ft. above field at downwind position for normal landing approach.
 When field can easily be reached slow to 75 KIAS for shortest landing.

GEAR DOWN EMERGENCY LANDING

Touchdowns should normally be made at lowest possible airspeed with full flaps.

When committed to landing:

Throttle close
 Mixture idle cut-off
 Ignition OFF
 Master switch OFF
 Fuel selector OFF
 Seat belt and harness tight

GEAR UP EMERGENCY LANDING

In the event a gear up landing is required, proceed as follows:

Lock emergency gear lever in "Override Engaged" position before airspeed drops to 106 KIAS to prevent landing gear from inadvertently free falling.
 Flaps as desired
 Throttle close
 Mixture idle cut-off
 Ignition switches OFF
 Master switch OFF
 Fuel selector OFF
 Seat belt and harness tight
 Contact surface at minimum possible airspeed.

FIRE IN FLIGHT

Source of fire check

Electrical fire (smoke in cabin):

Master switch OFF

Vents open

Cabin heat OFF

Land as soon as practicable.

Engine fire:

Fuel selector OFF

Throttle CLOSED

Mixture idle cut-off

Auxiliary fuel pump check OFF

Heater and defroster OFF

Proceed with power off landing procedure.

LOSS OF OIL PRESSURE

Land as soon as possible and investigate cause.

Prepare for power off landing.

LOSS OF FUEL PRESSURE

Auxiliary fuel pump unlatch, HI

Fuel selector check on full tank

ENGINE DRIVEN FUEL PUMP FAILURE

Throttle retard

Auxiliary fuel pump unlatch,

HI

Throttle reset (75%

power or below)

CAUTIONS

If normal engine operation and fuel flow is not immediately re-established, the auxiliary fuel pump should be turned off. The lack of a fuel flow indication while in the HI auxiliary fuel pump position could indicate a leak in the fuel system, or fuel exhaustion.

DO NOT actuate the auxiliary fuel pump unless vapor suppression is required (LO position) or the engine driven fuel pump fails (HI position). The auxiliary pump has no standby function. Actuation of the HI switch position when the engine is operating normally, may cause engine roughness and/or power loss.

HIGH OIL TEMPERATURE

Land at nearest airport and investigate the problem. Prepare for power off landing.

ALTERNATOR FAILURE

Verify failure.

Reduce electrical load as much as possible.

Alternator circuit breakers check

Alt switch OFF (for 1 second),
then on

If no output:

Alt switch OFF

Reduce electrical load and land as soon as practical.

If battery is fully discharged, the gear will have to be lowered using the emergency gear extension procedure. Position lights will not illuminate.

PROPELLER OVERSPEED

Throttle retard

Oil pressure check

Prop control full DECREASE rpm,

then set if any

control available

Airspeed reduce

Throttle as required to remain
below 2575 rpm

EMERGENCY LANDING GEAR EXTENSION

Prior to emergency extension procedure:

Master switch check ON
Circuit breakers check
Panel lights OFF (in daytime)
Gear indicator bulbs check

If landing gear does not check down and lock:

Airspeed reduce below 88 KIAS
Landing gear selector switch gear DOWN
position

If gear has failed to lock down, raise emergency gear lever to "Override Engaged" position.

If gear has still failed to lock down, move emergency lever to "Emergency Down" position.

If gear has still failed to lock down, yaw the airplane abruptly from side to side with the rudder.

If the nose gear will not lock down using the above procedure, slow the aircraft to the lowest safe speed attainable using the lowest power setting required for safe operation and accomplish the following:

Emergency gear lever . "Override Engage" position
Landing gear selector switch gear DOWN
position

If landing gear does not check down, recycle gear through up position, and then select gear DOWN.

SPIN RECOVERY

Rudder full opposite to
direction of rotation
Control wheel full forward while
neutralizing ailerons
Throttle idle
Rudder neutral (when rotation stops)
Control wheel as required to smoothly
regain level flight attitude

OPEN DOOR

If both upper and side latches are open, the door will trail slightly open and airspeeds will be reduced slightly.

To close the door in flight:

Slow airplane to 87 KIAS.

Cabin vents close
Storm window open

If upper latch is open latch

If side latch is open pull on armrest while
moving latch handle to
latched position

If both latches are open latch side latch
then top latch

EMERGENCY DESCENT

A malfunction of the oxygen system requires an immediate descent to an altitude at or below 12,500 feet.

NOTE

Time of useful consciousness at 20,000 ft. is approximately 10 minutes. In the event an emergency descent becomes necessary, CLOSE the throttle and move the propeller control full FORWARD. Adjust the mixture control as necessary to attain smooth operation. Extend the landing gear and flaps at 103 KIAS and maintain this airspeed.

THIS PAGE INTENTIONALLY LEFT BLANK

3.5 AMPLIFIED EMERGENCY PROCEDURES (GENERAL)

The following paragraphs are presented to supply additional information for the purpose of providing the pilot with a more complete understanding of the recommended course of action and probable cause of an emergency situation.

3.7 ENGINE FIRE DURING START

Engine fires during start are usually the result of overpriming. The first attempt to extinguish the fire is to try to start the engine and draw the excess fuel back into the induction system.

If a fire is present before the engine has started, move the mixture control to idle cut-off, open the throttle and crank the engine. This is an attempt to draw the fire back into the engine.

If the engine has started, continue operating to try to pull the fire into the engine.

In either case (above), if fire continues more than a few seconds, the fire should be extinguished by the best available external means.

The fuel selector valves should be "OFF" and the mixture at idle cut-off if an external fire extinguishing method is to be used.

3.9 ENGINE POWER LOSS DURING TAKEOFF

The proper action to be taken if loss of power occurs during takeoff will depend on the circumstances of the particular situation.

If sufficient runway remains to complete a normal landing, leave the landing gear down and land straight ahead.

If the area ahead is rough, or if it is necessary to clear obstructions, move the gear selector switch to the "UP" position and lock the emergency gear lever in the "OVERRIDE ENGAGED" position.

If sufficient altitude has been gained to attempt a restart, maintain a safe airspeed and switch the fuel selector to another tank containing fuel. Place the auxiliary fuel pump to "HI." Check that the mixture is "RICH." The alternate air should be "OPEN." Use the emergency gear lever as required.

The landing gear will extend automatically when engine power fails at speeds below approximately 103 KIAS. The glide distance with the landing gear extended is roughly halved. If the situation dictates, the landing gear can be retained in the retracted position by locking the lever in the "OVERRIDE ENGAGED" position.

If engine failure was caused by fuel exhaustion, power will not be regained after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and Paragraph 3.13).

*The "HI" position on the auxiliary fuel pump switch is guarded and must be unlatched before it can be activated.

3.11 ENGINE POWER LOSS IN FLIGHT

Complete engine power loss is usually caused by fuel flow interruption and power will be restored shortly after fuel flow is restored. If power loss occurs at a low altitude, the first step is to prepare for an emergency landing (refer to Paragraph 3.13). An airspeed of at least 97 KIAS should be maintained.

If altitude permits, switch the fuel selector to another tank containing fuel and turn the auxiliary fuel pump to "HI." Move the mixture control to "RICH" and the alternate air to "OPEN." Check the engine gauges for an indication of the cause of the power loss. If no fuel pressure is indicated, check the tank selector position to be sure it is on a tank containing fuel.

When power is restored move the alternate air to the "CLOSED" position and turn "OFF" the auxiliary fuel pump.

If the preceding steps do not restore power, prepare for an emergency landing.

If time permits, turn the ignition switch to "L" then to "R" then back to "BOTH." Move the throttle and mixture control levers to different settings. This may restore power if the problem is too rich or too lean a mixture or if there is a partial fuel system restriction. Try other fuel tanks. Water in the fuel could take some time to be used up, and allowing the engine to windmill may restore power. If power is due to water, fuel pressure indications will be normal.

If engine failure was caused by fuel exhaustion power will not be restored after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and Paragraph 3.13).

*The "HI" position on the auxiliary fuel pump switch is guarded and must be unlatched before it can be activated.

3.13 POWER OFF LANDING

If loss of power occurs at altitude, trim the aircraft for best gliding angle (97 KIAS, Air Cond. off) and look for a suitable field. If measures taken to restore power are not effective, and if time permits, check your charts for airports in the immediate vicinity; it may be possible to land at one if you have sufficient altitude. At best gliding angle, with the engine windmilling, and the propeller control in full "DECREASE rpm," the aircraft will travel approximately 1.6 miles for each thousand feet of altitude. If possible, notify the FAA by radio of your difficulty and intentions. If another pilot or passenger is aboard, let him help.

When you have located a suitable field, establish a spiral pattern around this field. Try to be at 1000 feet above the field at the downwind position, to make a normal landing approach. When the field can easily be reached, slow to 75 KIAS with flaps down for the shortest landing. Excess altitude may be lost by widening your pattern, using flaps or slipping, or a combination of these.

Whether to attempt a landing with gear up or down depends on many factors. If the field chosen is obviously smooth and firm, and long enough to bring the plane to a stop, the gear should be down. If there are stumps or rocks or other large obstacles in the field, the gear in the down position will better protect the occupants of the aircraft. If, however, the field is suspected to be excessively soft or short, or when landing in water of any depth, a wheels-up landing will normally be safer and do less damage to the airplane.

Don't forget that at airspeeds below approximately 103 KIAS the gear will free fall, and will take six to eight seconds to be down and locked. If a gear up landing is desired, it will be necessary to lock the override lever in the "OVERRIDE ENGAGED" position before the airspeed drops to 106 KIAS to prevent the landing gear from inadvertently free falling.

Touchdown should normally be made at the lowest possible airspeed.

(a) Gear Down Emergency Landing

When committed to a gear down emergency landing, close the throttle control and shut "OFF" the master and ignition switches. Flaps may be used as desired. Turn the fuel selector valve to "OFF" and move the mixture to idle cut-off. The seat belts and shoulder harness (if installed) should be tightened. Touchdown should be normally made at the lowest possible airspeed.

Always remember that the automatic gear mechanism will extend the gear below approximately 103 KIAS with power off. Be prepared to lock the emergency gear lever in the "OVERRIDE ENGAGED" position before the airspeed drops to 106 KIAS to prevent the landing gear from inadvertently free falling, unless gear extension is desired.

NOTE

If the master switch is "OFF," the gear cannot be retracted.

(b) Gear Up Emergency Landing

In the event a gear up landing is required lock the emergency gear lever in "Override Engaged" position before the airspeed drops to 106 KIAS to prevent the landing gear from inadvertently free falling. Wing flaps should be extended as desired.

When committed to a gear up landing, CLOSE the throttle and shut "OFF" the master and ignition switches. Turn "OFF" the fuel selector valve.

Touchdowns should normally be made at the lowest possible airspeed with full flaps.

3.15 FIRE IN FLIGHT

The presence of fire is noted through smoke, smell and heat in the cabin. It is essential that the source of the fire be promptly identified through instrument readings, character of the smoke, or other indications since the action to be taken differs somewhat in each case.

Check for the source of the fire first.

If an electrical fire is indicated (smoke in the cabin), the master switch should be turned "OFF." The cabin vents should be opened and the cabin heat turned "OFF." A landing should be made as soon as possible.

If an engine fire is present, switch the fuel selector to "OFF" and close the throttle. The mixture should be at idle cut-off. Turn the auxiliary fuel pump "OFF." In all cases, the heater and defroster should be "OFF." If radio communication is not required select master switch "OFF." If the terrain permits, a landing should be made immediately.

NOTE

The possibility of an engine fire in flight is extremely remote. The procedure given is general and pilot judgment should be the determining factor for action in such an emergency.

3.17 LOSS OF OIL PRESSURE

Loss of oil pressure may be either partial or complete. A partial loss of oil pressure usually indicates a malfunction in the oil pressure regulating system, and a landing should be made as soon as possible to investigate the cause and prevent engine damage.

A complete loss of oil pressure indication may signify oil exhaustion or may be the result of a faulty gauge. In either case, proceed toward the nearest airport, and be prepared for a forced landing. If the problem is not a pressure gauge malfunction, the engine may stop suddenly. Maintain altitude until such time as a dead stick landing can be accomplished. Don't change power settings unnecessarily, as this may hasten complete power loss.

Depending on the circumstances, it may be advisable to make an off airport landing while power is still available, particularly if other indications of actual oil pressure loss, such as sudden increases in temperatures, or oil smoke, are apparent, and an airport is not close.

If engine stoppage occurs, proceed with Power Off Landing.

3.19 LOSS OF FUEL PRESSURE

The most probable cause of loss of fuel pressure is either fuel depletion in the fuel tank selected, or failure of the engine driven fuel pump. If loss of fuel pressure occurs, check that the fuel selector is on a tank containing fuel; place auxiliary fuel pump on "HI" until fuel pressure recovers, then turn OFF.

If loss of fuel pressure is due to failure of the engine driven fuel pump, the auxiliary fuel pump system can supply sufficient fuel pressure for engine power up to approximately 75%. Any combination of RPM and Manifold Pressure defined in the Power Setting Table may be used, but leaning may be required for smooth operation at altitudes above 15,000 feet, or for RPM below 2300. Normal cruise, descent and approach procedures should be used.

If failure of the engine driven fuel pump is suspected, retard throttle and unlatch the auxiliary fuel pump and place in "HI" position. The throttle can then be reset at 75% power or below.

CAUTION

If normal engine operation and fuel flow is not immediately re-established, the auxiliary fuel pump should be turned off. The lack of a fuel flow indication while on the HI auxiliary fuel pump position could indicate a leak in the fuel system, or fuel exhaustion.

DO NOT actuate the auxiliary fuel pump unless vapor suppression is required (LO position) or the engine driven fuel pump fails (HI position). The auxiliary pump has no standby function. Actuation of the HI switch position when the engine is operating normally may cause engine roughness and/or power loss.

3.21 ENGINE DRIVEN FUEL PUMP FAILURE

If an engine driven fuel pump failure is indicated, immediately retard the throttle. The auxiliary fuel pump switch should be unlatched and the HI position selected. The throttle should then be reset at 75% power or below.

CAUTIONS

If normal engine operation and fuel flow is not immediately re-established, the auxiliary fuel pump should be turned off. The lack of a fuel flow indication while on the HI auxiliary fuel pump position could indicate a leak in the fuel system, or fuel exhaustion.

DO NOT actuate the auxiliary fuel pump unless vapor suppression is required (LO position) or the engine driven fuel pump fails (HI position). The auxiliary pump has no standby function. Actuation of the HI switch position when the engine is operating, normally may cause engine roughness and/or power loss.

3.23 HIGH OIL TEMPERATURE

An abnormally high oil temperature indication may be caused by a low oil level, an obstruction in the oil cooler, damaged or improper baffle seals, a defective gauge, or other causes. Land as soon as practical at an appropriate airport and have the cause investigated.

A steady, rapid rise in oil temperature is a sign of trouble. Land at the nearest airport and let a mechanic investigate the problem. Watch the oil pressure gauge for an accompanying loss of pressure.

3.25 ALTERNATOR FAILURE

Loss of alternator output is detected through zero reading on the ammeter. Before executing the following procedure, insure that the reading is zero and not merely low by actuating an electrically powered device, such as the landing light. If no increase in the ammeter reading is noted, alternator failure can be assumed.

The electrical load should be reduced as much as possible. Check the alternator circuit breakers for a popped circuit.

The next step is to attempt to reset the overvoltage relay. This is accomplished by moving the "ALT" switch to "OFF" for one second and then to "ON." If the trouble was caused by a momentary overvoltage condition (16.5 volts and up) this procedure should return the ammeter to a normal reading.

If the ammeter continues to indicate "O" output, or if the alternator will not remain reset, turn off the "ALT" switch, maintain minimum electrical load and land as soon as practical. All electrical load is being supplied by the battery.

3.27 PROPELLER OVERSPEED

Propeller overspeed is caused by a malfunction in the propeller governor or low oil pressure which allows the propeller blades to rotate to full low pitch.

If propeller overspeed should occur, retard the throttle and check the oil pressure. The propeller control should be moved to full "DECREASE rpm" and then set if any control is available. Airspeed should be reduced and throttle used to maintain 2575 RPM.

3.29 EMERGENCY LANDING GEAR EXTENSION

Prior to initiating the emergency extension procedure check to insure that the master switch is "ON" and that the circuit breakers have not opened. If it is daytime the panel lights should be turned OFF. Check the landing gear indicators for faulty bulbs.

If the landing gear does not check down and locked, reduce the airspeed below 88 KIAS. Move the landing gear selector switch to the "DOWN" position. If the gear has failed to lock down, raise the emergency gear lever to the "OVERRIDE ENGAGED" position.

If the gear has still failed to lock down, move the emergency gear lever to the "EMERGENCY DOWN" position.

If the gear has still failed to lock down, yaw the airplane abruptly from side to side with the rudder.

If the nose gear will not lock down using the above procedure, slow the airplane to the lowest safe speed attainable using the lowest power setting required for safe operation and raise the emergency gear lever to the "OVERRIDE ENGAGED" position. Move the landing gear selector switch to the gear "DOWN" position. If the landing gear does not check down, recycle the gear through the "UP" position and then select the "DOWN" position.

3.31 SPIN RECOVERY

Intentional spins are prohibited in this airplane. If a spin is inadvertently entered, immediately apply full rudder opposite to the direction of rotation. Move the control wheel full forward while neutralizing the ailerons. Move the throttle to "IDLE." When the rotation stops, neutralize the rudder and ease back on the control wheel as required to smoothly regain a level flight attitude.

3.33 OPEN DOOR

The cabin door on the Cherokee is double latched, so the chances of its springing open in flight at both the top and bottom are remote. However, should you forget the upper latch, or not fully engage the side latch, the door may spring partially open. This will usually happen at takeoff or soon afterward. A partially open door will not affect normal flight characteristics, and a normal landing can be made with the door open.

If both upper and side latches are open, the door will trail slightly open, and airspeed will be reduced slightly.

To close the door in flight, slow the airplane to 87 KIAS, close the cabin vents and open the storm window. If the top latch is open, latch it. If the side latch is open, pull on the arm rest while moving the latch handle to the latched position. If both latches are open, close the side latch then the top latch.

3.35 ENGINE ROUGHNESS

Engine roughness may be caused by dirt in the injector nozzles, induction system icing, or ignition problems.

First adjust the mixture for maximum smoothness. The engine will run rough if the mixture is too rich or too lean.

Move the alternate air to "OPEN."

Switch the fuel selector to another tank to see if fuel contamination is the problem.

Check the engine gauges for abnormal readings. If any gauge readings are abnormal proceed accordingly.

The magneto switch should then be moved to "L" then "R," then back to "BOTH." If operation is satisfactory on either magneto, proceed on that magneto at reduced power with full "RICH" mixture to a landing at the first available airport.

If roughness persists, prepare for a precautionary landing at pilot's discretion.

3.37 EMERGENCY DESCENT

A malfunction of the oxygen system requires an immediate descent to an altitude at or below 12,500 feet.

NOTE

Time of useful consciousness at 20,000 ft. is approximately 10 minutes. In the event an emergency descent becomes necessary, CLOSE the throttle and move the propeller control full FORWARD. Adjust the mixture control as necessary to attain smooth operation. Extend the landing gear and flaps at 103 KIAS and maintain this airspeed.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 4

NORMAL PROCEDURES

Paragraph No.		Page No.
4.1	General	4-1
4.3	Airspeeds for Safe Operations	4-1
4.5	Normal Procedures Check List	4-3
4.7	Amplified Normal Procedures (General)	4-9
4.9	Preflight Check	4-9
4.11	Before Starting Engine	4-10
4.13	Starting Engine (Standard Engine Primer)	4-11
4.15	Starting Engine (Optional Engine Primer)	4-11
4.17	Starting Engine When Flooded	4-12
4.19	Starting Engine in Cold Weather (Standard Engine Primer)	4-12
4.21	Starting with External Power Source	4-13
4.23	Warm-Up	4-14
4.25	Taxiing	4-14
4.27	Ground Check	4-14
4.29	Before Takeoff	4-15
4.31	Takeoff	4-16
4.33	Climb	4-16
4.35	Cruising	4-17
4.37	Approach and Landing	4-17
4.39	Stopping Engine	4-18
4.41	Parking	4-18
4.43	Stalls	4-19
4.45	Turbulent Air Operation	4-19
4.47	Landing Gear	4-19
4.49	Weight and Balance	4-20

SECTION 4
NORMAL PROCEDURES

4.1 GENERAL

This section clearly describes the recommended procedures for the conduct of normal operations for the Cherokee Turbo Arrow III. All of the required (FAA regulations) procedures and those necessary for the safe operation of the airplane as determined by the operating and design features of the airplane are presented.

Normal procedures associated with those optional systems and equipment which require handbook supplements are provided by Section 9 (Supplements).

These procedures are provided to present a source of reference and review and to supply information on procedures which are not the same for all aircraft. Pilots should familiarize themselves with the procedures given in this section in order to become proficient in the normal operations of the airplane.

The first portion of this section consists of a short form check list which supplies an action sequence for normal operations with little emphasis on the operation of the systems.

The remainder of the section is devoted to amplified normal procedures which provide detailed information and explanations of the procedures and how to perform them. This portion of the section is not intended for use as an in-flight reference due to the lengthy explanations. The short form check list should be used for this purpose.


4.3 AIRSPEEDS FOR SAFE OPERATIONS

The following airspeeds are those which are significant to the safe operation of the airplane. These figures are for standard airplanes flown at gross weight under standard conditions at sea level.

Performance for a specific airplane may vary from published figures depending upon the equipment installed, the condition of the engine, airplane and equipment, atmospheric conditions and piloting technique.

(a) Best Rate of Climb Speed	
gear up, flaps up	96 KIAS
gear down, flaps up	78 KIAS
(b) Best Angle of Climb Speed	
gear up, flaps up	78 KIAS
gear down, flaps up	71 KIAS
(c) Turbulent Air Operating Speed (See Subsection 2.3)	119 KIAS
(d) Maximum Flap Speed	103 KIAS
(e) Landing Final Approach Speed (Flaps 40°)	75 KIAS
(f) Maximum Demonstrated Crosswind Velocity	17 KTS

THIS PAGE INTENTIONALLY LEFT BLANK



WALK-AROUND

Figure 4-1

4.5 NORMAL PROCEDURES CHECK LIST

PREFLIGHT CHECK

- Control wheelrelease belts
- Master switchON
- Fuel quantity gaugescheck
- Master switchOFF
- IgnitionOFF
- Exteriorcheck for damage
- Control surfacescheck for interference -
free of ice, snow, frost
- Hingescheck for interference
- Wingsfree of ice, snow, frost
- Stall warningcheck
- Navigation lightscheck
- Fuel tankscheck supply
visually - secure caps
- Fuel tank sumpsdrain
- Fuel ventsopen
- Main gear strutsproper
inflation (2.5 ± .25 in.)
- Tirescheck
- Brake blockscheck
- Fuselage static ventsclear

- Pitot headremove cover -
holes clear
- Windshieldclean
- Propeller and spinnercheck
- Engine baffle sealscheck
- Fuel and oilcheck for leaks
- Oilcheck level
- Dipstickproperly seated
- Cowlingsecure
- Inspection coverssecure
- Nose wheel tirecheck
- Nose gear strutproper
inflation (2.75 ± .25 in.)
- Air inletsclear
- Alternator beltcheck tension
- Tow bar and control locksstow
- Baggagestowed properly -
secure
- Baggage doorclose and secure
- Fuel strainerdrain
- Primary flight controlsproper operation
- Cabin doorsclose and secure
- Required paperson board
- Seat belts and harnessfastened - check
inertia reel

**SECTION 4
NORMAL PROCEDURES**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

BEFORE STARTING ENGINE

Brakes set.
 Propeller full INCREASE rpm
 Fuel selector desired tank
 Alternate air OFF

STARTING ENGINE (AIRPLANE EQUIPPED WITH STANDARD ENGINE PRIMER SYSTEM)

Fuel selector ON
 Mixture RICH
 Throttle half travel
 Propeller FORWARD
 Master switch ON
 Propeller clear
 Starter engage
 Primer button ON as required
 Throttle retard when engine starts
 Oil pressure check
 Alternator check
 Gyro vacuum check

STARTING ENGINE (AIRPLANE EQUIPPED WITH OPTIONAL ENGINE PRIMER SYSTEM)

Fuel selector ON
 Mixture full RICH
 Throttle full FORWARD
 Prop control full FORWARD
 Master switch ON
 Auxiliary fuel pump OFF
 Primer ON
 See Figure 4-3
 for Priming Time
 Throttle CLOSE
 Starter engage immediately
 At temperatures below +20°F continue priming while cranking until engine starts.

When engine starts firing - open throttle very slowly to raise engine speed to 1000 RPM. As engine speed accelerates through 500 RPM, release starter.
 Primer release

Auxiliary fuel pump low only as necessary to obtain smooth engine operation (1-3 minutes will be required when temp. is below 20°F)
 Oil pressure check
 Alternator check
 Gyro vacuum check

STARTING ENGINE WHEN FLOODED

Mixture idle cut-off
 Throttle full FORWARD
 Propeller FORWARD
 Master switch ON
 Auxiliary fuel pump OFF
 Propeller clear
 Starter engage
 When engine fires:
 Throttle retard
 Mixture advance slowly

STARTING ENGINE IN COLD WEATHER (AIRPLANE EQUIPPED WITH STANDARD ENGINE PRIMER SYSTEM)

Fuel selector ON
 Mixture full RICH
 Throttle full FORWARD
 Prop control full FORWARD
 Master switch ON
 Electric fuel boost pump ON LOW boost
 Starter engage
 Primer ON for 3 sec.
 Throttle full FORWARD to full AFT
 Primer ON 3 sec., then OFF 3 sec., then ON 3 sec.

When engine fires:
 Starter leave engaged
 Primer button tap until rhythmic firing
 Starter release
 Throttle half travel
 Oil pressure check

If engine begins to falter:
 Primer button tap
 Throttle 1000 RPM
 Electric fuel boost pump OFF after start complete

STARTING WITH EXTERNAL POWER SOURCE

Master switch OFF
 All electrical equipment OFF
 Terminals connect
 External power plug insert in fuselage

Proceed with normal start.
 Throttle lowest possible RPM
 External power plug disconnect from fuselage
 Master switch ON - check ammeter
 Oil pressure check

WARM-UP

Throttle 900 to 1200 RPM

TAXIING

Chocks removed
 Taxi area clear
 Throttle apply slowly
 Prop high RPM
 Brakes check
 Steering check

GROUND CHECK

Propeller full INCREASE
 Throttle 1800 to 2000 RPM
 Magnetos max. drop 150 RPM -max. diff. 50 RPM
 Vacuum 4.8" Hg. to 5.1" Hg.
 Oil temperature check
 Oil pressure check
 Air conditioner check
 Annunciator panel press-to-test
 Propeller exercise - then full INCREASE

Alternate air check
 Engine is warm for takeoff when oil temperature is at least 100° F.
 Auxiliary fuel pump OFF
 Fuel pressure check
 Throttle retard
 Manifold pressure line drain

BEFORE TAKEOFF

Master switch ON
 Flight instruments check
 Fuel selector proper tank
 Auxiliary fuel pump OFF
 Engine gauges check
 Alternate air CLOSED
 Seat backs erect
 Mixture set
 Prop set
 Belts/harness fastened
 Empty seats seat belts snugly fastened
 Flaps set
 Trim tab set
 Controls free
 Doors latched
 Air conditioner OFF

TAKEOFF

NORMAL

Flaps set
 Tab set
 Accelerate to 70 to 77 KIAS.
 Control wheel back pressure to
 rotate to climb attitude

SHORT FIELD, OBSTACLE CLEARANCE

Flaps 25° (second notch)
 Accelerate to 53 to 64 KIAS depending on aircraft
 weight.
 Control wheel back pressure to
 rotate to climb attitude
 After breaking ground, accelerate to 59 to 68 KIAS
 depending on aircraft weight.
 Gear UP
 Accelerate to best flaps up angle of climb speed - 78
 KIAS, slowly retract the flaps and climb past the
 obstacle.
 Accelerate to best flaps up rate of climb speed - 96
 KIAS.

SOFT FIELD

Flaps 25° (second notch)
 Accelerate to 53 to 64 KIAS depending on aircraft
 weight.
 Control wheel back pressure to
 rotate to climb attitude
 After breaking ground, accelerate to 59 to 68 KIAS
 depending on aircraft weight.
 Gear UP
 Accelerate to best flaps up rate of climb speed 96
 KIAS.
 Flaps retract slowly

TAKEOFF CLIMB

Mixture full RICH
 Prop speed 2575 RPM
 Manifold pressure DO NOT EXCEED
 41 in. Hg.
 Climb speed
 Best angle 78 KIAS
 Best rate 96 KIAS

CRUISE CLIMB

Mixture full RICH
 Prop speed 2450 RPM
 Manifold pressure 33 in. Hg.
 Climb speed 104 KIAS

CRUISING

Reference performance charts, Teledyne
 Continental Operator's Manual and power setting
 table.
 Normal max power 75%
 Power set per power table
 Mixture adjust

APPROACH AND LANDING

Fuel selector proper tank
 Seat backs erect
 Belts/harness fasten
 Mixture set
 Propeller set
 Gear down - 129 KIAS max
 Flaps set - 103 KIAS max
 Air conditioner OFF
 Trim to 75 KIAS.

STOPPING ENGINE

Flaps retract
 Air conditioner OFF
 Radios OFF
 Propeller full INCREASE
 Throttle full aft
 Mixture idle cut-off
 Magnetos OFF
 Master switch OFF

PARKING

Parking brake set
 Control wheel secured with belts
 Flaps full up
 Wheel chocks in place
 Tie downs secure

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

4.7 AMPLIFIED NORMAL PROCEDURES (GENERAL)

The following paragraphs are provided to supply detailed information and explanations of the normal procedures necessary for the safe operation of the airplane.

4.9 PREFLIGHT CHECK

The airplane should be given a thorough preflight and walk-around check. The preflight should include a check of the airplane's operational status, computation of weight and C.G. limits, takeoff distance and in-flight performance. A weather briefing should be obtained for the intended flight path, and any other factors relating to a safe flight should be checked before takeoff.

CAUTION

The flap position should be noted before boarding the airplane. The flaps must be placed in the "UP" position before they will lock and support weight on the step.

Upon entering the cockpit, release the seat belts securing the control wheel. Turn "ON" the master switch and check the fuel quantity gauges for sufficient fuel. After the fuel quantity check is made turn the master switch "OFF" and check that the ignition switch is "OFF."

To begin the exterior walk-around, check for external damage and operational interference of the control surfaces or hinges. Insure that the wings and control surfaces are free of snow, ice, frost or any other foreign materials.

An operational check of the stall warning system and navigation lights should now be made. Turn the master switch "ON." Lift the detector while checking to determine if the horn is actuated and check that the navigation lights are illuminated. The master switch should be returned to the "OFF" position after the checks are complete.

A visual check of the fuel tank quantity should be performed. Remove the filler cap from each tank and visually check the supply and color. Be sure to secure the caps properly after the check is complete.

The fuel system tank sumps and strainer should be drained daily prior to the first flight and after refueling to avoid the accumulation of water or sediment. Each fuel tank is equipped with an individual quick drain located at the lower inboard rear corner of the tank. The fuel strainer is located on the lower left side of the fire wall, and the strainer drain is accessible through a hole in the lower cowl approximately 3 inches forward of the fire wall.

CAUTION

When draining any amount of fuel, care should be taken to insure that no fire hazard exists before starting engine.

Check all of the fuel tank vents to make sure they are open.

Next, complete a check of the landing gear. Check the main gear shock struts for proper inflation. There should be $2.5 \pm .25$ inches of strut exposure under a normal static load. The nose gear should be checked for $2.75 \pm .25$ inches of strut exposure. Check all tires for cuts and wear and insure proper inflation. Make a visual check of the brake blocks for wear or damage.

Remove the cover from the pitot head on the underside of the left wing. Check the pitot head to make sure the holes are open and clear of obstructions. Check static vent holes on both sides of aft fuselage to make sure the holes are open and clear of obstructions.

Don't forget to clean and check the windshield.

The propeller and spinner should be checked for defects or nicks.

Check the air inlets for foreign matter.

Looking through the nose cowl air inlets, visually check the cylinder baffle seals on the left and right side for proper installation. The seals should roll up against the inner surface of the upper cowl. They should NOT be rolled down below the baffles.

Check for any obvious fuel or oil leaks. Check the oil level (six to eight quarts). Make sure that the dipstick has properly seated after checking and secure the inspection door.

Stow the tow bar and check the baggage for proper storage and security. The baggage compartment doors should be closed and secure.

Upon entering the aircraft, ascertain that all primary flight controls operate properly. Close and secure the cabin door and check that all the required papers are in order and in the airplane.

Fasten the seat belts and shoulder harness and check the function of the inertia reel by pulling sharply on the strap. Fasten seat belts on empty seats.

4.11 BEFORE STARTING ENGINE

Before starting the engine the brakes should be set "ON" and the propeller lever moved to the full "INCREASE" rpm position. The fuel selector should then be moved to the desired tank.

4.13 STARTING ENGINE (AIRPLANE EQUIPPED WITH STANDARD ENGINE PRIMER SYSTEM)

The first step in starting is to move the fuel selector to the ON position. Advance the mixture control to full RICH, open the throttle half travel and move the propeller control full FORWARD. Turn the master switch and ignition switches ON. After ensuring that the propellers are clear, engage the starter. The primer button should be used (ON) as required. For cold weather starts, refer to Paragraph 4.19 - Starting Engines in Cold Weather. When the engine starts, retard the throttle and monitor the oil pressure gauge. If no oil pressure is indicated within 30 seconds, shut down the engine and have it checked. In cold weather it may take somewhat longer for an oil pressure indication. After the engine has started, check the alternator for sufficient output and the gyro pressure gauge for a reading between 4.8 and 5.1 in. Hg.

NOTE

To prevent starter damage, limit starter cranking to 30 second periods. If the engine does not start within that time, allow a cooling period of several minutes before engaging starter again. Do not engage the starter immediately after releasing it. This practice may damage the starter mechanism.

4.15 STARTING ENGINE (AIRPLANE EQUIPPED WITH OPTIONAL ENGINE PRIMER SYSTEM)


NOTE

Engine starts can be accomplished down to ambient temperatures of +20°F with engine equipped with standard (massive electrode) spark plugs. Below that temperature fine wire spark plugs are highly recommended to ensure engine starts, and are a necessity at +10°F and below. In addition, the use of external electrical power source is also recommended when ambient temperatures are below +20°F.

Upon entering the cockpit, begin starting procedure by moving the fuel selector to ON. Advance the mixture to full RICH and the throttle and prop controls to full FORWARD. Turn the master switch ON. The electric fuel boost pump should be OFF. Push primer switch and hold for the required priming time (see Figure 4-3). Close throttle and immediately engage starter. With ambient temperatures above +20°F, starts may be made by discontinuing priming before engaging starter. With ambient temperatures below +20°F, starts should be made by continuing to prime during cranking period. Do not release starter until engine accelerates through 500 RPM, then SLOWLY advance throttle to obtain 1000 RPM. Release primer and immediately place auxiliary fuel pump switch to LO. Auxiliary fuel pump operation will be required for one to three minutes initial engine warm-up.

NOTE

When cold weather engine starts are made without the use of engine preheating or other precautions (refer to TCM Operator's Manual), longer than normal elapsed time may be required before an oil pressure indication is observed.



OPTIONAL ENGINE PRIMER SYSTEM - PRIMING TIME VS. AMBIENT TEMPERATURE

Figure 4-3

4.17 STARTING ENGINE WHEN FLOODED

If an engine is flooded, move the mixture control to idle cut-off and advance the throttle and propeller controls full forward. Turn ON the master switch and ignition switches. The auxiliary fuel pump should be OFF. After ensuring that the propeller is clear, engage the starter. When the engine fires, retard the throttle and advance the mixture slowly.

4.19 STARTING ENGINE IN COLD WEATHER (AIRPLANE EQUIPPED WITH STANDARD ENGINE PRIMER SYSTEM)

NOTE

As cold weather engine operations are decidedly more demanding, it may become necessary to utilize the starting procedure listed below in low ambient temperatures. (See Continental Engine Operator's Manual for Cold Weather Operating Recommendations.)

NOTE

It may be necessary to apply an external power source to facilitate engine cranking if the aircraft's battery is deficient of charge.

Prior to attempting the start, turn the propellers through by hand three times. Upon entering the cockpit, begin the starting procedure by moving the fuel selector to ON. Advance the mixture to full RICH and the throttle and prop controls to full FORWARD. Turn ON the master switch and the ignition switch (mag). The electric fuel boost pump should be ON in the LOW boost position. Push the primer button and engage the starter simultaneously. Begin moving the throttle control back and forth from full forward to full aft. Release the primer button after about 3 seconds of cranking. Leave the primer button off for 3 seconds of cranking and then reapply primer for about 3 seconds, repeat until the engine begins to fire.

When the engine begins firing, leave the starter engaged and tap the primer periodically until a rhythmic firing pattern is observed and then release the starter switch and position the throttle at half travel. Tap the primer button if the engine begins to falter during this period and adjust the throttle to a 1000 RPM idle speed.

The electric fuel boost pump may be turned OFF as soon as it is determined that the engine will continue to run without it.

4.21 STARTING WITH EXTERNAL POWER SOURCE

An optional feature called the Piper External Power (PEP) allows the operator to use an external battery to crank the engine without having to gain access to the airplane's battery.

Turn the master switch OFF and turn all electrical equipment OFF. Connect the RED lead of the PEP kit jumper cable to the POSITIVE (+) terminal of an external 12-volt battery and the BLACK lead to the NEGATIVE (-) terminal. Insert the plug of the jumper cable into the socket located on the fuselage. Note that when the plug is inserted, the electrical system is ON. Proceed with the normal starting technique.

After the engine has started, reduce power to the lowest possible RPM, to reduce sparking, and disconnect the jumper cable from the aircraft. Turn the master switch ON and check the alternator ammeter for an indication of output. DO NOT ATTEMPT FLIGHT IF THERE IS NO INDICATION OF ALTERNATOR OUTPUT.

NOTE

For all normal operations using the PEP jumper cables, the master switch should be OFF, but it is possible to use the ship's battery in parallel by turning the master switch ON. This will give longer cranking capabilities, but will not increase the amperage.

CAUTION

Care should be exercised because if the ship's battery has been depleted, the external power supply can be reduced to the level of the ship's battery. This can be tested by turning the master switch ON momentarily while the starter is engaged. If cranking speed increases, the ship's battery is at a higher level than the external power supply.

4.23 WARM-UP

Warm-up the engine at 900 to 1200 RPM. Avoid prolonged idling at low RPM, as this practice may result in fouled spark plugs.

Takeoff may be made as soon as the ground check is completed, provided that the oil temperature is at least 100°F and throttle may be opened to 41 inches manifold pressure without backfiring or skipping, and without a reduction in engine oil pressure.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

4.25 TAXIING

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Ascertain that the propeller back blast and taxi areas are clear.

Power should be applied slowly to start the taxi roll. Taxi a few feet forward and apply the brakes to determine their effectiveness. Taxi with the propeller set in low pitch, high RPM setting. While taxiing, make slight turns to ascertain the effectiveness of the steering.

Observe wing clearances when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.

Avoid holes and ruts when taxiing over uneven ground.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

4.27 GROUND CHECK

The magnetos should be checked at 1800 to 2000 RPM with the propeller set at high RPM. Drop off on either magneto should not exceed 150 RPM and the difference between the magnetos should not exceed 50 RPM. Operation on one magneto should not exceed 10 seconds.

Check the vacuum gauge; the indicator should read between 4.8 and 5.1 inches Hg at 2000 RPM.

Check the annunciator panel lights with the press-to-test button. Also check the air conditioner and the alternate air.

The propeller control should be moved through its complete range to check for proper operation, and then placed in full "INCREASE" rpm for takeoff. To obtain maximum rpm, push the pedestal mounted control fully forward on the instrument panel. Do not allow a drop of more than 200 RPM to 300 RPM during this check. In cold weather the propeller control should be cycled from high to low RPM at least three times before takeoff to make sure that warm engine oil has circulated.

Drain the manifold pressure line by running the engine at 1000 RPM and depressing the drain valve located behind and below the manifold pressure gauge for 5 seconds. Do not depress the valve when the manifold pressure exceeds 25 inches Hg.

4.29 BEFORE TAKEOFF

All aspects of each particular takeoff should be considered prior to executing the takeoff procedure.

After takeoff, if the gear selector switch is placed in the gear up position before reaching the airspeed at which the back up gear extender system no longer commands gear down*, the gear will not retract. For obstacle clearance on takeoff and for takeoffs from high altitude airports, the landing gear can be retracted after lift-off at the pilot's discretion by placing the gear selector switch in the "UP" position and then locking the emergency gear lever in the "OVERRIDE ENGAGED" position. If desired, the "OVERRIDE ENGAGED" position can be selected and locked before takeoff, and the gear will then retract as soon as the gear selector switch is placed in the "UP" position. Care should always be taken not to retract the gear prematurely, or the aircraft could settle back onto the runway. If the override lock is used for takeoff, it should be disengaged as soon as sufficient airspeed and terrain clearance are obtained, to return the gear system to normal operation.

For normal operation, the pilot should extend and retract the gear with the gear selector switch located on the instrument panel, just as he would if the back-up gear extender system were not installed.

After all aspects of the takeoff are considered, a pretakeoff check procedure must be performed.

Turn "ON" the master switch and check and set all of the flight instruments as required. Check the fuel selector to make sure it is on the proper tank (fullest). Check the engine gauges. The alternate air should be in the "CLOSED" position.

All seat backs should be erect.

The mixture and propeller control levers should be set and the seat belts and shoulder harness fastened. Fasten the seat belts snugly around the empty seats.

Exercise and set the flaps and trim tab. Insure proper flight control movement and response.

All doors should be properly secured and latched.

On air conditioned models, the air conditioner must be "OFF" to insure normal takeoff performance.

*Approximately 78 KIAS at sea level to approximately 97 KIAS at 20,000 ft. with a straight line variation between.

4.31 TAKEOFF

The normal takeoff technique is conventional for the Cherokee Turbo Arrow III. The tab should be set slightly aft of neutral, with the exact setting determined by the loading of the airplane. Allow the airplane to accelerate to 70 to 77 KIAS depending on the weight of the aircraft and ease back on the control wheel to rotate to climb attitude.

The procedure used for a short field takeoff with an obstacle clearance or a soft field takeoff differs slightly from the normal technique. The flaps should be lowered to 25° (second notch). Allow the aircraft to accelerate to 53 to 64 KIAS depending on the aircraft weight and rotate the aircraft to climb attitude. After breaking ground, accelerate to 59 to 68 KIAS, depending on aircraft weight and select gear up*. Continue to climb while accelerating to the flaps-up rate of climb speed, 96 KIAS if no obstacle is present or 78 KIAS if obstacle clearance is a consideration. Slowly retract the flaps while climbing out.

4.33 CLIMB

On climb-out after takeoff, it is recommended that the best angle of climb speed (78 KIAS) be maintained only if obstacle clearance is a consideration. The best rate of climb speed (96 KIAS) should be maintained with full power on the engines until adequate terrain clearance is obtained. At this point, engine power should be reduced to 33 inches manifold pressure and 2450 RPM (approximately 75% power) for cruise climb. A cruise climb speed of 104 KIAS or higher is also recommended. This combination of reduced power and increased climb speed provides better engine cooling, less engine wear, reduced fuel consumption, lower cabin noise level, and better forward visibility.

When reducing power the throttle should be retarded first, followed by the propeller control. The mixture control should remain at full rich during the climb. Cylinder head temperatures should be monitored during climb and should be kept below 460° at all times. During climbs under hot weather conditions, it may be necessary to use LO auxiliary fuel pump for vapor suppression.

Consistent operational use of cruise climb power settings is strongly recommended since this practice will make a substantial contribution to fuel economy and increased engine life, and will reduce the incidence of premature engine overhauls.

*If desired, the override up position can be selected and locked before takeoff, and the gear will then retract as soon as the gear selector switch is placed in the up position. In this case care should be taken not to retract the gear prematurely, or the aircraft could settle back onto the runway. If the override lock is used for takeoff, it should be disengaged as soon as sufficient terrain clearance is obtained, to return the gear system to normal operation.

4.35 CRUISING

When leveling off at cruise altitude, the pilot may reduce to a cruise power setting in accordance with the Power Setting Table in this Manual. The mixture should be leaned in accordance with the recommendations for the TSIO-360-F engine in the Teledyne Continental Operator's Manual which is provided with the aircraft.

For maximum service life, cylinder head temperature should be maintained below 400°F during high performance cruise operation and below 350°F during economy cruise operation. If cylinder head temperatures become too high during flight, reduce them by enriching the mixture, by reducing power, or by use of any combination of these methods.

Following level-off for cruise, the airplane should be trimmed.

The pilot should monitor weather conditions while flying and should be alert to conditions which might lead to icing. If induction system icing is expected, place the alternate air control in the "ON" position.

During flight, keep account of time and fuel used in connection with power settings to determine how the fuel flow and fuel quantity gauging systems are operating. If the fuel flow indication is considerably higher than the fuel actually being consumed, a fuel nozzle may be clogged and require cleaning.

There are no mechanical uplocks in the landing gear system. In the event of a hydraulic system malfunction, the landing gear will free-fall to the gear down position. The true airspeed with gear down is approximately 75% of the gear retracted airspeed for any given power setting. Allowances for the reduction in airspeed and range should be made when planning extended flight between remote airfields or flight over water.

In order to keep the airplane in best lateral trim during cruise flight, the fuel should be used alternately from each tank at one hour intervals.

4.37 APPROACH AND LANDING

Check to insure the fuel selector is on the proper (fullest) tank and that the seat backs are erect. The seat belts and shoulder harness should be fastened and the inertia reel checked.

Turn "OFF" the air conditioner. The mixture should be set in the full "RICH" position. Set the propeller at full "INCREASE" rpm to facilitate ample power for an emergency go-around.

The landing gear may be extended at speeds below 129 KIAS. The airplane should be trimmed to a final approach speed of about 75 KIAS with flaps extended. The flaps can be lowered at speeds up to 103 KIAS, if desired.

The mixture control should be kept in full "RICH" position to insure maximum acceleration if it should be necessary to open the throttle again.

The amount of flap used during landings and the speed of the aircraft at contact with the runway should be varied according to the landing surface and conditions of wind and airplane loading. It is generally good practice to contact the ground at the minimum possible safe speed consistent with existing conditions.

Normally, the best technique for short and slow landings is to use full flap and enough power to maintain the desired airspeed and approach flight path. Mixture should be full "RICH," fuel on the fullest tank. Reduce the speed during the flareout and contact the ground close to the stalling speed. After ground contact hold the nose wheel off as long as possible. As the airplane slows down, gently lower the nose and apply the brakes. Braking is most effective when flaps are raised and back pressure is applied to the control wheel, putting most of the aircraft weight on the main wheels. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds with partial or no flaps.

4.39 STOPPING ENGINE

At the pilot's discretion, the flaps should be raised.

NOTE

The flaps must be placed in the "UP" position for the flap step to support weight. Passengers should be cautioned accordingly.

The air conditioner and radios should be turned "OFF," the propeller set in the full "INCREASE" position, and the engine stopped by disengaging the mixture control lock and pulling the mixture control back to idle cut-off. The throttle should be left full aft to avoid engine vibration while stopping. Then the magneto and master switches must be turned "OFF."

4.41 PARKING

If necessary, the airplane should be moved on the ground with the aid of the nose wheel tow bar provided with each airplane and secured behind the rear seats. The aileron and stabilator controls should be secured by looping the safety belt through the control wheel and pulling it snug. The flaps are locked when in the "UP" position and should be left retracted.

Tie downs can be secured to rings provided under each wing and to the tail skid. The rudder is held in position by its connections to the nose wheel steering and normally does not have to be secured.

4.43 STALLS

The stall characteristics of the Cherokee Turbo Arrow III are conventional. An approaching stall is indicated by a stall warning horn which is activated between five and ten knots above stall speed. Mild airframe buffeting and gentle pitching may also precede the stall.

The gross weight stalling speed of the Cherokee Turbo Arrow III with power off and full flaps is 56 KIAS. With the flaps up this speed is increased 7 KTS. Loss of altitude during stalls can be as great as 500 feet, depending on configuration and power.

NOTE

The stall warning system is inoperative with the master switch "OFF."

During preflight, the stall warning system should be checked by turning the master switch "ON," lifting the detector and checking to determine if the horn is actuated. The master switch should be returned to the "OFF" position after the check is complete.

4.45 TURBULENT AIR OPERATION

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups which may occur as a result of the turbulence or of distractions caused by the conditions.

4.47 LANDING GEAR

This airplane is equipped with an airspeed - power sensing system (back-up gear extender) which extends the landing gear under low airspeed - power conditions* even though the pilot may not have selected gear down. This system will also prevent retraction of the landing gear by normal means when the airspeed - power values are below a predetermined minimum. To override this system or to hold the emergency gear lever in the "OVERRIDE ENGAGED" position without maintaining manual pressure on the emergency gear lever, pull the lever full up and push the lock pin in. To release the override, pull lever up and then release.

For normal operation, the pilot should extend and retract the gear with the gear selector switch located on the instrument panel, just as he would if the back-up gear extender system were not installed.

The pilot should become familiar with the function and significance of the landing gear position indicators and warning lights.

The red gear warning light on the instrument panel and the horn operate simultaneously in flight when the throttle is reduced to where the manifold pressure is approximately 14 inches of mercury or below, and the gear selector switch is not in the "DOWN" position. This warning will also occur during flight when the back-up gear extended system has lowered the landing gear and the gear selector switch is not in the "DOWN" position and the manifold pressure is reduced below approximately 14 inches of mercury.

The red gear warning light on the instrument panel and the horn will also operate simultaneously on the ground when the master switch is "ON" and the gear selector switch is in the "UP" position and the throttle is in the retarded position.

The three green lights on the instrument panel operate individually as each associated gear is locked in the extended position.

WARNING

Panel lights' dimmer switch must be off to obtain gear and overboost lights full intensity during daytime flying. When aircraft is operated at night and panel lights' dimmer switch is turned on, gear lights and overboost light will automatically dim.

The yellow "Auto Ext. OFF" light immediately below the gear selector switch flashes whenever the emergency gear lever is in the "OVERRIDE ENGAGED" position.

4.49 WEIGHT AND BALANCE

It is the responsibility of the owner and pilot to determine that the airplane remains within the allowable weight vs. center of gravity envelope while in flight.

For weight and balance data, refer to Section 6 (Weight and Balance).

*Approximately 103 KIAS at any altitude, power off.

TABLE OF CONTENTS

SECTION 5

PERFORMANCE

Paragraph No.		Page No.
5.1	General	5-1
5.3	Introduction to Performance and Flight Planning	5-1
5.5	Flight Planning Example	5-3
5.7	Performance Graphs	5-9
	List of Figures	5-9

**SECTION 5
PERFORMANCE**

5.1 GENERAL

All of the required (FAA regulations) and complementary performance information applicable to the Cherokee Turbo Arrow III is provided by this section.

Performance information associated with those optional systems and equipment which require handbook supplements is provided by Section 9 (Supplements).

5.3 INTRODUCTION TO PERFORMANCE AND FLIGHT PLANNING

The performance information presented in this section is based on measured Flight Test Data corrected to I.C.A.O. standard day conditions and analytically expanded for the various parameters of weight, altitude, temperature, etc.

The performance charts are unfactored and do not make any allowance for varying degrees of pilot proficiency or mechanical deterioration of the aircraft. This performance, however, can be duplicated by following the stated procedures in a properly maintained airplane.

Effects of conditions not considered on the charts must be evaluated by the pilot, such as the effect of soft or grass runway surface on takeoff and landing performance, or the effect of winds aloft on cruise and range performance. Endurance can be grossly affected by improper leaning procedures, and inflight fuel flow and quantity checks are recommended.

REMEMBER! To get chart performance, follow the chart procedures.

The information provided by paragraph 5.5 (Flight Planning Example) outlines a detailed flight plan using the performance charts in this section. Each chart includes its own example to show how it is used.

THIS PAGE INTENTIONALLY LEFT BLANK

5.5 FLIGHT PLANNING EXAMPLE

(a) Aircraft Loading

The first step in planning our flight is to calculate the airplane weight and center of gravity by utilizing the information provided by Section 6 (Weight and Balance) of this handbook.

The basic empty weight for the airplane as delivered from the factory has been entered in Figure 6-5. If any alterations to the airplane have been made effecting weight and balance, reference to the aircraft logbook and Weight and Balance Record (Figure 6-7) should be made to determine the current basic empty weight of the airplane.

Make use of the Weight and Balance Loading Form (Figure 6-11) and the C.G. Range and Weight graph (Figure 6-15) to determine the total weight of the airplane and the center of gravity position.

After proper utilization of the information provided we have found the following weights for consideration in our flight planning example.

The landing weight cannot be determined until the weight of the fuel to be used has been established [refer to item (g)(1)].

(1) Basic Empty Weight	1810 lbs.
(2) Occupants (2 x 170 lbs.)	340 lbs.
(3) Baggage and Cargo	128 lbs.
(4) Fuel (6 lb./gal. x 77)	462 lbs.
(5) Takeoff Weight	2740 lbs.
(6) Landing Weight	
(a)(5) minus (g)(1), (2740 lbs. minus 360 lbs.)	2380 lbs.

Our takeoff weight is below the maximum of 2900 lbs. and our weight and balance calculations have determined our C.G. position within the approved limits.

(b) Takeoff and Landing

Now that we have determined our aircraft loading, we must consider all aspects of our takeoff and landing.

All of the existing conditions at the departure and destination airport must be acquired, evaluated and maintained throughout the flight.

Apply the departure airport conditions and takeoff weight to the appropriate Takeoff Performance and Takeoff Ground Roll graph (Figures 5-5, 5-7, 5-9 and 5-11) to determine the length of runway necessary for the takeoff and/or the barrier distance.

The landing distance calculations are performed in the same manner using the existing conditions at the destination airport and, when established, the landing weight.

The conditions and calculations for our example flight are listed below. The takeoff and landing distances required for our example flight have fallen well below the available runway lengths.

	Departure Airport	Destination Airport
(1) Pressure Altitude	4990 ft.	2000 ft.
(2) Temperature	20° C	30° C
(3) Wind Component	6 KTS	0 KTS
(4) Runway Length Available	5000 ft.	4600 ft.
(5) Runway Required	3750 ft.*	1470 ft.**

NOTE

The remainder of the performance charts used in this flight planning example assume a no wind condition. The effect of winds aloft must be considered by the pilot when computing climb, cruise and descent performance.

(c) Climb

The next step in our flight plan is to determine the necessary climb segment components.

The desired cruise pressure altitude and corresponding cruise outside air temperature values are the first variables to be considered in determining the climb components from the Fuel, Distance, and Time to Climb graph (Figure 5-17). After the fuel, distance and time for the cruise pressure altitude and outside air temperature values have been established, apply the existing conditions at the departure field to graph (Figure 5-17). Now, subtract the values obtained from the graph for the field of departure conditions from those for the cruise pressure altitude.

The remaining values are the true fuel, distance and time components for the climb segment of the flight plan corrected for field pressure altitude and temperature.

The following values were determined from the above instructions in our flight planning example.

(1) Cruise Pressure Altitude	8500 ft.
(2) Cruise OAT	10° C
(3) Time to Climb (12 min. minus 8 min.)	4 min.***
(4) Distance to Climb (20 nautical miles minus 13 nautical miles)	7 nautical miles***
(5) Fuel to Climb (4 gal. minus 2.5 gal.)	1.5 gal.***

*reference Figure 5-11

**reference Figure 5-35

***reference Figure 5-17

(d) Descent

The descent data will be determined prior to the cruise data to provide the descent distance for establishing the total cruise distance.

Utilizing the cruise pressure altitude and OAT we determine the basic fuel, distance and time for descent (Figure 5-31). These figures must be adjusted for the field pressure altitude and temperature at the destination airport. To find the necessary adjustment values, use the existing pressure altitude and temperature conditions at the destination airport as variables to find the fuel, distance and time values from the graph (Figure 5-31). Now, subtract the values obtained from the field conditions from the values obtained from the cruise conditions to find the true fuel, distance and time values needed for the flight plan.

The values obtained by proper utilization of the graphs for the descent segment of our example are shown below.

- | | |
|---|--------------------|
| (1) Time to Descend (10 min. minus 4 min.) | 6 min.* |
| (2) Distance to Descend (24 nautical miles minus 10 nautical miles) | 14 nautical miles* |
| (3) Fuel to Descend (2 gal. minus 1 gal.) | 1 gal.* |

(e) Cruise

Using the total distance to be traveled during the flight, subtract the previously calculated distance to climb and distance to descend to establish the total cruise distance. Refer to the Power Setting Table (Figure 5-19) when selecting the cruise power setting. The established pressure altitude and temperature values and the selected cruise power should now be utilized to determine the true airspeed from the appropriate Speed Power graph (Figure 5-21 or 5-23).

Calculate the cruise fuel flow for the cruise power setting (75% Power Best Economy for this example) from the information provided by the Best Economy Range chart (Figure 5-27).

The cruise time is found by dividing the cruise distance by the cruise speed and the cruise fuel is found by multiplying the cruise fuel flow by the cruise time.

The cruise calculations established for the cruise segment of our flight planning example are as follows:

- | | |
|--|----------------------------|
| (1) Total Distance | 745 nautical miles |
| (2) Cruise Distance | |
| (e)(1) minus (c)(4) minus (d)(2), (745 nautical miles
minus 7 nautical miles minus 14 nautical miles) | 724 nautical miles |
| (3) Cruise Power (Best Economy) | 75% rated power |
| (4) Cruise Speed | 151 KTS TAS** |
| (5) Cruise Fuel Consumption | 12 GPH*** |
| (6) Cruise Time | |
| (e)(2) divided by (e)(4), (724 nautical miles divided
by 151 KTS) | 4.79 hrs. (4 hrs. 47 min.) |
| (7) Cruise Fuel | |
| (e)(5) multiplied by (e)(6), (12 GPH multiplied by 4.79 hrs.) | 57.5 gal. |

*reference Figure 5-31

**reference Figure 5-25

***reference Figure 5-27

(f) Total Flight Time

The total flight time is determined by adding the time to climb, the time to descend and the cruise time. Remember! The time values taken from the climb and descent graphs are in minutes and must be converted to hours before adding them to the cruise time.

The following flight time is required for our flight planning example.

(1) Total Flight Time

(c)(3) plus (d)(1) plus (e)(6), (.07 hrs. plus .10 hrs. plus 4.79 hrs.)
(4 min. plus 6 min. plus 4 hrs. & 47 min.) 4.96 hrs.

(g) Total Fuel Required

Determine the total fuel required by adding the fuel to climb, the fuel to descend and the cruise fuel. When the total fuel (in gallons) is determined, multiply this value by 6 lb./gal. to determine the total fuel weight used for the flight.

The total fuel calculations for our example flight plan are shown below.

(1) Total Fuel Required

(c)(5) plus (d)(3) plus (e)(7), (1.5 gal. plus 1 gal. plus 57.5 gal.) 60 gal.
(60 gal. multiplied by 6 lb./gal.) 360 lbs.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK


5.7 PERFORMANCE GRAPHS

LIST OF FIGURES

Figure No.		Page No.
5-1	Airspeed System Calibration	5-11
5-3	Power Off Stall Speed Versus Angle of Bank	5-12
5-5	25° Flap Takeoff Performance	5-13
5-7	25° Flap Takeoff Ground Roll	5-14
5-9	0° Flap Takeoff Performance	5-15
5-11	0° Flap Takeoff Ground Roll	5-16
5-13	Gear Up Climb Performance	5-17
5-15	Gear Down Climb Performance	5-18
5-17	Fuel, Time and Distance to Climb	5-19
5-19	Power Setting Table	5-21
5-21	Speed Power - Performance Cruise	5-23
5-23	Speed Power - Economy Cruise	5-24
5-25	Range - Best Power Mixture	5-25
5-27	Range - Best Economy Mixture	5-26
5-29	Endurance	5-27
5-31	Fuel, Time and Distance to Descend	5-28
5-33	Glide Time and Distance	5-29
5-35	Landing Distance Over 50 Ft.	5-30
5-37	Landing Ground Roll Distance.	5-31

THIS PAGE INTENTIONALLY LEFT BLANK

PA-28R-201T




Example:
158 KIAS = 160 KCAS

Example:
85 KIAS = 83 KCAS

AIRSPEED SYSTEM CALIBRATION

Figure 5-1


PA-28R-201T



POWER OFF STALL SPEED VERSUS ANGLE OF BANK

Figure 5-3

PA-28R-201T




Example:
 Pressure altitude: 5000 ft.
 OAT: -20°C
 Gross weight: 2740 lbs.
 Wind: 3 knots (tailwind)
 Takeoff distance: 1900 ft.

25° FLAP TAKEOFF PERFORMANCE

Figure 5-5

PA-28R-201T



Example:

Pressure altitude: 5000 ft.

OAT: 20°C

Gross weight: 2740 lbs.


Wind: 8 knots (headwind)

Takeoff ground roll: 1650 ft.

25° FLAP TAKEOFF GROUND ROLL

Figure 5-7

PA-28R-201T




Example:

- Pressure altitude: 4990 ft.
- OAT: 20°C
- Gross weight: 2740 lbs.
- Surface wind: 6 knots (headwind)
- Takeoff distance: 3750 ft.

0° FLAP TAKEOFF PERFORMANCE

Figure 5-9

PA-28R-201T




Example:

- Pressure altitude: 5000 ft.
- OAT: 20°C
- Gross weight: 2740 lbs.
- Wind: 6 knots (headwind)
- Takeoff ground roll: 2900 ft.

0° FLAP TAKEOFF GROUND ROLL

Figure 5-11

PA-28R-201T




Example:
Pressure altitude: 8500 ft.
OAT: 10°C
Gross weight: 2740 lbs.
Rate of climb: 900 FPM

GEAR UP CLIMB PERFORMANCE

Figure 5-13

PA-28R-201T




Example:

- Pressure altitude: 5000 ft.
- OAT: 20°C
- Gross weight: 2740 lbs.
- Gear down rate of climb: 690 FPM

GEAR DOWN CLIMB PERFORMANCE

Figure 5-15

PA-28R-201T



Example:

- Departure pressure altitude: 5000 ft.
- Departure OAT: 20°C
- Cruise pressure altitude: 8500 ft.
- Cruise OAT: 10°C
- Fuel to climb: (4 minus 2.5) = 1.5 gal.
- Time to climb: (12 minus 8) = 4 min.
- Distance to climb: (20 minus 13) = 7 nautical miles

FUEL, TIME AND DISTANCE TO CLIMB

Figure 5-17

THIS PAGE INTENTIONALLY LEFT BLANK

POWER SETTING TABLE - T.C.M. TSIO 360F SERIES

PRESS. ALT. FEET	STD. ALT. TEMP. ° F	RPM	55% POWER					65% POWER					75% POWER				
			2200	2300	2400	2500	2575	2200	2300	2400	2500	2575	2200	2300	2400	2500	2575
			MANIFOLD PRESSURE -- INCHES MERCURY														
S.L.	59		29.0	27.7	26.8	26.0	25.0	32.8	31.1	30.0	29.2	28.2		34.8	33.8	32.8	31.5
2000	52		29.0	27.7	26.8	26.0	25.0	32.8	31.1	30.0	29.2	28.2		34.8	33.8	32.8	31.5
4000	45		29.0	27.7	26.8	26.0	25.0	32.8	31.1	30.0	29.2	28.2		34.8	33.8	32.8	31.5
6000	38		29.0	27.7	26.8	26.0	25.0	32.8	31.1	30.0	29.2	28.2	34.8	33.8	32.8	31.5	
8000	31		29.0	27.7	26.8	26.0	25.0		31.1	30.0	29.2	28.2		33.8	32.8	31.5	
10000	23		29.0	27.7	26.8	26.0	25.0		31.1	30.0	29.2	28.2		33.8	32.8	31.5	
12000	16			27.7	26.8	26.0	25.0			30.0	29.2	28.2			32.8	31.5	
14000	9			27.7	26.8	26.0	25.0			30.0	29.2	28.2			32.8	31.5	
16000	2				26.8	26.0	25.0				29.2	28.2				31.5	
18000	-5					26.0	25.0				29.2	28.2				31.5	
20000	-12					26.0	25.0					28.2				31.5	

For each 6°F above std. temp. add 0.4" MAP.
For each 6°F below std. temp. subtract 0.4" MAP.

APPROXIMATE FUEL FLOW	
BEST ECONOMY	BEST POWER
55% Power 9.2 GPH	55% 11. GPH
65% Power 10.8 GPH	65% 12.7 GPH
75% Power 12. GPH	75% 14. GPH


NOTE: Fuel flow will vary with altitude; therefore, cruise fuel control must be accomplished by adjusting EGT (peak EGT for best economy and peak EGT plus 100°F rich for best power) rather than leaning to an indicated fuel flow.

POWER SETTING TABLE

Figure 5-19

THIS PAGE INTENTIONALLY LEFT BLANK

PA-28R-201T




Example:

- Cruise pressure altitude: 8500 ft.
- Cruise OAT: 10°C
- Power: 75%
- True airspeed: 154 knots

SPEED POWER - PERFORMANCE CRUISE

Figure 5-21

PA-28R-201T




Example:

- Cruise pressure altitude: 8500 ft.
- Cruise OAT: 10°C
- Power: 75%
- True airspeed: 151 knots

SPEED POWER - ECONOMY CRUISE

Figure 5-23

PA-28R-201T



*Fuel flow will vary with altitude, therefore, cruise fuel control is accomplished by EGT rather than fuel flow.


Example:

- Cruise pressure altitude: 8500 ft.
- Cruise OAT: 10°C
- Power: 75%
- Range: 675 N.M. with reserve, 755 N.M. no reserve

RANGE - BEST POWER MIXTURE

Figure 5-25

PA-28R-201T



*Fuel flow will vary with altitude, therefore, cruise fuel control is accomplished by EGT rather than fuel flow.

Example:

Cruise pressure altitude: 8500 ft.

Cruise OAT: 10°C


Power: 75%

Range: 785 N.M. with reserve, 875 N.M. no reserve

RANGE - BEST ECONOMY MIXTURE

Figure 5-27

PA-28R-201T



Example:

Cruise pressure altitude: 8500 ft.

Cruise OAT: 10°C


Power: 75%

Endurance: 5 hours with reserve, 5.75 hours no reserve

ENDURANCE

Figure 5-29


PA-28R-201T



FUEL, TIME AND DISTANCE TO DESCEND

Figure 5-31

PA-28R-201T




Example:

- Cruise pressure altitude: 8500 ft.
- Cruise OAT: 10°C
- Terrain pressure altitude: 2000 ft.
- Terrain OAT: 30°C
- Glide time: (9 minus 4) = 5 min.
- Glide distance: (16 minus 7) = 9 nautical miles

GLIDE TIME AND DISTANCE

Figure 5-33

PA-28R-201T




Example:

Destination pressure altitude: 2000 ft.
 Destination OAT: 30°C
 Landing weight: 2378 lbs.; approach speed: 72.6 KIAS
 Wind: 3 knots (headwind)
 Landing distance: 1470 ft.

LANDING DISTANCE OVER 50 FT.

Figure 5-35

PA-28R-201T



Example:

- Destination pressure altitude: 2000 ft.
- Destination OAT: 30°C
- Landing weight: 2378 lbs.
- Wind: 3 knots (headwind)
- Landing ground roll: 580 ft.

LANDING GROUND ROLL DISTANCE

Figure 5-37

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 6

WEIGHT AND BALANCE

Paragraph No.		Page No.
6.1	General	6-1
6.3	Airplane Weighing Procedure	6-3
6.5	Weight and Balance Data and Record	6-6
6.7	Weight and Balance Determination for Flight	6-11
6.9	Equipment List	6-17
(a)	Propeller and Propeller Accessories	6-17
(b)	Engine and Engine Accessories	6-19
(c)	Landing Gear and Brakes	6-21
(d)	Electrical Equipment	6-23
(e)	Instruments	6-25
(f)	Miscellaneous	6-27
(g)	Engine and Engine Accessories (Optional Equipment)	6-29
(h)	Propeller and Propeller Accessories (Optional Equipment)	6-31
(i)	Landing Gear and Brakes (Optional Equipment)	6-33
(j)	Electrical Equipment (Optional Equipment)	6-35
(k)	Instruments (Optional Equipment)	6-37
(l)	Autopilots (Optional Equipment)	6-39
(m)	Radio Equipment (Optional Equipment)	6-41
(n)	Miscellaneous (Optional Equipment)	6-53

SECTION 6
WEIGHT AND BALANCE

6.1 GENERAL

In order to achieve the performance, safety and good flying characteristics which are designed into the airplane, it must be flown with the weight and center of gravity (C.G.) position within the approved operating range (envelope). Although the airplane offers a tremendous flexibility of loading, it cannot be flown with the maximum number of adult passengers, full fuel tanks and maximum baggage. With the flexibility comes responsibility. The pilot must ensure that the airplane is loaded within the loading envelope before he makes a takeoff.

Misloading carries consequences for any aircraft. An overloaded airplane will not take off, climb or cruise as well as a properly loaded one. The heavier the airplane is loaded, the less climb performance it will have.

Center of gravity is a determining factor in flight characteristics. If the C.G. is too far forward in any airplane, it may be difficult to rotate for takeoff or landing. If the C.G. is too far aft, the airplane may rotate prematurely on takeoff or tend to pitch up during climb. Longitudinal stability will be reduced. This can lead to inadvertent stalls and even spins; and spin recovery becomes more difficult as the center of gravity moves aft of the approved limit.

A properly loaded airplane, however, will perform as intended. This airplane is designed to provide excellent performance and safety within the flight envelope. Before the airplane is delivered, it is weighed, and a basic empty weight and C.G. location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment). Using the basic empty weight and C.G. location, the pilot can easily determine the weight and C.G. position for the loaded airplane by computing the total weight and moment and then determining whether they are within the approved envelope.

The basic empty weight and C.G. location are recorded in the Aircraft Log Book, or the Weight and Balance Data Form (Figure 6-5) and the Weight and Balance Record (Figure 6-7). The current values should always be used. Whenever new equipment is added or any modification work is done, the mechanic responsible for the work is required to compute a new basic empty weight and C.G. position and to write these in the Aircraft Log Book and the Weight and Balance Record. The owner should make sure that it is done.

A weight and balance calculation can be helpful in determining how much fuel or baggage can be boarded so as to keep within allowable limits. Check calculations prior to adding fuel to insure against overloading.

The following pages are forms used in weighing an airplane in production and in computing basic empty weight, C.G. position, and useful load. Note that the useful load includes usable fuel, baggage, cargo and passengers. Following this is the method for computing takeoff weight and C.G.

THIS PAGE INTENTIONALLY LEFT BLANK

6.3 AIRPLANE WEIGHING PROCEDURE

At the time of delivery, Piper Aircraft Corporation provides each airplane with the basic empty weight and center of gravity location. This data is supplied by Figure 6-5.

The removal or addition of equipment or airplane modifications can affect the basic empty weight and center of gravity. The following is a weighing procedure to determine this basic empty weight and center of gravity location:

(a) Preparation

- (1) Be certain that all items checked in the airplane equipment list are installed in the proper location in the airplane.
- (2) Remove excessive dirt, grease, moisture, foreign items such as rags and tools from the airplane before weighing.
- (3) Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Operate engine on each tank until all undrainable fuel is used and engine stops. Then add the unusable fuel (5.0 gallons total, 2.5 gallons each wing).
- (4) Fill with oil to full capacity.
- (5) Place pilot and copilot seats in fourth (4th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. Tow bar should be in the proper location and all entrance and baggage doors closed.
- (6) Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.

(b) Leveling

- (1) With airplane on scales, block main gear oleo pistons in the fully extended position.
- (2) Level airplane (refer to Figure 6-3) deflating nose wheel tire, to center bubble on level.

(c) Weighing - Airplane Basic Empty Weight

- (1) With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.


Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Basic Empty Weight, as Weighed (T)	— —	— —	

WEIGHING FORM

Figure 6-1

(d) Basic Empty Weight Center of Gravity

- (1) The following geometry applies to the PA-28R-201T airplane when it is level. Refer to Leveling paragraph 6.3 (b).



The datum is 78.4 inches ahead of the wing leading edge at the intersection of the straight and tapered section.

A = 15.6
B = 109.7

LEVELING DIAGRAM

Figure 6-3

- (2) The basic empty weight center of gravity (as weighed including optional equipment, full oil and unusable fuel) can be determined by the following formula:

$$\text{C.G. Arm} = \frac{N(A) + (R+L)(B)}{T} \quad \text{inches}$$

Where: $T = N + R + L$

6.5 WEIGHT AND BALANCE DATA AND RECORD

The Basic Empty Weight, Center of Gravity Location and Useful Load listed in Figure 6-5 are for the airplane as delivered from the factory. These figures apply only to the specific airplane serial number and registration number shown.

The basic empty weight of the airplane as delivered from the factory has been entered in the Weight and Balance Record (Figure 6-7). This form is provided to present the current status of the airplane basic empty weight and a complete history of previous modifications. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the Weight and Balance Record.

MODEL PA-28R-201T CHEROKEE TURBO ARROW III

Airplane Serial Number _____

Registration Number _____

Date _____

AIRPLANE BASIC EMPTY WEIGHT

Item	Weight (Lbs)		x	C. G. Arm (Inches Aft of Datum)	=	Moment (In-Lbs)
	Actual	Computed				
Standard Empty Weight*						
Optional Equipment						
Basic Empty Weight						

*The standard empty weight includes full oil capacity and 5.0 gallons of unusable fuel.

AIRPLANE USEFUL LOAD - NORMAL CATEGORY OPERATION

(Gross Weight) - (Basic Empty Weight) = Useful Load

(2900 lbs) - (lbs) = lbs.

THIS BASIC EMPTY WEIGHT, C.G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS DELIVERED FROM THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

WEIGHT AND BALANCE DATA FORM

Figure 6-5

THIS PAGE INTENTIONALLY LEFT BLANK

PA-28R-201T			Serial Number	Registration Number						Page Number	
Date	Item No.		Description of Article or Modification	Weight Change						Running Basic Empty Weight	
	In	Out		Added (+)			Removed (-)			Wt. (Lb.)	Moment /100
				Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Arm (In.)	Moment /100		
			As Delivered								

WEIGHT AND BALANCE RECORD

Figure 6-7

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

PA-28R-201T			Serial Number	Registration Number			Page Number				
Date	Item No.		Description of Article or Modification	Weight Change Added (+)			Weight Change Removed (-)			Running Basic Empty Weight	
	In	Out		Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Moment /100
			As Delivered								

WEIGHT AND BALANCE RECORD (cont)

Figure 6-7 (cont)

6.7 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT

- (a) Add the weight of all items to be loaded to the basic empty weight.
- (b) Use the Loading Graph (Figure 6-13) to determine the moment of all items to be carried in the airplane.
- (c) Add the moment of all items to be loaded to the basic empty weight moment.
- (d) Divide the total moment by the total weight to determine the C.G. location.
- (e) By using the figures of item (a) and item (d) (above), locate a point on the C.G. range and weight graph (Figure 6-15). If the point falls within the C.G. envelope, the loading meets the weight and balance requirements.

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight			
Pilot and Front Passenger	340.0	80.5	27370
Passengers (Rear Seats)	340.0	118.1	40154
Fuel (72 Gallon Maximum)		95.0	
Baggage		142.8	
Moment due to Retraction of Landing Gear			819
Total Loaded Airplane			

The center of gravity (C.G.) of this sample loading problem is at _____ inches aft of the datum line. Locate this point () on the C.G. range and weight graph. Since this point falls within the weight - C.G. envelope, this loading meets the weight and balance requirements.

IT IS THE RESPONSIBILITY OF THE PILOT AND AIRCRAFT OWNER TO INSURE THAT THE AIRPLANE IS LOADED PROPERLY.

SAMPLE LOADING PROBLEM (NORMAL CATEGORY)

Figure 6-9

**SECTION 6
WEIGHT AND BALANCE**


**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight			
Pilot and Front Passenger		80.5	
Passengers (Rear Seats)		118.1	
Fuel (72 Gallon Maximum)		95.0	
Baggage		142.8	
Moment due to Retraction of Landing Gear			819
Total Loaded Airplane			

Totals must be within approved weight and C.G. limits. It is the responsibility of the airplane owner and the pilot to insure that the airplane is loaded properly. The Basic Empty Weight C.G. is noted on the Weight and Balance Data Form (Figure 6-5). If the airplane has been altered, refer to the Weight and Balance Record for this information.


WEIGHT AND BALANCE LOADING FORM

Figure 6-11



LOADING GRAPH

Figure 6-13



Moment due to retracting landing gear = +819 in. lbs.

C. G. RANGE AND WEIGHT

Figure 6-15

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

6.9 EQUIPMENT LIST

The following is a list of equipment which may be installed in the PA-28R-201T. It consists of those items used for defining the configuration of an airplane when the basic empty weight is established at the time of delivery. Only those standard items which are alternate standard items and those required to be listed by the certificating authority (FAA) are presented. Items marked with an "X" are those items which were installed on the airplane described below as delivered by the manufacturer.

PIPER AIRCRAFT CORPORATION

PA-28R-201T CHEROKEE TURBO ARROW III

SERIAL NO. _____ REGISTRATION NO. _____ DATE: _____

(a) Propeller and Propeller Accessories

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
1	Propeller, Hartzell BHC-C2YF-1BF/F8459A-8R Cert. Basis - TC P920				
3	Propeller Governor				
	a. Piper Dwg. 37845-2	_____	3.7	3.8	14
	b. Piper Dwg. 37476-3	_____	2.5	3.8	10
	Cert. Basis - TC P920				

THIS PAGE INTENTIONALLY LEFT BLANK

(b) Engine and Engine Accessories

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
5	Teledyne Continental Model TSIO-360-F Cert. Basis - TC E9CE				

THIS PAGE INTENTIONALLY LEFT BLANK

(c) Landing Gear and Brakes

Item No.	Item	Mark if Instl.	Weight Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
11	Two Main Wheel Assemblies				
	a. Cleveland Aircraft Products				
	Wheel Assy. No. 40-86				
	Brake Assy. No. 30-55				
	Cert. Basis - TSO C26a				
	b. 6.00-6 Type III 6 Ply				
	Rating Tires with Regular				
	Tubes				
	Cert. Basis - TSO C62				
13	Nose Wheel Assembly				
	a. Cleveland Aircraft Products				
	Wheel Assy. No. 40-77				
	Cert. Basis - TSO C26a	_____	2.6	15.5	40
	b. McCauley Industrial Corp.				
	Wheel Assy. No. D-30500				
	Cert. Basis - TSO C26b	_____	3.6	15.5	56
	c. 5.00-5 Type III 4 Ply				
	Rating Tire with Regular				
	Tube				
	Cert. Basis - TSO C62				

THIS PAGE INTENTIONALLY LEFT BLANK

(d) Electrical Equipment

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

(e) Instruments

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
21	Altimeter, Piper PS50008-50-2 Cert. Basis - TSO C10b				
23	Airspeed Indicator Piper PS50049-33S Cert. Basis - TSO C2b				
25	Manifold Pressure and Fuel Flow Indicator Piper Dwg. 35711-2 Cert. Basis - TSO C45, C47				
27	Compass Cert. Basis - TSO C7c				

THIS PAGE INTENTIONALLY LEFT BLANK

(f) Miscellaneous

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
33	Front Seat Belts (2) Piper PS50039-4-2A Cert. Basis - TSO C22f				
35	Rear Seat Belts (2) Piper PS50039-4-3A Cert. Basis - TSO C22f				

THIS PAGE INTENTIONALLY LEFT BLANK

(g) Engine and Engine Accessories
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
51	Optional Engine Primer System, Piper Dwg. 37865-3 Cert. Basis - TC 2A13	_____	1.6	13.9	22.2

THIS PAGE INTENTIONALLY LEFT BLANK

(h) Propeller and Propeller Accessories
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

(i) Landing Gear and Brakes
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	---------------------

THIS PAGE INTENTIONALLY LEFT BLANK

(j) Electrical Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
79	Instrument Panel Lights Cert. Basis - TC 2A13	_____	0.3	62.8	19
81	Instrument Light, Grimes 15-0083-7 Cert. Basis - TC 2A13	_____	0.1	99.0	10
83	Cabin Light Cert. Basis - TC 2A13	_____	0.3	99.0	30
85	Landing Light, G.E. Model 4509 Cert. Basis - TC 2A13	_____	0.5	10.0	5
87	Navigation Lights (Wing) (2) Grimes Model A1285 (Red and Green) Cert. Basis - TC 2A13	_____	0.4	106.6	43
89	Navigation Light (Rear) (1), Grimes Model A2064 (White) Cert. Basis - TC 2A13	_____	0.2	281.0	56
91	Rotating Beacon Cert. Basis - TC 2A13	_____	1.5	263.4	395
93	Anti-Collision Lights (Wing Tip) (Whelen) Cert. Basis - STC SA615EA	_____	5.7	157.9	900

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(j) Electrical Equipment (Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
95	Heated Pitot Head, Cert. Basis - TC 2A13	_____	0.4	100.0	40
97	Piper Pitch Trim Piper Dwg. 67496-3 Cert. Basis - TC 2A13	_____	4.3	155.3	668
99	Battery 12V 35 A.H. Rebat R35 (Wt. 27.2 lbs.) Cert. Basis - TC 2A13	_____	*5.3	168.0	890
101	Auxiliary Power Receptacle, Piper Dwg. 65647 Cert. Basis - TC 2A13	_____	2.7	178.5	482
103	External Power Cable, Piper Dwg. 62355-2 Cert. Basis - TC 2A13	_____	4.6	142.8	657
105	Lighter, * 200462, 12 Volt Universal Cert. Basis - TC 2A13	_____	0.2	62.9	13

*Weight and moment difference between standard and optional equipment.

(k) Instruments
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
113	Vacuum System Installation Cert. Basis - TC 2A13	_____	4.5	37.1	167
115	Attitude Gyro, Piper Dwg. 99002-3, -4 or -8 Cert. Basis - TSO C4c	_____	2.2	59.4	131
117	Directional Gyro, Piper Dwg. 99003-3, -4 or -7 Cert. Basis - TSO C5c	_____	2.6	59.7	155
119	NSD-360 Gyro Cert. Basis - TSO C6c, C9c, C52c	_____	4.1	59.0	241
121	Tru-Speed Indicator, Piper PS50049-33T Cert. Basis - TSO C2b	_____	(same as standard equipment)		
123	Altimeter, Piper PS50008-4 or -5 Cert. Basis - TSO C10b	_____	(same as standard equipment)		
125	Encoding Altimeter, Piper PS50008-6 or -7 Cert. Basis - TSO C10b, C88	_____	*0.9	60.3	54
127	Vertical Speed Piper Dwg. 99010-5 Cert. Basis - TSO C8b	_____	1.0	60.9	61
129	Alternate Static Source Cert. Basis - TC 2A13	_____	0.4	61.0	24
131	Turn and Slip Indicator, Piper PS50030-2 or -3 Cert. Basis - TSO C3b	_____	2.6	59.7	155

*Weight and moment difference between standard and optional equipment.

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(k) Instruments (Optional
Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
133	MK 10 Radar Altimeter Piper Dwg. 37693-2 Cert. Basis - TC 2A13	_____	5.4	156.3	844
135	Engine Hour Meter Piper Dwg. 79548-0 Cert. Basis - TC 2A13	_____	0.3	61.2	18
137	Clock Cert. Basis - TC 2A13	_____	0.4	62.4	25
139	Air Temperature Gauge Piper Dwg. 79316 Cert. Basis - TC 2A13	_____	0.2	72.6	15

(I) Autopilots (Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
147	AutoFlite II Cert. Basis - STC SA3162SW-D	_____	5.6	91.8	514
149	AutoControl IIIB Cert. Basis - STC SA3161SW-D	_____	9.6	77.6	745
	a. Directional Gyro # 52D54	_____	2.9	59.0	171
	b. Omni Coupler 1C-388	_____	1.0	59.3	59

THIS PAGE INTENTIONALLY LEFT BLANK

(m) Radio Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
161	Collins VHF-251 Comm Transceiver				
	a. Single	_____	3.4	56.9	193
	b. Dual	_____	6.8	56.9	387
	Cert. Basis - TSO C37b, C38b				
163	Collins VIR-351 Nav Receiver				
	a. Single	_____	2.7	57.4	155
	b. Dual	_____	5.4	57.4	310
	Cert. Basis - TSO C40a, C36c				
165	Collins IND-350 VOR/LOC Indicator				
	a. Single	_____	1.0	60.2	60
	b. Dual	_____	2.0	60.2	120
	Cert. Basis - TSO C40a, C36c				
167	Collins IND-351 VOR/LOC/GS Indicator				
	Cert. Basis - TSO C40a, C36c				
		_____	1.3	60.2	78
169	Collins GLS-350 Glide Slope Receiver				
	Cert. Basis - TSO C34c				
		_____	2.0	181.8	364
171	Collins RCR-650 ADF Receiver and Antenna and IND-650 Indicator				
	Cert. Basis - TSO C41c				
		_____	6.6	104.8	692
173	Collins AMR-350 Audio/Marker Panel				
	Cert. Basis - TSO C35d, C50b				
		_____	*3.3	110.0	363
175	Collins TDR-950 Transponder				
	Cert. Basis - TSO C74c				
		_____	2.8	63.2	177

*Weight includes antenna and cable.

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

(m) Radio Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
177	King KX 170 () VHF Comm/Nav				
	a. Transceiver, Single	_____	7.5	56.6	425
	b. Transceiver, Dual	_____	15.0	56.6	849
	Cert. Basis - TC 2A13				
179	King KX 175 () VHF				
	a. Transceiver,	_____	9.4	56.6	532
	b. King KN 73 Glide Slope Receiver,	_____	3.2	184.3	590
	c. King KN 77 VOR/LOC Converter,	_____	3.6	183.6	661
	d. King KNI 520 VOR/ILS Indicator	_____	2.8	60.5	169
	Cert. Basis - TSO C3bc, C37b, C38b, C40a				
181	King KX 175 () VHF				
	a. Transceiver (2nd),	_____	8.6	56.6	487
	b. King KN 77 VOR/LOC Converter,	_____	4.2	183.6	771
	c. King KNI 520 VOR/ILS Indicator	_____	2.8	60.5	169
	Cert. Basis - TSO C36c, C37b, C38b, C40a				
183	King KI 201 () VOR/ LOC Ind.				
	a. Single	_____	2.5	59.6	149
	b. Dual	_____	5.0	59.9	300
	Cert. Basis - TC 2A13				
185	King KI 213 VOR/LOC/GS Indicator				
	Cert. Basis - TC 2A13	_____	2.5	60.4	151
187	King KI 214 () VOR/ LOC/GS Ind.				
	Cert. Basis - TC 2A13	_____	3.3	59.9	198
189	King KN 74 R-Nav				
	Cert. Basis - TC 2A13	_____	4.7	56.6	266

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
191	King KN 61 DME Cert. Basis - TC 2A13	_____	12.5	179.0	2237
193	King KN 65A DME Cert. Basis - TSO C66a	_____	13.0	174.9	2274
195	King KR 85 Digital ADF a. Audio Amplifier Cert. Basis - TSO C41b	_____	8.6	85.2	733
		_____	0.8	51.0	41
197	King KR 86 ADF a. First b. Second c. Audio Amplifier Cert. Basis - TC 2A13	_____	6.7	91.6	614
		_____	9.7	107.0	1038
		_____	0.8	51.0	41
199	King KMA 20 () Audio Panel Cert. Basis - TSO C35c, C50b	_____	*3.7	70.8	262
201	King KT 76/78 Transponder Cert. Basis - TSO C74b	_____	*3.1	58.1	180

*Weight includes antenna and cable.

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
203	Narco Comm 10A VHF Transceiver Cert. Basis - TC 2A13	_____	3.9	57.4	224
205	Narco Comm 11A VHF Transceiver				
	a. Single	_____	3.6	57.4	207
	b. Dual	_____	7.1	57.4	408
	Cert. Basis - TC 2A13				
207	Narco Comm 11B VHF Transceiver				
	a. Single	_____	3.9	57.4	224
	b. Dual	_____	7.8	57.4	448
	Cert. Basis - TC 2A13				
209	Narco Comm 111 VHF Transceiver				
	a. Single	_____	3.0	57.4	172
	b. Dual	_____	6.0	57.4	344
	Cert. Basis - TSO C37b, C38b				
211	Narco Comm 111B VHF Transceiver				
	a. Single	_____	3.9	57.4	224
	b. Dual	_____	7.8	57.4	448
	Cert. Basis - TSO C37b, C38b				
213	Narco Comm 120 VHF Transceiver				
	a. Single	_____	4.8	56.9	273
	b. Dual	_____	8.6	57.4	494
	Cert. Basis - TSO C37b, C38b				
215	Narco Nav 10 VHF Receiver Cert. Basis - TC 2A13	_____	1.9	58.6	111
217	Narco Nav 11 VHF Receiver				
	a. Single	_____	2.8	58.6	164
	b. Dual	_____	5.6	58.6	328
	Cert. Basis - TC 2A13				
219	Narco Nav 12 VHF Receiver Cert. Basis - TC 2A13	_____	3.4	58.6	199

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
223	Narco Nav 14 VHF Receiver Cert. Basis - TC 2A13	_____	2.5	57.4	144
225	Narco Nav 111 Cert. Basis - TSO C36c, C40a, C66a	_____	2.5	58.6	147
227	Narco Nav 112 Receiver Cert. Basis - TSO C36c, C40a, C66c, C34c	_____	3.3	58.6	193
229	Narco Nav 114 VHF Receiver Cert. Basis - TSO C38b, C40a, C36c, C34c, C66a	_____	2.5	57.4	144
231	Narco Nav 121 VHF Receiver a. Single b. Dual Cert. Basis - TSO C36c, C40c, C66a	_____ _____	3.1 6.2	58.4 58.4	181 362
233	Narco Nav 122 VHF Receiver a. Single b. Dual Cert. Basis - TSO C35d, C36c, C40c, C66a	_____ _____	*5.1 *8.6	99.4 82.9	507 713
235	Narco Nav 122A VHF Receiver a. Single b. Dual Cert. Basis - TSO C34c, C35d, C36c, C40c, C66a	_____ _____	*5.2 *8.8	98.5 82.2	512 723
237	Narco Nav 124A VHF Receiver a. Single b. Dual Cert. Basis - TSO C35d, C36c, C40a, C66a	_____ _____	*6.2 *10.9	92.3 77.2	572 841
239	Narco Nav 124R VHF Receiver Cert. Basis - TSO C36c, C40a, C66a	_____	4.4	57.5	253

*Weight includes marker antenna and cable.

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
241	Narco ID 124 VOR/LOC/GS Indicator				
	a. Single	_____	1.2	60.5	73
	b. Dual	_____	2.4	60.5	145
	Cert. Basis - TSO C34c, C35d, C36c, C40c				
243	Narco OC-110 Converter and Mount				
	Cert. Basis - TSO C36c, C40a	_____	2.1	185.5	390
245	Narco UGR-2A Glide Slope				
	a. Single	_____	4.2	154.0	647
	b. Dual	_____	8.4	220.0	1848
	Cert. Basis - TSO C34b				
247	Narco UGR-3 Glide Slope				
	Cert. Basis - TC 2A13	_____	4.2	154.0	647
249	Narco MBT-12-R, Marker Beacon				
	Cert. Basis - TC 2A13	_____	3.1	69.1	214
251	Narco CP-125 Audio Selector Panel				
	Cert. Basis - TC 2A13	_____	2.2	55.0	121
253	Narco CP135 Audio Selector Panel				
	Cert. Basis - TSO C50b	_____	2.2	55.0	121
255	Narco CP135M Audio Selector Panel				
	Cert. Basis - TSO C50b, C35d	_____	*3.7	114.3	423
257	Narco CLC-60A R-NAV				
	a. Narco SA-11 Adapter	_____	9.6	140.1	1345
	Cert. Basis - TC 2A13	_____	0.7	174.0	122

*Weight includes marker antenna and cable.

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
259	Narco DME-190 Cert. Basis - TC 2A13	_____	*5.9	60.9	359
261	Narco DME-190 TSO Cert. Basis - TSO C66a	_____	*5.9	60.9	359
263	Narco DME-195 Receiver and Indicator Cert. Basis - TSO C66a	_____	*13.2	154.5	2039
265	Narco ADF-140 a. Single b. Dual Cert. Basis - TSO C41c	_____ _____ _____	6.0 **17.9	91.2 107.6	547 1926
267	Narco ADF-141 a. Single b. Dual Cert. Basis - TSO C41c	_____ _____ _____	6.0 **17.9	91.2 107.6	547 1926
269	Narco AT50A Transponder Cert. Basis - TSO C74b a. Narco AR-500 Altitude Encoder Cert. Basis - TSO C88	_____ _____ _____	*3.0 1.0	57.3 51.5	172 52
271	Narco AT150 Transponder Cert. Basis - TSO C74c a. Narco AR-500 Altitude Encoder Cert. Basis - TSO C88	_____ _____ _____	*3.0 1.0	57.3 51.5	172 52

*Weight includes antenna and cable.

**Weight includes dual antenna and cable.

(m) Radio Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
273	Antenna and Cable				
	a. Nav Receiving	_____	1.4	195.7	274
	b. * 1 VHF Comm	_____	0.7	125.7	88
	c. * 2 VHF Comm	_____	0.8	147.5	118
	d. Glide Slope (Single)	_____	0.9	122.2	110
	e. Glide Slope (Dual)	_____	2.8	154.0	431
	f. Single ADF Sense	_____	0.4	147.5	59
	Cert. Basis - TC 2A13				
275	Anti Static Antenna and Cable				
	a. * 1 VHF Comm	_____	1.4	144.3	202
	b. * 2 VHF Comm	_____	1.5	170.7	256
	c. Single ADF Sense	_____	0.5	147.5	74
	Cert. Basis - TC 2A13				
277	Emergency Locator Transmitter				
	a. Antenna and Coax	_____	1.7	236.2	402
	b. Shelf and Access Hole	_____	0.2	224.4	45
	Cert. Basis - TC 2A13		0.3	235.4	71
279	Microphone				
	a. Piper Dwg. 68856-10	_____	0.3	64.9	19
	b. Piper Dwg. 68856-11	_____	0.6	69.9	42
	c. Piper Dwg. 68856-12	_____	0.3	64.9	19
	Cert. Basis - TC 2A13				
281	Boom Microphone - Headset Piper Dwg. 37921-2 Cert. Basis - TC 2A13	_____	0.3	80.5	24
283	Cabin Speaker Cert. Basis - TC 2A13	_____	0.8	99.0	79
285	Headset, Piper Dwg. 68856-10 Cert. Basis - TC 2A13	_____	0.5	60.0	30

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

(n) Miscellaneous (Optional Equipment)					
Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
321	Zinc Chromate Finish Cert. Basis - TC 2A13	_____	5.0	158.0	790
323	Stainless Steel Control Cables Cert. Basis - TC 2A13	_____	-	-	-
325	Air Conditioner, Cert. Basis - TC 2A13	_____	59.6	126.6	7545
327	Overhead Vent System Piper Dwg. 76304-11 Cert. Basis - TC 2A13	_____	6.4	159.6	1022
329	Overhead Vent System with Ground Ventilating Blower Piper Dwg. 76304-12 Cert. Basis - TC 2A13	_____	14.9	172.2	2566
331	Assist Step, Piper Dwg. 65384 Cert. Basis - TC 2A13	_____	1.8	156.0	281
333	Super Cabin Sound Proofing, Piper Dwg. 79601-4 Cert. Basis - TC 2A13	_____	18.1	86.8	1571
335	Adjustable Front Seat (Left), Piper Dwg. 79591-0 or 79591-2 Cert. Basis - TC 2A13	_____	*6.6	80.3	530
337	Adjustable Front Seat (Right), Piper Dwg. 79591-1 or 79591-3 Cert. Basis - TC 2A13	_____	*6.6	79.6	525
339	Headrests (2) Front, Piper Dwg. 79337-18 Cert. Basis - TC 2A13	_____	2.2	94.5	208
341	Headrests (2) Rear, Piper Dwg. 79337-18 Cert. Basis - TC 2A13	_____	2.2	132.1	291

*Weight and moment difference between standard and optional equipment.

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28R-201T, CHEROKEE TURBO ARROW III**

(n) Miscellaneous (Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
343	Oversize Headrests (2) Front Cert. Basis - TC 2A13	_____	3.2	94.5	302
345	Oversize Headrests (2) Rear Cert. Basis - TC 2A13	_____	3.2	132.1	423
347	Inertia Safety Belts (Rear) (2) 0.8 lbs. each, Piper PS50039-4-14 Cert. Basis - TC 2A13	_____	1.6	140.3	224
349	Assist Strap, Piper Dwg. 79455 Cert. Basis - TC 2A13	_____	0.2	109.5	22
351	Curtain & Rod Instl. Piper Dwg. 79721-3 Cert. Basis - TC 2A13	_____	1.2	129.2	155
353	Curtain and Rod Installation Piper Dwg. 67955-2 Cert. Basis - TC 2A13	_____	4.2	124.0	521
355	Deluxe Carpeting Cert. Basis - TC 2A13	_____	*-1.8	101.9	-183
357	Luxurious Interior Piper Dwg. 67952-2 Cert. Basis - TC 2A13	_____	17.0	101.9	1732
359	Fire Extinguisher a. Piper Dwg. 76167-2 b. Piper Dwg. 37872-2 Cert. Basis - TC 2A13	_____ _____	4.6 5.6	71.0 57.9	327 324
361	Oxygen System - Scott Aviation MKIII (Incl. (1) Mike Mask) Scott 802180-02 Piper Dwg. 35822-2 Cert. Basis - TC 2A13	_____	19.2	118.1	2268

*Weight and moment difference between standard and optional equipment.

(n) Miscellaneous (Optional
Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

TOTAL OPTIONAL EQUIPMENT _____

EXTERIOR FINISH

Base Color _____

Registration No. Color _____

Trim Color _____

Type Finish _____

Accent Color _____

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 7

**DESCRIPTION AND OPERATION
OF THE AIRPLANE AND ITS SYSTEMS**

Paragraph No.		Page No.
7.1	The Airplane	7-1
7.3	Airframe	7-1
7.5	Engine and Propeller	7-3
7.7	Engine Controls	7-5
7.9	Landing Gear	7-6
7.11	Flight Controls	7-10
7.13	Fuel System	7-13
7.15	Electrical System	7-15
7.17	Vacuum System	7-18
7.19	Pitot-Static System	7-18
7.21	Instrument Panel	7-21
7.23	Cabin Features	7-22
7.25	Baggage Area	7-23
7.27	Heating and Ventilating System	7-25
7.29	Stall Warning	7-25
7.31	Finish	7-25
7.33	Air Conditioning	7-26
7.35	Piper External Power	7-27
7.37	Emergency Locator Transmitter	7-27

SECTION 7

DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS

7.1 THE AIRPLANE

The Cherokee Turbo Arrow III is a single engine, retractable landing gear, all metal airplane. It has seating for up to four occupants, a 200 pound luggage compartment, and a turbocharged 200 HP engine.

7.3 AIRFRAME

With the exception of the steel engine mount, the landing gear, miscellaneous steel parts, the cowling, and the lightweight plastic extremities (tips of wings, tail fin, rudder and stabilator), the basic airframe is of aluminum alloy. Aerobatics are prohibited in this airplane since the structure is not designed for aerobatic loads.

The fuselage is a semi-monocoque structure. There is a front door on the right side. A cargo door is installed aft of the rear seat.

The wing is of a conventional design semi-tapered and employs a laminar flow NACA 65₂-415 airfoil section. The main spar is located at approximately 40% of the chord aft of the leading edge. The wings are attached to the fuselage by the insertion of the butt ends of the spar into a spar box carry-through, which is an integral part of the fuselage structure. The bolting of the spar ends into the spar box carry-through structure, which is located under the aft seats, provides in effect a continuous main spar. The wings are also attached fore and aft of the main spar by an auxiliary front spar and a rear spar. The rear spar, in addition to taking torque and drag loads, provides a mount for flaps and ailerons. The four-position wing flaps are mechanically controlled by a handle located between the front seats. When fully retracted, the right flap locks into place to provide a step for cabin entry. Each wing contains one fuel tank.

A vertical stabilizer, an all-movable horizontal stabilator, and a rudder make up the empennage. The stabilator incorporates an anti-servo tab which improves longitudinal stability and provides longitudinal trim. This tab moves in the same direction as the stabilator, but with increased travel.

THIS PAGE INTENTIONALLY LEFT BLANK

7.5 ENGINE AND PROPELLER

The Turbo Arrow III is powered by a Teledyne Continental TSIO-360-F engine. It is a six cylinder, horizontally opposed, fuel injected, turbocharged engine, rated at 200 horsepower at 2575 RPM and 41 inches MAP from sea level to 12,000 feet density altitude. It is equipped with an oil cooler with a low temperature bypass system and engine mounted oil filter. A winterization plate is provided to restrict air during winter operation. (See Winterization in Handling and Servicing Section.) The turbocharger control system is a fixed, ground adjustable orifice ("fixed wastegate"), and is adjusted to provide 41 inches MAP at full throttle at 12,000 feet density altitude. Throttle position controls engine power and no separate turbocharge control system is utilized. An overboost valve prevents manifold pressure from exceeding 42 inches Hg, should the throttle inadvertently be opened too far below 12,000 feet density altitude. Should this occur, the amber "overboost" warning light in the annunciator panel will illuminate.

The engine induction system is provided with two independent air sources, an induction air filter box with filter, and interconnecting ducting. The primary air inlet is located above No. 1 cylinder (right rear) in the engine rear baffle. Induction air enters at this point and is ducted to the induction filter box, thru the filter and is further ducted to the turbocharger compressor inlet. The induction air filter box incorporates an alternate air valve. This valve may be manually operated (opened) with the alternate air control, allowing air to bypass the filter, supplying heated air directly to the compressor inlet. Should the primary air source become blocked, the alternate air valve will open automatically due to the sucking action of the turbocharger compressor. The heated air provided by the alternate air source will protect against induction system blockage caused by snow or freezing rain, or by the freezing of moisture accumulated in the induction air filter. The alternate air is unfiltered and therefore should not be used during ground operation when dust or other contaminants might enter the system. The primary (filtered air) induction source should always be used for takeoff.


A RayJay turbocharger on the engine is operated by the engine exhaust gases. The exhaust gases drive a turbine wheel which is coaxial with a compressor wheel. Induction air entering the compressor wheel is compressed and delivered to the engine induction distribution system and hence to each cylinder. The amount of induction air compression is a function of engine power - low power, low compression; high power, higher compression. Any excessive pressure (and flow) is expelled by the overboost valve discussed previously.

The fuel injection system incorporates a metering system which measures the rate at which turbocharged air is being used by the engine and dispenses fuel to the cylinders proportionally. Fuel is supplied to the injector pump at a greater rate than the engine requires. The fuel injection system is a "continuous flow" type.

A combination fuel flow indicator and manifold pressure gauge is installed in the left side of the instrument panel. The fuel flow indicator is connected to the fuel flow divider and monitors fuel pressure. The instrument converts fuel pressure to an approximate indication of fuel flow in gallons per hour and percentage of cruise power.

To obtain maximum efficiency and time from the TSIO-360-F engines, follow the procedures recommended in the Teledyne Continental Operator's Manual provided with the airplane.

The Hartzell constant speed propeller is controlled by a governor mounted on the left forward side of the crankcase. The governor is controlled by a cable from the power control quadrant.



CONTROL QUADRANT AND CONSOLE

Figure 7-1

7.7 ENGINE CONTROLS

Engine controls consist of a throttle control, a propeller control and a mixture control lever. These controls are located on the control quadrant on the lower center of the instrument panel (Figure 7-1) where they are accessible to both the pilot and the copilot. The controls utilize teflon-lined control cables to reduce friction and binding.


The throttle lever is used to adjust the manifold pressure. It incorporates a gear up warning horn switch which is activated during the last portion of travel of the throttle levers to the low power position. If the landing gear is not locked down, the horn will sound until the gear is down and locked or until the power setting is increased. This is a safety feature to prevent an inadvertent gear up landing.

The propeller control lever is used to adjust the propeller speed from high RPM to low RPM.

The mixture control lever is used to adjust the air to fuel ratio. The engine is shut down by the placing of the mixture control lever in the full lean position. In addition, the mixture control has a lock to prevent activation of the mixture control instead of the pitch control. For information on the leaning procedure, see the Continental Operator's Manual.

The friction adjustment lever on the right side of the control quadrant may be adjusted to increase or decrease the friction holding the throttle, propeller, and mixture controls or to lock the controls in a selected position.

The alternate air control is located to the right of the control quadrant. When the alternate air lever is in the up, or closed, position the engine is operating on filtered air; when the lever is in the down, or open, position the engine is operating on unfiltered, heated air (refer to Figure 7-1).



LANDING GEAR SELECTOR

Figure 7-3

7.9 LANDING GEAR

The Cherokee Turbo Arrow III is equipped with a retractable tricycle landing gear, which is hydraulically actuated by an electrically powered reversible pump. The pump is controlled by a selector switch on the instrument panel to the left of the control quadrant (Figure 7-3). The landing gear is retracted or extended in about seven seconds.

Also incorporated in the system is a pressure sensing device which lowers the gear regardless of gear selector position, depending upon airspeed and engine power (propeller slipstream). Gear extension is designed to occur, even if the selector is in the up position, at airspeeds below approximately 103 KIAS with power off.

The extension speeds will vary from approximately 78 KTS to approximately 103 KIAS depending on power settings and altitude. The device also prevents the gear from retracting at airspeeds below approximately 78 KTS with full power, though the selector switch may be in the up position. This speed increases with reduced power and/or increased altitude. Manual override of the device is provided by an emergency gear lever located between the front seats to the right of the flap handle (refer to Figure 7-9). The sensing device operation is controlled by differential air pressure across a flexible diaphragm which is mechanically linked to a hydraulic valve and an electrical switch which actuates the pump motor. A high pressure and static air source for actuating the diaphragm is provided in a mast mounted on the left side of the fuselage above the wing. Any obstruction of the holes in this mast will cause the gear to extend. An optional heated mast is available to alleviate obstruction in icing conditions. The optional heated mast is turned on whenever the "PITOT HEAT" is turned on.

WARNING

Avoid ejecting objects out of the pilot storm window which could possibly enter or obstruct the holes in the mast.

The emergency gear lever, used for emergency extension of the gear, manually releases hydraulic pressure to permit the gear to free-fall with spring assistance on the nose gear. The lever must be held in the downward position for emergency extension. This same lever, when placed in the raised position, can be used to override the system, and gear position is then controlled by the selector switch regardless of airspeed/power combinations. The emergency gear lever is provided with a locking device which may be used to lock the override lever in the up position. The lock is located on the right side panel of the console below the level of the manual override lever. To lock the override lever in the up position, raise the override lever to the full up position and push the pin in. A yellow warning light located below the gear selector switch (Figure 7-3) flashes to warn the pilot that the automatic gear lowering system is disabled. The lock is spring-loaded to the off position to aid disengagement. To disengage the lock raise the override lever and release. The lever will return to its normal position and the yellow flashing light will extinguish. The lever must also be locked in the raised (up) position when gear-up stalls are practiced.

Gear down and locked positions are indicated by three green lights located below the selector, and a red "Warning Gear Unsafe" light is located at the top of the panel. An all lights out condition indicates the gear is up. The landing gear should not be retracted above a speed of 107 KIAS and should not be extended above a speed of 129 KIAS.

The main landing gear uses 6.00 x 6 wheels. The main gear incorporate brake drums and Cleveland single disc hydraulic brake assemblies. The nose wheel carries a 5.00 x 5 four ply tire and the main gear use 6.00 x 6 six ply tires. All three tires are tube type.

A micro-switch in the throttle quadrant activates a warning horn and red "Warning Gear Unsafe" light under the following conditions:


- (a) Gear up and power reduced below approximately 14 inches of manifold pressure.
- (b) Gear extended by back-up gear extender system but gear selector switch "UP," power reduced below approximately 14 inches of manifold pressure.
- (c) Gear selector switch "UP" while on the ground and throttle in retarded position.

The gear warning horn emits a 90 cycle per minute beeping sound in contrast to the stall warning horn which emits a continuous sound.

The nose gear is steerable through a 30 degree arc each side of center through the use of the rudder pedals. As the nose wheel retracts, the steering linkage disengages to reduce rudder pedal loads in flight. The nose wheel is equipped with a hydraulic shimmy dampener to reduce nose wheel shimmy. A bungee assembly is also included to reduce ground steering effort and to dampen shocks and bumps during taxiing.


The oleo struts are of the air-oil type, with normal extension being $2.75 \pm .25$ inches for the nose gear and $2.25 \pm .25$ inches for the main gear under normal static load (empty weight of airplane plus full fuel and oil).

The standard brake system includes toe brakes on the left and right set of rudder pedals and a hand brake located below and near the center of the instrument panel. The toe brakes and the hand brake have individual brake cylinders, but all cylinders use a common reservoir. The parking brake is incorporated in the lever brake and is operated by pulling back on the lever and depressing the knob attached to the top of the handle. To release the parking brake, pull back on the brake lever; then allow the handle to swing forward.




LANDING GEAR ELECTRICAL SCHEMATIC

Figure 7-5



LANDING GEAR HYDRAULIC SCHEMATIC

Figure 7-7



FLIGHT CONTROL CONSOLE

Figure 7-9

7.11 FLIGHT CONTROLS

Dual flight controls are provided as standard equipment. A cable system provides actuation of the control surfaces when the flight controls are moved in their respective directions.

The horizontal surface (stabilator) is of the flying tail design with a trim tab/servo mounted on the trailing edge. This tab serves the dual function of providing trim control and pitch control forces. The trim function is controlled by a trim control wheel located on the control console between the two front seats (Figure 7-9). Rotating the wheel forward gives nose down trim and rotation aft gives nose up trim.


The rudder is conventional in design and incorporates a rudder trim. The trim mechanism is a spring-loaded recentering device. The trim control is located on the right side of the pedestal below the throttle quadrant. Turning the trim control clockwise gives nose right trim and counterclockwise rotation gives nose left trim.

Manually controlled flaps are provided. They are extended by a control cable and are spring-loaded to the retracted (up) position. The control is located between the two front seats on the control console. To extend the flaps pull the handle up to the desired flap setting of 10, 25 or 40 degrees. To retract, depress the button on the end of the handle and lower the control.

When extending or retracting flaps, there is a pitch change in the aircraft. This pitch change can be corrected either by stabilator trim or increased control wheel force. When the flaps are in the retracted position the right flap, provided with a over-center lock mechanism, acts as a step.


NOTE

The right flap will support a load only in the fully retracted (up) position. When loading and unloading passengers make sure the flaps are in the retracted (up) position.



FUEL SYSTEM SCHEMATIC

Figure 7-11



FUEL SELECTOR

Figure 7-13

7.13 FUEL SYSTEM

The fuel system was designed with simplicity in mind. It incorporates two fuel tanks, one in each wing containing 38.5 U.S. Gallons, giving a total capacity of 77 gallons, of which 72 gallons are usable. The minimum fuel grade is 100/130 octane (green) or 100LL (blue). The tanks are attached to the leading edge of the wing with screws and are an integral part of the wing structure. This allows removal for service. The tanks are vented individually by a vent tube which protrudes below the bottom of the wing at the rear inboard corner of each tank. The vents should be checked periodically to ascertain that the vent is not obstructed and will allow free passage of air.

Each fuel tank has an individual quick drain located at the bottom inboard rear corner. The fuel strainer also incorporates a quick drain, which is located on the left lower portion of the firewall. The quick drain protrudes thru the cowling to allow easy draining of the fuel strainer. To avoid the accumulation of water and sediment, the fuel tank sumps and strainer should be drained daily prior to first flight and after refueling.

CAUTION

When draining fuel, care should be taken to ensure that no fire hazard exists before starting the engine.

A fuel tank selector allows the pilot to control the flow of fuel to the engine, and is located on the left side wall below the instrument panel. It has three positions: OFF, LEFT TANK and RIGHT TANK. The arrow on the handle of the selector points to the tank which is supplying fuel to the engine. The vapor return from the engine is also routed back to the tank selected. When the selector valve is in the OFF position, vapor return is routed back to the right fuel tank. The valve also incorporates a safety latch which prevents inadvertently selecting the "OFF" position.

The engine fuel injection system is a "continuous flow" type, which utilizes a vapor return line leading back to the fuel tanks. This line provides a route back to the tanks for vapor laden fuel that has been separated in the injector pump swirl chamber. The engine has an engine driven fuel pump that is a part of the fuel injection system. An auxiliary fuel pump is also provided. The purpose of the electrically powered auxiliary fuel pump is to supply fuel to the engine in case of engine driven fuel pump shaft failure or malfunction, for ground and inflight engine starting, and for vapor suppression. The auxiliary fuel pump switch is located on the instrument panel above the engine control quadrant, and is a three position rocker switch; LO, HI and OFF. The LO auxiliary fuel pressure is selected by pushing the top of the switch. The HI auxiliary fuel pressure is selected by pushing the bottom of the switch, but this can be done only after unlatching the adjacent guard. When the HI auxiliary fuel pump is activated, an amber light near the annunciation panel is illuminated. This light dims whenever the pump pressure reduces automatically and manifold pressure is below approximately 21 inches.

In case of a failed engine-driven fuel pump, the auxiliary electric fuel pump should be set on HI. Adequate pressure and fuel flow will be supplied for up to approximately 75% power. Manual leaning to the correct fuel flow will be required at altitudes above 15,000 feet and for engine speeds less than 2300 RPM. An absolute pressure switch automatically selects a lower fuel pressure when the throttle is reduced below 21" Hg manifold pressure and the HI auxiliary fuel pump is on.

NOTE

Excessive fuel pressure and very rich fuel/air mixtures will occur if the HI position is energized when the engine fuel injection system is functioning normally.

Low auxiliary fuel pressure is available and may be used during normal engine operation both on the ground and inflight for vapor suppression should it be necessary as evidenced by unstable engine operation or fluctuating fuel flow indications during idle or at high altitudes.

A spring loaded OFF primer button switch is located on the instrument panel and is used to select HI auxiliary fuel pump operation for priming, irrespective of other switch positions. The primer button may be used for both hot or cold engine starts.

On airplanes equipped with an optional engine primer system (identified by Placard below primer button shown in Figure 7-21), the primer switch location and actuation is the same as the basic airplane. However, this system does provide a separate primer system as an integral part of the engine fuel system. An electrically operated diverter valve is located in the metered fuel supply line between the air throttle valve and the manifold valve. Other components are two primer nozzles, located in the intake manifold on each side of the engine, the interconnecting fuel lines, and fine wire spark plugs. Actuation of the engine primer switch operates the auxiliary electric fuel pump on HI and energizes the diverter valve which supplies fuel to each primer nozzle. The diverter valve does not shut off all fuel flow to the manifold valve, therefore some quantity of fuel is also supplied to each cylinder nozzle during priming. Operation of the auxiliary fuel pump on HI and LO is unchanged.

7.15 ELECTRICAL SYSTEM

All switches are grouped in a switch panel above the power quadrant. On the lower right side of the instrument panel is the circuit breaker panel, with each breaker clearly marked to show what circuit it protects. Also, circuit provisions are made to handle the addition of communications and navigational equipment.

Standard electrical accessories include alternator, starter, electric fuel pump, stall warning indicator, ammeter, and annunciator panel.

The annunciator panel includes alternator and low oil pressure indicator lights. When the optional gyro system is installed, the annunciator panel also includes a low vacuum indicator light. The annunciator panel lights are provided only as a warning to the pilot that a system may not be operating properly, and that he should check and monitor the applicable system gauge to determine when or if any necessary action is required.

Optional electrical accessories include navigation, anti-collision, landing, instrument and cabin dome lights. Navigation and radio lights are controlled by a rheostat switch on the left side of the switch panel. The instrument panel lights are controlled by a rheostat switch on the right side of the panel.

WARNING

When optional panel lights are installed, rheostat switch must be off to obtain gear lights full intensity during daytime flying. When aircraft is operated at night and panel light rheostat switch is turned on, gear lights and over boost light will automatically dim.

The anti-collision and landing lights are controlled by rocker switches on the switch panel.


NOTE

Anti-collision lights should not be operating when flying through overcast and clouds since reflected light can produce spacial disorientation. Do not operate strobe lights in close proximity to ground, during takeoff and landing.

The master switch, also located in the switch panel, is a split rocker switch. One side of the switch is the battery side ("BAT") and the other is the alternator side ("ALT"). Henceforth, "master switch," used in this manual, shall mean both "BAT" and "ALT" switches. The "ALT" switch is provided for an emergency and its function is covered under "Alternator Failure" in the Emergency section of the handbook.


The primary electrical power source is a 14-volt, 65-amp alternator, which is protected by a voltage regulator and an overvoltage relay. The alternator provides full electrical power output even at low engine RPM. This provides improved radio and electrical equipment operation and increases battery life by reducing battery load.

Secondary power is provided by a 12-volt, 25-ampere hour battery.



ALTERNATOR AND STARTER SCHEMATIC

Figure 7-15



CIRCUIT BREAKER PANEL

Figure 7-17

The ammeter as installed does not show battery discharge; rather it shows the electrical load placed on the system. With all the electrical equipment off, and the master switch on, the ammeter will indicate the charging rate of the battery. As each electrical unit is switched on, the ammeter will indicate the total ampere draw of all the units including the battery. For example, the maximum continuous load for night flying with radios on is about 30 amperes. The 30 ampere value plus 2 amperes for charging the battery will then show on the ammeter, indicating the alternator is functioning properly.

Solenoids, provided in the battery and starter circuits, are used to control high current drain functions remotely from the cabin.

7.17 VACUUM SYSTEM

The vacuum system is designed to operate the air driven gyro instruments. This includes the directional and attitude gyros when installed. The system consists of an engine vacuum pump, a vacuum regulator, a filter and the necessary plumbing.

The vacuum pump is a dry type pump which eliminates the need for an air/oil separator and its plumbing. A shear drive protects the engine from damage. If the drive shears the gyros will become inoperative.

The vacuum gauge, mounted on the right instrument panel to the right of the radios, (refer to Figure 7-21) provides valuable information to the pilot about the operation of the vacuum system. A decrease in pressure in a system that has remained constant over an extended period, may indicate a dirty filter, dirty screens, possibly a sticking vacuum regulator or leak in system (a low vacuum indicator light is provided in the annunciator panel). Zero pressure would indicate a sheared pump drive, defective pump, possibly a defective gauge or collapsed line. In the event of any gauge variation from the norm, the pilot should have a mechanic check the system to prevent possible damage to the system components or eventual failure of the system.

A vacuum regulator is provided in the system to protect the gyros. The valve is set so the normal vacuum reads 4.8 to 5.1 inches of mercury, a setting which provides sufficient vacuum to operate all the gyros at their rated RPM. Higher settings will damage the gyros and with a low setting the gyros will be unreliable. The regulator is located behind the instrument panel.

7.19. PITOT-STATIC SYSTEM

The system supplies both pitot and static pressure for the airspeed indicator, altimeter and vertical speed indicator (when installed).


Pitot pressure is picked up by the pitot head on the bottom of the left wing. An optional heated pitot head, which alleviates problems with icing or heavy rain, is available. The switch for pitot heat is located on the switch panel to the pilot's left. The static pressure is sensed by static buttons on each side of the aft fuselage.

An alternate static source is available as optional equipment. The control valve is located below the left side of the instrument panel. When the valve is set in the alternate position, the altimeter, vertical speed indicator and airspeed indicator will be using cabin air for static pressure. The storm window and cabin vents must be closed and the cabin heater and defroster must be on during alternate static source operation. The altimeter error is less than 50 feet unless otherwise placarded.

To prevent bugs and water from entering the pitot pressure holes when the airplane is parked, a cover should be placed over the pitot head. A partially or completely blocked pitot head will give erratic or zero readings on the instruments.


NOTE

During preflight, check to make sure the pitot cover is removed.



PITOT-STATIC SYSTEM

Figure 7-19



- | | | |
|---|--|---|
| <ul style="list-style-type: none"> 1. CLOCK 2. TURN COORDINATOR 3. AIRSPEED INDICATOR 4. WARNING - GEAR UNSAFE LIGHT 5. ATTITUDE GYRO 6. DIRECTIONAL GYRO 7. ALTIMETER 8. VERTICAL SPEED INDICATOR 9. ANNUNCIATOR DISPLAY 10. OMNI AND GLIDE SLOPE INDICATOR 11. OMNI INDICATOR 12. PRIMER BUTTON 13. AIR CONDITIONER DOOR LIGHT 14. COMPASS 15. AUDIO CONTROL PANEL | <ul style="list-style-type: none"> 16. COMMUNICATIONS TRANSCIVERS 17. TRANSPONDER 18. ADF 19. CLIMATE CONTROL CENTER 20. GYRO SUCTION GAUGE 21. CIGAR LIGHTER 22. MIKE JACK 23. PHONE JACK 24. AUTOPILOT - AUTOCONTROL IIIB 25. CLUSTER GAUGES 26. OMNI COUPLER 27. NAV 1, NAV 2 SWITCH 28. ELECTRIC TRIM SWITCH 29. IGNITION SWITCH | <ul style="list-style-type: none"> 30. MANIFOLD PRESSURE/ FUEL FLOW GAUGE 31. CLUSTER GAUGE 32. TACHOMETER 33. GEAR SELECTOR SWITCH 34. GEAR INDICATOR LIGHTS 35. CONTROL QUADRANT 36. MIKE ATTACHMENT 37. MIXTURE CONTROL LOCK 38. FRICTION LOCK 39. ALTERNATE AIR 40. CONTROL SWITCHES 41. EGT 42. CIRCUIT BREAKER PANEL |
|---|--|---|

INSTRUMENT PANEL

Figure 7-21

7.21 INSTRUMENT PANEL

The instrument panel of the Cherokee Turbo Arrow III is designed to accommodate the customary advanced flight instruments and the normally required power plant instruments. The artificial horizon and directional gyro are vacuum operated and are located in the center of the left hand instrument panel. The vacuum gauge is located on the right hand instrument panel. The turn indicator, on the left side, is electrically operated.


The radios are located in the center section of the panel, and the circuit breakers are in the lower right corner of the panel.

An annunciator panel is mounted in the upper instrument panel to warn the pilot of a possible malfunction in the alternator, oil pressure, vacuum systems, and over boost light.

The manifold pressure line has a drain valve located behind and below the manifold pressure gauge. This allows any moisture which may have collected from condensation to be pulled into the engine. This is accomplished by depressing the valve for 5 seconds while operating the engine at 1000 RPM.

NOTE

Do not depress the valve when manifold pressure exceeds 25 inches Hg.



CABIN DOOR LATCH

Figure 7-23

7.23 CABIN FEATURES

The interior has been designed for passenger comfort and safety. All seat backs have three positions: normal, intermediate and recline. The adjustment lever is located at the base of the seat back on the outboard side of the seat. The front seats adjust fore and aft for ease of entry and occupant comfort. An armrest is located on the side panels adjacent to the front seat. The rear seats are easily removed to provide room for bulky items. Rear seat installations incorporate leg retainers with latching mechanisms which must be released before the rear seats can be removed. Releasing the retainers is accomplished on earlier models by turning the latching mechanisms 90° with a coin or screwdriver. Releasing the retainers is accomplished on later models by depressing the plunger behind each rear leg. Optional headrests are available.

A single strap shoulder harness controlled by an inertial reel, located above the side window, protects each front seat occupant. Optional shoulder straps for the rear occupants are available. The shoulder strap is routed over the shoulder adjacent to the window and attached to the lap belt in the general area of the occupant's inboard hip. A check of the inertia reel mechanism can be made by pulling sharply on the strap and checking that the reel will lock in place under sudden stress; this locking feature prevents the strap from extending and holds the occupant in place. Under normal movement the strap will extend and retract as required. Shoulder harnesses should be routinely worn during takeoff, landing and whenever an inflight emergency situation occurs.

Additional features include pilot storm window, two sun visors, ashtrays for each occupant, map pockets located on the side panels below the instrument panel, miscellaneous pockets on the rear of the front seat backs, armrests for the front occupants, cabin or baggage door locks and ignition lock.


The cabin door is double latched. To close the cabin door, hold the door closed with the arm set while moving the side door latch to the "LATCHED" position. Then engage the top latch. Both latches must be secured before flight.

7.25 BAGGAGE AREA

A large baggage area, located behind the rear seats, is accessible either from the cabin or through a large outside baggage door on the right side of the aircraft. Maximum capacity is 200 lbs. Tie-down straps are provided and should be used at all times.

NOTE

It is the pilot's responsibility to be sure when the baggage is loaded that the aircraft C.G. falls within the allowable C.G. Range. (See Weight and Balance Section.)



HEATING, VENTILATING AND DEFROSTING SYSTEM
Figure 7-25

7.27 HEATING, VENTILATING AND DEFROSTING SYSTEM

The heating system is designed to provide maximum comfort for the occupants during winter and cool weather flights. The system includes a heat shroud, heat ducts, defroster outlets, heat and defroster controls.

An opening in the front of the lower cowl admits ram air to the heater shroud and then the air is ducted to the heater shut-offs on the right and left side of the firewall. When the shut-offs are opened the heated air then enters the heat ducts located along each side of the center console. Outlets in the heat duct are located at each seat location. Air flow to the rear seats can be regulated by controls in the heat ducts located between the front seats. The temperature of the cabin is regulated by the heater control located on the right side of the instrument panel.

Defrosting is accomplished by heat outlets located on the right and left side of the cowl cover. Heated air is ducted directly to defroster shut-off valves at the firewall, then to the defroster outlets. The air flow is regulated by a defroster control located below the heat control.

To aid air distribution, the cabin air is exhausted overboard by an outlet located on the bottom of the fuselage. Cabin exhaust outlets are located below and outboard of the rear seats. The above features are removed when air conditioning is installed.

Optional individual overhead fresh air outlets supply fresh air from an air inlet located on the tip of the vertical fin. The air is directed to a plenum chamber at the base of the fin, then ducted to the individual outlets. For individual comfort, the amount and direction of air can be regulated to control the amount of air and direction of desired airflow. An optional blower is available which forces outside air through the overhead vents for ground use. The blower is operated by a "FAN" switch with 4 positions - "OFF," "LOW," "MED," or "HIGH."

7.29 STALL WARNING

An approaching stall is indicated by a stall warning horn which is activated between five and ten knots above stall speed. Mild airframe buffeting and gentle pitching may also precede the stall. Stall speeds are shown on graphs in the Performance Section. The stall warning horn emits a continuous sound. The landing gear warning horn is different in that it emits a 90 cycle per minute beeping sound. The stall warning horn is activated by a lift detector installed on the leading edge of the left wing. During preflight, the stall warning system should be checked by turning the master switch "ON," lifting the detector and checking to determine if the horn is actuated.

7.31 FINISH

All exterior surfaces are primed with etching primer and finished with acrylic lacquer. To keep the finish attractive looking, economy size spray cans of touch-up paint are available from Piper Dealers.

7.33 AIR CONDITIONING*

The air conditioning system is a recirculating air system. The major components include an evaporator, a condenser, a compressor, a blower, switches and temperature controls.

The evaporator is located behind the rear baggage compartment. This cools the air used for the air conditioning system.

The condenser is mounted on a retractable scoop located on the bottom of the fuselage and to the rear of the baggage compartment area. The scoop extends when the air conditioner is ON and retracts to a flush position when the system is OFF.

The compressor is mounted on the rear left side of the engine. It has an electric clutch which automatically engages or disengages the compressor to the belt drive system of the compressor.

Air from the baggage area is drawn through the evaporator by the blower and distributed through an overhead duct to individual outlets located adjacent to each occupant.

The switches and temperature control are located on the lower right side of the instrument panel in the climate control center panel. The temperature control regulates the temperature of the cabin. Turning the control clockwise increases cooling; counterclockwise decreases cooling.

The fan speed switch and the air conditioning ON-OFF switch are inboard of the temperature control. The fan can be operated independently of the air conditioning; however, the fan must be on for air conditioner operation. Turning either switch off will disengage the compressor clutch and retract the condenser door. Cooling air should be felt within one minute after the air conditioner is turned on.

NOTE

If the system is not operating in 5 minutes, turn the system OFF until the fault is corrected.

The fan switch allows operation of the fan with the air conditioner turned OFF to aid in cabin air circulation. "LOW," "MED" or "HIGH" can be selected to direct a flow of air through the air conditioner outlets in the overhead duct. These outlets can be adjusted or turned off individually.

The condenser door light is located to the right of the engine instrument cluster in front of the pilot. The door light illuminates when the door is open and is off when the door is closed.

A circuit breaker on the circuit breaker panel protects the air conditioning electrical system.

Whenever 38 inches Hg or more manifold pressure is used a manifold pressure switch disengages the compressor and retracts the scoop. This allows maximum power and maximum rate of climb. The fan continues to operate and the air will remain cool for about one minute. When the throttle is retarded so that less than 38 inches Hg manifold pressure is used, the clutch will engage, the scoop will extend, and the system will again supply cool, dry air.

*Optional equipment

7.35 PIPER EXTERNAL POWER*

An optional starting installation known as Piper External Power (PEP) is accessible through a receptacle located on the right side of the fuselage aft of the wing. An external battery can be connected to the socket, thus allowing the operator to crank the engine without having to gain access to the airplane's battery.

7.37 EMERGENCY LOCATOR TRANSMITTER*

The Emergency Locator Transmitter (ELT) when installed, is located in the aft portion of the fuselage just below the stabilator leading edge and is accessible through a plate on the right side of the fuselage. This plate is attached with three slotted-head nylon screws for ease of removal; these screws may be readily removed with a variety of common items such as a dime, a key, a knife blade, etc. If there are no tools available in an emergency the screw heads may be broken off by any means. The ELT is an emergency locator transmitter which meets the requirements of FAR 91.52. It is automatically activated by a longitudinal force of 5 g's and transmits a distress signal on both 121.5 MHz and 243.0 MHz for a period of from 48 hours in low temperature areas up to 100 hours in high temperature areas. The unit operates on a self-contained battery.

The battery has a useful life of 10 years. However, to comply with FAA regulations it must be replaced after 5 years of shelf life or service life. The battery should also be replaced if the transmitter has been used in an emergency situation or if accumulated test time exceeds one hour. The replacement date is marked on the transmitter label.

On the unit itself is a three position selector switch placarded "OFF," "ARM" and "ON." The "ARM" position is provided to set the unit to the automatic position so that it will transmit only after impact and will continue to transmit until the battery is drained to depletion or until the switch is manually moved to the "OFF" position. The "ARM" position is selected when the transmitter is installed at the factory and the switch should remain in that position whenever the unit is installed in the airplane. The "ON" position is provided so the unit can be used as a portable transmitter or in the event the automatic feature was not triggered by impact or to periodically test the function of the transmitter.

Select the "OFF" position when changing the battery, when rearming the unit if it has been activated for any reason, or to discontinue transmission.

NOTE

If the switch has been placed in the "ON" position for any reason, the "OFF" position has to be selected before selecting "ARM." If "ARM" is selected directly from the "ON" position, the unit will continue to transmit in the "ARM" position.

A pilot's remote switch, located on the left side panel, is provided to allow the transmitter to be controlled from inside the cabin. The pilot's remote switch is placarded "ON, AUTO/ARM and OFF/RESET." The switch is normally left in the "AUTO/ARM" position. To turn the transmitter off, move the switch momentarily to the "OFF/RESET" position. The aircraft master switch must be "ON" to turn the transmitter "OFF." To actuate the transmitter for tests or other reasons, move the switch upward to the "ON" position and leave it in that position as long as transmission is desired.

*Optional equipment

The unit is equipped with a portable antenna to allow the locator to be removed from the airplane in case of an emergency and used as a portable signal transmitter.

The locator should be checked during the ground check to make certain the unit has not been accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating sound, the locator may have been activated and should be turned off immediately. Reset to the "ARM" position and check again to insure against outside interference.

NOTE

If for any reason a test transmission is necessary, the test transmission should be conducted only in the first five minutes of any hour and limited to three audio sweeps. If tests must be made at any other time, the tests should be coordinated with the nearest FAA tower or flight service station.

TABLE OF CONTENTS

SECTION 8

AIRPLANE HANDLING, SERVICING AND MAINTENANCE

Paragraph No.		Page No.
8.1	General	8-1
8.3	Airplane Inspection Periods	8-3
8.5	Preventive Maintenance	8-4
8.7	Airplane Alterations	8-5
8.9	Ground Handling	8-6
8.11	Engine Air Filter	8-8
8.13	Brake Service	8-8
8.15	Landing Gear Service	8-10
8.17	Propeller Service	8-10
8.19	Oil Requirements	8-11
8.21	Fuel System	8-11
8.23	Tire Inflation	8-12
8.25	Battery Service	8-13
8.27	Cleaning	8-13
8.29	Winterization	8-15

SECTION 8

AIRPLANE HANDLING, SERVICING AND MAINTENANCE

8.1 GENERAL

This section provides general guidelines relating to the handling, servicing and maintenance of the Cherokee Turbo Arrow III.

Every owner should stay in close contact with his Piper dealer or distributor and Authorized Piper Service Center to obtain the latest information pertaining to his aircraft and to avail himself of the Piper Aircraft Service Back-up.

Piper Aircraft Corporation takes a continuing interest in having the owner get the most efficient use from his aircraft and keeping it in the best mechanical condition. Consequently, Piper Aircraft from time to time issues Service Bulletins, Service Letters and Service Spares Letters relating to the aircraft.

Service Bulletins are of special importance and should be complied with promptly. These are sent to the latest registered owners, distributors and dealers. Depending on the nature of the bulletin, material and labor allowances may apply, and will be addressed in the body of the Bulletin.

Service Letters deal with product improvements and service hints pertaining to the aircraft. They are sent to dealers, distributors and occasionally (at the factory's discretion) to latest registered owners, so they can properly service the aircraft and keep it up to date with the latest changes. Owners should give careful attention to the Service Letter information.

Service Spares Letters offer improved parts, kits and optional equipment which were not available originally and which may be of interest to the owner.

If an owner is not having his aircraft serviced by an Authorized Piper Service Center, he should periodically check with a Piper dealer or distributor to find out the latest information to keep his aircraft up to date.

Piper Aircraft Corporation has a Subscription Service for the Service Bulletins, Service Letters and Service Spares Letters. This service is offered to interested persons such as owners, pilots and mechanics at a nominal fee, and may be obtained through Piper dealers and distributors.

A service manual, parts catalog, and revisions to both, are available from your Piper dealer or distributor. Any correspondence regarding the airplane should include the airplane model and serial number to insure proper response.

THIS PAGE INTENTIONALLY LEFT BLANK

8.3 AIRPLANE INSPECTION PERIODS

The Federal Aviation Administration (FAA) occasionally publishes Airworthiness Directives (ADs) that apply to specific groups of aircraft. They are mandatory changes and are to be complied with within a time limit set by the FAA. When an AD is issued, it is sent to the latest registered owner of the affected aircraft and also to subscribers of the service. The owner should periodically check with his Piper dealer or A & P mechanic to see whether he has the latest issued AD against his aircraft.

Piper Aircraft Corporation provides for the initial and first 50-hour inspection, at no charge to the owner. The Owner Service Agreement which the owner receives upon delivery of the aircraft should be kept in the aircraft at all times. This identifies him to authorized Piper dealers and entitles the owner to receive service in accordance with the regular service agreement terms. This agreement also entitles the transient owner full warranty by any Piper dealer in the world.

One hundred hour inspections are required by law if the aircraft is used commercially. Otherwise this inspection is left to the discretion of the owner. This inspection is a complete check of the aircraft and its systems, and should be accomplished by a Piper Authorized Service Center or by a qualified aircraft and power plant mechanic who owns or works for a reputable repair shop. The inspection is listed, in detail, in the inspection report of the appropriate Service Manual.

An annual inspection is required once a year to keep the Airworthiness Certificate in effect. It is the same as a 100-hour inspection except that it must be signed by an Inspection Authorized (IA) mechanic or a General Aviation District Office (GADO) representative. This inspection is required whether the aircraft is operated commercially or for pleasure.

A Progressive Maintenance program is approved by the FAA and is available to the owner. It involves routine and detailed inspections at 50-hour intervals. The purpose of the program is to allow maximum utilization of the aircraft, to reduce maintenance inspection cost and to maintain a maximum standard of continuous airworthiness. Complete details are available from Piper dealers.

A spectographic analysis of the oil is available from several sources. This system, if used intelligently, provides a good check of the internal condition of the engine. For this system to be accurate, oil samples must be sent in at regular intervals, and induction air filters must be cleaned or changed regularly.

8.5 PREVENTIVE MAINTENANCE

The holder of a Pilot Certificate issued under FAR Part 61 may perform certain preventive maintenance described in FAR Part 43. This maintenance may be performed only on an aircraft which the pilot owns or operates and which is not used in air carrier service. The following is a list of the maintenance which the pilot may perform:

- (a) Repair or change tires and tubes.
- (b) Service landing gear wheel bearings, such as cleaning, greasing or replacing.
- (c) Service landing gear shock struts by adding air, oil or both.
- (d) Replace defective safety wire and cotter keys.
- (e) Lubrication not requiring disassembly other than removal of non-structural items such as cover plates, cowling or fairings.
- (f) Replenish hydraulic fluid in the hydraulic reservoirs.
- (g) Refinish the exterior or interior of the aircraft (excluding balanced control surfaces) when removal or disassembly of any primary structure or operating system is not required.
- (h) Replace side windows and safety belts.
- (i) Replace seats or seat parts with replacement parts approved for the aircraft.
- (j) Replace bulbs, reflectors and lenses of position and landing lights.
- (k) Replace cowling not requiring removal of the propeller.
- (l) Replace, clean or set spark plug clearance.
- (m) Replace any hose connection, except hydraulic connections, with replacement hoses.
- (n) Replace prefabricated fuel lines.
- (o) Replace the battery and check fluid level and specific gravity.

Although the above work is allowed by law, each individual should make a self analysis as to whether he has the ability to perform the work.

If the above work is accomplished, an entry must be made in the appropriate logbook. The entry should contain:

- (a) The date the work was accomplished.
- (b) Description of the work.
- (c) Number of hours on the aircraft.
- (d) The certificate number of pilot performing the work.
- (e) Signature of the individual doing the work.

8.7 AIRPLANE ALTERATIONS

If the owner desires to have his aircraft modified, he must obtain FAA approval for the alteration. Major alterations accomplished in accordance with Advisory Circular 43.13-2, when performed by an A & P mechanic, may be approved by the local FAA office. Major alterations to the basic airframe or systems not covered by AC 43.13-2 require a Supplemental Type Certificate.

The owner or pilot is required to ascertain that the following Aircraft Papers are in order and in the aircraft.

- (a) To be displayed in the aircraft at all times:
 - (1) Aircraft Airworthiness Certificate Form FAA-8100-2.
 - (2) Aircraft Registration Certificate Form FAA-8050-3.
 - (3) Aircraft Radio Station License if transmitters are installed.

- (b) To be carried in the aircraft at all times:
 - (1) Pilot's Operating Handbook.
 - (2) Weight and Balance data plus a copy of the latest Repair and Alteration Form FAA-337, if applicable.
 - (3) Aircraft equipment list.

Although the aircraft and engine logbooks are not required to be in the aircraft, they should be made available upon request. Logbooks should be complete and up to date. Good records will reduce maintenance cost by giving the mechanic information about what has or has not been accomplished.

8.9 GROUND HANDLING

(a) Towing

The airplane may be moved on the ground by the use of the nose wheel steering bar that is stowed in the rear baggage compartment or by power equipment that will not damage or excessively strain the nose gear steering assembly. Towing lugs are incorporated as part of the nose gear fork.

CAUTION

When towing with power equipment, do not turn the nose gear beyond its steering radius in either direction, as this will result in damage to the nose gear and steering mechanism.

CAUTION

Do not tow the airplane when the controls are secured.

In the event towing lines are necessary, ropes should be attached to both main gear struts as high up on the tubes as possible. Lines should be long enough to clear the nose and/or tail by not less than fifteen feet, and a qualified person should ride in the pilot's seat to maintain control by use of the brakes.

(b) Taxiing

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Engine starting and shut-down procedures as well as taxi techniques should be covered. When it is ascertained that the propeller back blast and taxi areas are clear, power should be applied to start the taxi roll, and the following checks should be performed:

- (1) Taxi a few feet forward and apply the brakes to determine their effectiveness.
- (2) Taxi with the propeller set in low pitch, high RPM setting.
- (3) While taxiing, make slight turns to ascertain the effectiveness of the steering.
- (4) Observe wing clearance when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.
- (5) When taxiing over uneven ground, avoid holes and ruts.
- (6) Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel, or any loose material that may cause damage to the propeller blades.

(c) Parking

When parking the airplane, be sure that it is sufficiently protected from adverse weather conditions and that it presents no danger to other aircraft. When parking the airplane for any length of time or overnight, it is suggested that it be moored securely.

- (1) To park the airplane, head it into the wind if possible.
- (2) Set the parking brake by pulling back on the brake lever and depressing the knob on the handle. To release the parking brake, pull back on the handle until the catch disengages; then allow the handle to swing forward.

CAUTION

Care should be taken when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

- (3) Aileron and stabilator controls should be secured with the front seat belt and chocks used to properly block the wheels.

(d) Mooring

The airplane should be moored for immovability, security and protection. The following procedures should be used for the proper mooring of the airplane:

- (1) Head the airplane into the wind if possible.
- (2) Retract the flaps.
- (3) Immobilize the ailerons and stabilator by looping the seat belt through the control wheel and pulling it snug.
- (4) Block the wheels.
- (5) Secure tie-down ropes to the wing tie-down rings and to the tail skid at approximately 45 degree angles to the ground. When using rope of non-synthetic material, leave sufficient slack to avoid damage to the airplane should the ropes contract.

CAUTION

Use bowline knots, square knots or locked slip knots. Do not use plain slip knots.

NOTE

Additional preparations for high winds include using tie-down ropes from the landing gear forks and securing the rudder.

- (6) Install a pitot head cover if available. Be sure to remove the pitot head cover before flight.
- (7) Cabin and baggage doors should be locked when the airplane is unattended.

8.11 ENGINE AIR FILTER

(a) Removing Engine Air Filter

- (1) Remove the upper cowl.
- (2) Remove the wing nuts securing the filter box cover. Remove the filter.

(b) Cleaning Engine Air Filter

The induction air filter must be cleaned at least once every 50 hours, and more often, even daily, when operating in dusty conditions. Extra filters are inexpensive, and a spare should be kept on hand for use as a rapid replacement.

To clean the filter:

- (1) Tap the filter gently to remove dirt particles, being careful not to damage the filter. DO NOT wash the filter in any liquid. DO NOT attempt to blow out dirt with compressed air.
- (2) If the filter is excessively dirty or shows any damage, replace it immediately.
- (3) Wipe the filter housing with a clean cloth soaked in unleaded gasoline. When the housing is clean and dry, install the filter.


(c) Installation Of Engine Air Filter

After cleaning or when replacing the filter, install the filter in the reverse order of removal.

8.13 BRAKE SERVICE

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic brake fluid. The fluid level should be checked periodically or at every 100 hour inspection and replenished when necessary. The brake reservoir is located on the left side of the fire wall in the engine compartment. If the entire system must be refilled, fill with fluid under pressure from the brake end of the system. This will eliminate air from the system.

No adjustment of the brake clearances is necessary. If after extended service brake blocks become excessively worn, they should be replaced with new segments.



BRAKE SYSTEM

Figure 8-1

8.15 LANDING GEAR SERVICE

The main landing gear uses 6.00 x 6 wheels with 6.00 x 6, six-ply rating tires and tubes. The nose wheel uses a 5.00 x 5 wheel with a 5.00 x 5 four-ply rating, type III tire and tube. (Refer to Paragraph 8.23.)

Wheels are removed by taking off the hub cap, cotter pin, axle nut, and the two bolts holding the brake segment in place. Mark tire and wheel for reinstallation; then dismount by deflating the tire, removing the three through-bolts from the wheel and separating the wheel halves.

Landing gear oleos on the Cherokee Turbo Arrow III should be serviced according to the instructions on the units. The main oleos should be extended under normal static load until $2.5 \pm .25$ inches of oleo piston tube is exposed, and the nose gear should show $2.75 \pm .25$ inches. To add air to the oleo struts, attach a strut pump to the valve assembly near the top of the oleo strut housing and pump the oleo to the desired position. To add oil, jack the aircraft, release the air pressure in the strut, remove the valve core and add oil through this opening with the strut extended. After the strut is full, compress it slowly and fully to allow excess air and oil to escape. With the strut still compressed reinsert the valve stem and pump up the strut as above.

In jacking the aircraft for landing gear or other service, two hydraulic jacks and a tail stand should be used. At least 250 pounds of ballast should be placed on the base of the tail stand before the airplane is jacked up. The hydraulic jacks should be placed under the jack points on the bottom of the wing and the airplane jacked up until the tail skid is at the right height to attach the tail stand. After the tail stand is attached and the ballast added, jacking may be continued until the airplane is at the height desired.

The steering arms from the rudder pedals to the nose wheel are adjusted at the rudder pedals or at the nose wheel by turning the threaded rod end bearings in or out. Adjustment is normally accomplished at the forward end of the rods and should be done in such a way that the nose wheel is in line with the fore and aft axis of the plane when the rudder pedals and rudder are centered. Alignment of the nose wheel can be checked by pushing the airplane back and forth with the rudder centered to determine that the plane follows a perfectly straight line. The turning arc of the nose wheel is 30° in either direction and is factory adjusted at stops on the bottom of the forging. The steering arm stops should be carefully adjusted so that the nose wheel reaches its full travel just after the rudder hits its stops. This guarantees that the rudder will be allowed to move through its full travel.

8.17 PROPELLER SERVICE

The spinner and backing plate should be cleaned and inspected for cracks frequently. Before each flight the propeller should be inspected for nicks, scratches, and corrosion. If found, they should be repaired as soon as possible by a rated mechanic, since a nick or scratch causes an area of increased stress which can lead to serious cracks or the loss of a propeller tip. The back face of the blades should be painted when necessary with flat black paint to retard glare. To prevent corrosion, the surface should be cleaned and waxed periodically.

8.19 OIL REQUIREMENTS

The oil capacity of the Continental TSIO-360-F engine is 8 quarts, and the minimum safe quantity is 3 quarts. It is recommended that the oil be changed every 50 hours and sooner under unfavorable operating conditions. The following grades are recommended for the specified temperatures:

Average Ambient Air Temperature For Starting	Oil Specification	Single Viscosity Grade	Multi-Viscosity Grades
Above 40°F	MHS-24A	SAE 50	See TCM Operator's Manual
Below 40°F	MHS-24A	SAE 30	

8.21 FUEL SYSTEM

(a) Servicing Fuel System

At every 50 hour inspection, the fuel screen in the strainer must be cleaned. The fuel strainer is located on the forward left lower side of the fire wall. It is accessible by removing the lower cowling. After cleaning, a small amount of grease applied to the gasket will facilitate reassembly.

(b) Fuel Requirements

Aviation grade fuel with a minimum octane of 100/130 or 100LL must be used in this airplane. Since the use of lower grades can cause serious engine damage in a short period of time, the engine warranty is invalidated by the use of lower octanes.


(c) Filling Fuel Tanks

Observe all safety precautions required when handling gasoline. Fill the fuel tanks through the filler located on the forward slope of the wing. Each wing holds a maximum of 38.5 U.S. gallons. When using less than the standard 77 gallon capacity, fuel should be distributed equally between each side.

(d) Draining Fuel Strainer, Sumps and Lines

The fuel strainer, located on the lower left side of the fire wall, is provided with a quick drain which should be drained before the first flight of the day or after refueling, to check for fuel contamination. If contamination is found, fuel should be drained until the contamination stops. If contamination persists after draining fuel for a minute, contact a mechanic to check the fuel system.

Each fuel tank is provided with a fuel quick drain to check for contamination. Each tank should be checked for contamination in accordance with the above procedure.



FUEL DRAIN

Figure 8-3

(e) Draining Fuel System

The bulk of the fuel may be drained from the fuel cells by the use of a siphon hose placed in the cell or tank through the filler neck. The remainder of the fuel may be drained by opening all the drain valves.

CAUTION

When draining fuel, be sure that no fire hazard exists before starting the engine.

8.23 TIRE INFLATION

For maximum service from the tires, keep them inflated to the proper pressure of 27 psi for nose tire and 30 psi for main tires. Interchange the tires periodically for even wear. All wheels and tires are balanced before original installation, and the relationship of tire, tube and wheel should be maintained upon reinstallation. In the installation of new components, it may be necessary to rebalance the wheels with the tires mounted. Unbalanced wheels can cause extreme vibration in the landing gear.

8.25 BATTERY SERVICE

Access to the 12-volt 25-ampere-hour battery is gained through the baggage compartment. It is located just aft of the baggage compartment. The battery container has a plastic drain tube which is normally closed off. This tube should be drained periodically to remove battery acid which may have collected in the tube.

The battery fluid level must not be brought above the baffle plates. It should be checked every 30 days to determine that the fluid level is proper and the connections are tight and free of corrosion.

If the battery is not properly charged, recharge it starting with a rate of four amperes and finishing with a rate of two amperes. The battery should be removed from the airplane for charging, and quick charges are not recommended.

The external power receptacle, if installed, is located on the right side of the fuselage aft of the baggage compartment door.

Refer to the Cherokee Turbo Arrow III Service Manual for battery servicing procedure.

8.27 CLEANING

(a) Cleaning Engine Compartment

Before cleaning the engine compartment, place a strip of tape on the magneto vents to prevent any solvent from entering these units.

- (1) Place a large pan under the engine to catch waste.
- (2) With the engine cowling removed, spray or brush the engine with solvent or a mixture of solvent and degreaser. In order to remove especially heavy dirt and grease deposits, it may be necessary to brush areas that were sprayed.

CAUTION

Do not spray solvent into the alternator, vacuum pump, starter, or air intakes.

- (3) Allow the solvent to remain on the engine from five to ten minutes. Then rinse the engine clean with additional solvent and allow it to dry.

CAUTION

Do not operate the engine until excess solvent has evaporated or otherwise been removed.

- (4) Remove the protective tape from the magnetos.
- (5) Lubricate the controls, bearing surfaces, etc., in accordance with the Lubrication Chart.

(b) Cleaning Landing Gear

Before cleaning the landing gear, place a plastic cover or similar material over the wheel and brake assembly.

- (1) Place a pan under the gear to catch waste.
- (2) Spray or brush the gear area with solvent or a mixture of solvent and degreaser, as desired. Where heavy grease and dirt deposits have collected, it may be necessary to brush areas that were sprayed, in order to clean them.
- (3) Allow the solvent to remain on the gear from five to ten minutes. Then rinse the gear with additional solvent and allow to dry.
- (4) Remove the cover from the wheel and remove the catch pan.
- (5) Lubricate the gear in accordance with the Lubrication Chart.
- (6) Caution: Do not brush the micro switches.

(c) Cleaning Exterior Surfaces

The airplane should be washed with a mild soap and water. Harsh abrasives or alkaline soaps or detergents could make scratches on painted or plastic surfaces or could cause corrosion of metal. Cover areas where cleaning solution could cause damage. To wash the airplane, use the following procedure:

- (1) Flush away loose dirt with water.
- (2) Apply cleaning solution with a soft cloth, a sponge or a soft bristle brush.
- (3) To remove exhaust stains, allow the solution to remain on the surface longer.
- (4) To remove stubborn oil and grease, use a cloth dampened with naphtha.
- (5) Rinse all surfaces thoroughly.
- (6) Any good automotive wax may be used to preserve painted surfaces. Soft cleaning cloths or a chamois should be used to prevent scratches when cleaning or polishing. A heavier coating of wax on the leading surfaces will reduce the abrasion problems in these areas.

(d) Cleaning Windshield and Windows

- (1) Remove dirt, mud and other loose particles from exterior surfaces with clean water.
- (2) Wash with mild soap and warm water or with aircraft plastic cleaner. Use a soft cloth or sponge in a straight back and forth motion. Do not rub harshly.
- (3) Remove oil and grease with a cloth moistened with kerosene.

CAUTION

Do not use gasoline, alcohol, benzene, carbon tetrachloride, thinner, acetone, or window cleaning sprays.

- (4) After cleaning plastic surfaces, apply a thin coat of hard polishing wax. Rub lightly with a soft cloth. Do not use a circular motion.
- (5) A severe scratch or mar in plastic can be removed by rubbing out the scratch with jeweler's rouge. Smooth both sides and apply wax.

(e) Cleaning Headliner, Side Panels and Seats

- (1) Clean headliner, side panels, and seats with a stiff bristle brush, and vacuum where necessary.
- (2) Soiled upholstery, except leather, may be cleaned with a good upholstery cleaner suitable for the material. Carefully follow the manufacturer's instructions. Avoid soaking or harsh rubbing.

CAUTION

Solvent cleaners require adequate ventilation.

- (3) Leather should be cleaned with saddle soap or a mild hand soap and water.

(f) Cleaning Carpets

To clean carpets, first remove loose dirt with a whisk broom or vacuum. For soiled spots and stubborn stains use a nonflammable dry cleaning fluid. Floor carpets may be cleaned like any household carpet.

8.29 WINTERIZATION

For winter operation a winterization kit is installed on the inlet opening of the oil cooler outboard chamber of the plenum chamber. This kit should be installed whenever the ambient temperature is 50°F or less. When the kit is not being used it can be stowed on the forward right hand side of the firewall (long flange down) using the screw provided.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 9

SUPPLEMENTS

Paragraph/Supplement No.		Page No.
9.1	General	9-1
1	Air Conditioning System Installation	9-3
2	AutoFlite II Autopilot Installation	9-7
3	AutoControl IIIB Autopilot Installation	9-9
4	Piper Electric Pitch Trim	9-13
5	Oxygen Installation	9-15

SECTION 9
SUPPLEMENTS

9.1 GENERAL

This section provides information in the form of Supplements which are necessary for efficient operation of the airplane when equipped with one or more of the various optional systems and equipment not provided with the standard airplane.

All of the Supplements provided by this section are "FAA Approved" and consecutively numbered as a permanent part of this Handbook. The information contained in each Supplement applies only when the related equipment is installed in the airplane.

THIS PAGE INTENTIONALLY LEFT BLANK

SUPPLEMENT 1

AIR CONDITIONING INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the efficient operation of the airplane when the optional air conditioning system is installed. The information contained within this supplement is to be used "as described" in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional air conditioning system is installed.

SECTION 2 - LIMITATIONS

- (a) To insure maximum climb performance the air conditioner must be turned "OFF" manually prior to takeoff to disengage the compressor and retract the condenser door. Also the air conditioner must be turned "OFF" manually before the landing approach in preparation for a possible go-around.
- (b) Placards
In full view of the pilot, in the area of the air conditioner controls when the air conditioner is installed:

"WARNING - AIR CONDITIONER MUST BE OFF TO INSURE
NORMAL TAKEOFF CLIMB PERFORMANCE."

In full view of the pilot, to the right of the engine gauges (condenser door light):

"AIR COND DOOR
OPEN"

SECTION 3 - EMERGENCY PROCEDURES

No changes to the basic Emergency Procedures provided by Section 3 of this Pilot's Operating Handbook are necessary for this supplement.

SECTION 4 - NORMAL PROCEDURES

Prior to takeoff, the air conditioner should be checked for proper operation as follows:

- (a) Check aircraft master switch "ON."
- (b) Turn the air conditioner control switch to "ON" and the fan switch to one of the operating positions - the "AIR COND DOOR OPEN" warning light will turn on, thereby indicating proper air conditioner condenser door actuation.
- (c) Turn the air conditioner control switch to "OFF" - the "AIR COND DOOR OPEN" warning light will go out, thereby indicating the air conditioner condenser door is in the up position.
- (d) If the "AIR COND DOOR OPEN" light does not respond as specified above, an air conditioner system or indicator bulb malfunction is indicated and further investigation should be conducted prior to flight.

The above operational check may be performed during flight if an in flight failure is suspected.

The condenser door light is located to the right of the engine instrument cluster in front of the pilot. The door light illuminates when the door is open and is off when the door is closed.

SECTION 5 - PERFORMANCE

Operation of the air conditioner will cause slight decreases in cruise speed and range. Power from the engine is required to run the compressor, and the condenser door, when extended, causes a slight increase in drag. When the air conditioner is turned off there is normally no measurable difference in climb, cruise or range performance of the airplane.

NOTE

To insure maximum climb performance the air conditioner must be turned off manually before takeoff to disengage the compressor and retract the condenser door. Also the air conditioner must be turned off manually before the landing approach in preparation for a possible go-around.

Although the cruise speed and range are only slightly affected by the air conditioner operation, these changes should be considered in preflight planning. To be conservative, the following figures assume that the compressor is operating continuously while the airplane is airborne. This will be the case only in extremely hot weather.

- (a) The decrease in true airspeed is approximately 6 KTS at all power settings.
- (b) The decrease in range may be as much as 45 nautical miles for the 77 gallon capacity.

The climb performance is not compromised measurably with the air conditioner operating since the compressor is declutched and the condenser door is retracted, both automatically, when 38 inches Hg. or more manifold pressure is used. When less than 38 inches Hg. manifold pressure is used or in the event of a malfunction which would cause the compressor to operate and the condenser door to be extended, a decrease in rate of climb of as much as 100 fpm can be expected at all altitudes. Should a malfunction occur which prevents condenser door retraction when the compressor is turned off, a decrease in rate of climb of as much as 50 fpm can be expected.

THIS PAGE INTENTIONALLY LEFT BLANK

SUPPLEMENT 2

AUTOFLITE II AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional AutoFlite II Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook based on EDO-AIRE Mitchell STC SA3162SW-D and must remain in this handbook at all times when the optional AutoFlite II Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot operation prohibited above 175 KIAS. (Autopilot Vmo)
- (b) Autopilot must be "OFF" for takeoff and landing.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In case of malfunction, depress disconnect switch on pilot's control wheel, or overpower autopilot at either control wheel.
- (b) AutoFlite II master switch - OFF.
- (c) In climb, cruise or descent configuration a malfunction with a 3 second delay in recovery initiation may result in 50° bank and 190 foot altitude loss. Maximum altitude loss measured at 175 KIAS in a descent.
- (d) In approach configuration, coupled or uncoupled, a malfunction with a 1 second delay in recovery initiation may result in 18° bank and 20 foot altitude loss.

SECTION 4 - NORMAL PROCEDURES

AUTOFLITE II PREFLIGHT INSPECTION

- (a) AutoFlite II master switch - ON.
- (b) Rotate turn command knob to left and right. Aircraft control wheels should rotate in corresponding directions.
- (c) With AutoFlite II on, rotate aircraft control wheel to left and right. Only light forces should be required to override roll servo clutch.
- (d) AutoFlite II master switch - OFF - rotate control wheel left and right to assure disengagement.

AUTOFLITE II IN-FLIGHT PROCEDURE

- (a) Engagement
 - (1) Check turn command knob in center detent position.
 - (2) AutoFlite II master switch - ON.
- (b) Disengagement
 - (1) AutoFlite II master switch - OFF.
- (c) Heading Changes
 - (1) Move trim knob on instrument for drift correction from a constant heading.
 - (2) Move turn command knob for left or right banked turns. Rotation of knob to stop will yield an appropriate bank angle to obtain an approximate standard rate turn. Intermediate settings may be used for lesser turn rates.
- (d) OMNI Tracker
 - (1) Turn command knob - move to center detent position and push IN to engage tracker. Aircraft will track desired radial established on NAV 1 (or as selected, if equipped with a NAV selector switch).

NOTE

Tracker must be engaged within 10° of being "on course," i.e. VOR course needle centered and aircraft heading within 10° of VOR course.

- (2) Trim knob - push IN for high sensitivity. Use high sensitivity position for localizer tracking and as desired for OMNI tracking.
- (e) Maintain directional trim during all autopilot operations.

PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 3

AUTOCONTROL IIIB AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper AutoControl IIIB Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook based on EDO-AIRE Mitchell STC SA3161SW-D and must remain in this handbook at all times when the optional Piper AutoControl IIIB Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot operation prohibited above 175 KIAS. (Autopilot Vmo)
- (b) Autopilot must be OFF for takeoff and landing.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In an emergency the AutoControl IIIB can be disconnected by:
 - (1) Pushing the A/P ON-OFF rocker switch - "OFF."
 - (2) Pulling the autopilot circuit breaker.
- (b) The autopilot can be overpowered at either control wheel.
- (c) An autopilot runaway, with a 3 second delay in the initiation of recovery while operating in climb, cruise or descending flight, could result in a 58° bank and 190 foot altitude loss. Maximum altitude loss measured at 175 KIAS in a descent.
- (d) An autopilot runaway, with a 1 second delay in the initiation of recovery, during an approach operation, coupled or uncoupled, could result in 18° bank and 20 foot altitude loss.
- (e) Emergency operation with optional NSD 360 and NSD 360A (HSI) - Slaved and/or Non-Slaved:

NSD 360

- (1) Appearance of HDG Flag:
 - a. Check air supply gauge (vac or pressure) for adequate air supply (4 in. Hg. min.).
 - b. Check compass circuit breaker.
 - c. Observe display for proper operation.
- (2) To disable heading card - pull circuit breaker and use magnetic compass for directional data.

NOTE

If heading card is not operational, autopilot should not be used.

- (3) With card disabled:
 - a. VOR and Glide Slope displays are still functional; use card set to rotate card to aircraft heading for correct picture.
 - b. Localizer - left-right information still usable. Flag information is disabled - compare needle with No. 2 indicator for valid left-right needle operation.
- (4) Slaving Failure - (i.e. failure to self correct for gyro drift):
 - a. Check gyro slaving switch is set to No. 1 position.
 - b. Check for HDG Flag.
 - c. Check compass circuit breaker.
 - d. Reset heading card while observing slaving meter.
 - e. Select slaving amplifier No. 2 (gyro slaving switch is set to No. 2 position).
 - f. Reset heading card while checking slaving meter.
 - g. Switch to free gyro and periodically set card as unslaved gyro.

NSD 360A (Instrument with red-white striped NAV-HDG Flags)

- (1) The emergency procedures for the NDS 306A remain identical to those listed for the NSD 360 (above), except that the presence of the NAV Flag on a localizer frequency invalidates the NAV left-right information. Usable navigation data will be indicated in both VOR and Localizer modes by the absence of the NAV Flag, whether the card is disabled or not.
- (2) In the localizer mode the "TO-FROM" arrows may remain out of view, depending upon the design of the NAV converter used in the installation.

SECTION 4 - NORMAL PROCEDURES

PREFLIGHT INSPECTION

(a) AUTOPILOT

- (1) Place Radio Coupler in "HDG" Mode (if installed) and place the AP "ON-OFF" switch to the "ON" position to engage roll section. Rotate roll command knob left and right and observe that control wheel describes a corresponding left and right turn, then center knob.
- (2) Set proper D.G. heading on D.G. and turn HDG bug to aircraft heading. Engage "HDG" mode rocker switch and rotate HDG bug right and left. Aircraft control wheel should turn same direction as bug. Grasp control wheel and manually override servo, both directions.

(b) RADIO COUPLER - (OPTIONAL)

- (1) Tune and identify VOR or VOT station. Position Radio Coupler to OMNI Mode. Engage Autopilot "ON" and HDG switches. Set HDG bug to aircraft heading and rotate O.B.S. to cause OMNI indicator needle to swing left and right slowly. Observe that control wheel rotates in direction of needle movement.
- (2) Disengage AP "ON-OFF" switch. Reset Radio Coupler control to HDG.

IN-FLIGHT

- (a) Trim airplane (ball centered).
- (b) Check air pressure or vacuum to ascertain that the directional gyro and attitude gyro are receiving sufficient air.

- (c) Roll Section:
- (1) To engage, center Roll knob, push AP "ON-OFF" switch to "ON" position. To turn, rotate console ROLL knob in desired direction. (Maximum angle of bank should not exceed 30°.)
 - (2) For heading mode, set directional gyro with magnetic compass. Push directional gyro HDG knob in, rotate bug to aircraft heading. Push console heading rocker (HDG) switch to "ON" position. To select a new aircraft heading, push D.G. heading knob "IN" and rotate, in desired direction of turn, to the desired heading.
- (d) Radio Coupling VOR-ILS with (Horizontal Situation Indicator) H.S.I. Type Instrument Display. (Optional)
- (1) VOR Navigation
 - a. Tune and identify VOR Station. Select desired course by rotating CRS knob of H.S.I.
 - b. Select OMNI mode on Radio Coupler.
 - c. Select HDG mode on autopilot console to engage coupler. Aircraft will turn to a 45° intercept angle to intercept the selected VOR course. Intercept angle magnitude depends on radio needle off course magnitude, 100% needle deflection will result in 45° intercept with the intercept angle diminishing as the needle off set diminishes.
 - d. NAV mode - NAV mode provides reduced VOR sensitivity for tracking weak, or noisy VOR signals. NAV mode should be selected after the aircraft is established on course.
 - (2) ILS-LOC Front Course
 - a. Set inbound, front, localizer course on H.S.I.
 - b. Select LOC-Normal non-Radio Coupler to intercept and track inbound on the localizer. Select LOC-REV to intercept and track outbound to the procedure turn area.
 - c. Select HDG Mode on autopilot console to engage coupler.
 - (3) ILS - Back Course
 - a. Set inbound, front localizer course on H.S.I.
 - b. Select LOC-REV on radio coupler to intercept and track inbound on the back localizer course. Select LOC-NORM to intercept and track outbound on the back course to the procedure turn area.
 - c. Select HDG mode on autopilot console to engage coupler.
- (e) Radio Coupling – VOR/ILS with Standard directional gyro. (Optional)
- Radio Coupler operation in conjunction with a standard directional gyro and VOR/LOC display differs from operation with an integrated display (H.S.I.) only in one respect. The HDG bug is used as the radio course datum and therefore must be set to match the desired VOR course as selected on the O.B.S.
- (1) For VOR Intercepts and Tracking:

Select the desired VOR course and set the HDG bug to the same heading. Select OMNI mode on the coupler and HDG Mode on the autopilot console.
 - (2) For ILS Front Course Intercepts and Tracking:

Tune the localizer frequency and place the HDG bug on the inbound, front course heading. Select LOC-NORM mode on the coupler and HDG mode on the autopilot console.
 - (3) For LOC Back Course Intercepts and Tracking:

Tune the localizer frequency and place the HDG bug on the inbound course heading to the airport. Select LOC-REV mode with coupler and HDG mode on the autopilot console.

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of the Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 4

PIPER ELECTRIC PITCH TRIM

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper Electric Pitch Trim is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional Piper Electric Pitch Trim is installed.

SECTION 2 - LIMITATIONS

No changes of the basic limitations provided by Section 2 of this Pilot's Operating Handbook are necessary for this supplement.

SECTION 3 - EMERGENCY PROCEDURES

The following information applies in case of electric trim malfunction:

- (a) In case of malfunction, disengage electric pitch trim by pushing pitch trim switch on instrument panel to off position.
- (b) In an emergency, electric pitch trim may be overpowered using manual pitch trim, and or control wheel pressure.
- (c) In cruise configuration, a malfunction can result in a 15° pitch change and 500 ft. altitude variation.
- (d) In approach configuration, a malfunction can result in a 20° pitch change and 500 ft. altitude loss.

SECTION 4 - NORMAL PROCEDURES

The electric trim system may be turned ON or OFF by a switch located above the ignition switch. The pitch trim may be changed when the electric trim system is turned on either by moving the manual pitch trim control wheel or by operating the trim control switch on the pilot's control yoke.

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

THIS PAGE INTENTIONALLY LEFT BLANK

SUPPLEMENT 5

OXYGEN INSTALLATION - SCOTT AVIATION PRODUCTS
EXECUTIVE MARK III PART NUMBER 802180-02

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional oxygen system is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional oxygen system is installed.

SECTION 2 - LIMITATIONS

- (a) No smoking allowed.
- (b) The aircraft is restricted to four occupants with one (1) oxygen unit installed.
- (c) Oxygen duration:

DURATION IN HOURS AT ALTITUDE

PERSONS USING EACH UNIT	5,000	10,000	15,000	20,000
1	10.6	6.3	4.7	3.8
2	5.3	3.2	2.4	1.9
3	3.5	2.1	1.6	1.3
4	2.7	1.6	1.2	.95

SECTION 3 - EMERGENCY PROCEDURES

- (a) Time of useful consciousness at 20,000 ft. is approximately 10 minutes.
- (b) If oxygen flow is interrupted as evidenced by the flow indicators or hypoxic indications:
 - (1) Install another mask unit.
 - (2) Install mask connection in an unused outlet if available.
 - (3) If flow is not restored, immediately descend to below 12,500 feet.

SECTION 4 - NORMAL PROCEDURES

PREFLIGHT

- (a) Check oxygen quantity.
- (b) Installation
 - (1) Install mounting base between center seats utilizing slotted receptacles for front and rear attachment points.
 - (2) Slide oxygen bottle into position on top of mounting base ensuring that all mounting lugs engage in the slotted receptacle and that the locking pin is in the raised position.
- (c) Turn on oxygen system and check flow indicators on all masks. All masks are stowed in the oxygen system containers.

IN-FLIGHT

- (a) Adjust oxygen mask.
- (b) Turn on system.
- (c) Monitor flow indicators and quantity.

CAUTION

Use of oxygen unit is prohibited when gauge approaches red area.

SECTION 5 - PERFORMANCE

Installation of the oxygen system does not affect the basic performance information presented in Section 5 of this Pilot's Operating Handbook.

TABLE OF CONTENTS

SECTION 10

SAFETY TIPS

Paragraph No.		Page No.
10.1	General	10-1
10.3	Safety Tips	10-1

SECTION 10
SAFETY TIPS

10.1 GENERAL

This section provides safety tips of particular value in the operation of the Cherokee Turbo Arrow III.

10.3 SAFETY TIPS

- (a) Learn to trim for takeoff so that only a very light back pressure on the control wheel is required to lift the airplane off the ground.
- (b) The best speed for takeoff is about 80 KIAS under normal conditions. Trying to pull the airplane off the ground at too low an airspeed decreases the controllability of the airplane in the event of engine failure.
- (c) Flaps may be lowered at airspeeds up to 103 KIAS. To reduce flap operating loads, it is desirable to have the airplane at a slower speed before extending the flaps. The flap step will not support weight if the flaps are in any extended position. The flaps must be placed in the "UP" position before they will lock and support weight on the step.
- (d) Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.
- (e) Before starting the engine, check that all radio switches, light switches and the pitot heat switch are in the off position so as not to create an overloaded condition when the starter is engaged.
- (f) Strobe lights should not be operating when flying through overcast and clouds, since reflected light can produce spacial disorientation. Do not operate strobe lights when in close proximity to ground.
- (g) The rudder pedals are suspended from a torque tube which extends across the fuselage. The pilot should become familiar with the proper positioning of his feet on the rudder pedals so as to avoid interference with the torque tube when moving the rudder pedals or operating the toe brakes.
- (h) In an effort to avoid accidents, pilots should obtain and study the safety related information made available in FAA publications such as regulations, advisory circulars, Aviation News, AIM and safety aids.

- (i) The shape of the wing fuel tanks is such that in certain maneuvers the fuel may move away from the tank outlet. If the outlet is uncovered, the fuel flow will be interrupted and a temporary loss of power may result. Pilots can prevent inadvertent uncovering of the outlet by avoiding maneuvers which could result in uncovering the outlet.

Extreme running turning takeoffs should be avoided as fuel flow interruption may occur.

Prolonged slips or skids which result in excess of 2000 ft. of altitude loss, or other radical or extreme maneuvers which could cause uncovering of the fuel outlet must be avoided as fuel flow interruption may occur when tank being used is not full.